

LT2218A

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar




ILLUSTRATED PARTS LIST

MFG. ID NO. 96041003500


CUSTOMER CATALOG NO. LT2218A

PRODUCT NO. 960 41 00-35



408625


TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35
DECALS



KEY NO.	PART NO.	DESCRIPTION
1	532 18 21-66	Decal, Cutfinger Warning
3	532 19 63-57	Decal, Warning Symbol
4	532 14 08-37	Decal, Brake Parking
5	532 40 03-89	Decal, Warning Symbol CE
6	532 18 04-32	Decal, Fender DB/CE
7	532 15 97-37	Decal, Brake/Clutch Symbol
8	532 16 03-96	Decal, Mower Sch.
9	532 14 50-05	Decal, Battery Dnge/Poi
10	532 15 97-36	Decal, Hot Muffler
11	532 19 68-41	Decal, Engine Warning
12	532 40 94-65	Decal, Engine HP
13	532 18 57-73	Decal, Steering Wheel

KEY NO.	PART NO.	DESCRIPTION
14	532 40 90-02	Decal, Panel Side
15	532 40 90-03	Decal Fender
16	532 18 95-53	Decal, Hood Logo
17	532 40 86-25	Decal, Replacement
18	532 18 39-30	Decal, Cover/Belt Guard
--	532 16 69-60	Decal, Bypass
--	532 16 25-98	Decal, Load Limit
--	532 40 95-04	Pad, Footrest, LH
--	532 41 12-73	Pad, Footrest, RH
--	532 40 87-05	Manual Oper. Euro
--	532 40 87-06	Manual Oper. Scand
--	532 40 87-07	Manual Oper. E-Bloc
--	532 40 87-08	Manual Oper. Baltic

WHEELS AND TIRES




KEY NO.	PART NO.	DESCRIPTION
1	532 05 91-92	Cap, Valve, Tire
2	532 06 51-39	Stem, Valve
3	532 13 83-36	Rim Assembly, Front
4	532 05 99-04	Tube, Front (Service Item Only)
5	532 10 62-22	Tire, Front
6	532 12 49-57	Fitting, Grease (Front Wheel Only)
7	532 12 49-59	Bearing, Flange (Front Wheel Only)
8	532 17 50-39	Cap, Axle
9	532 12 20-82	Tire, Rear
10	532 12 49-26	Tube, Rear (Service Item Only)
11	532 13 83-37	Rim Assembly, Rear
--	532 14 43-34	Sealant, Tire (10 oz. Tube)


NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35
SCHEMATIC

03025-194276_Regulated-Tex (12V)



03025




TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35
ELECTRICAL

KEY NO.	PART NO.	DESCRIPTION
1	532 14 49-27	Battery
2	874 76 04-12	Bolt Hex Hd 1/4-20 unc x 3/4
8	532 19 32-28	Battery Box
16	532 17 61-38	Switch Interlock
21	532 17 56-88	Harness Socket Light
22	532 00 41-52	Bulb, Light # 1156
25	532 19 88-93	Cable Starter
26	532 17 51-58	Fuse
27	873 51 04-00	Nut Keps Hex 1/4-20 unc
28	532 19 88-85	Cable Ground
29	532 40 15-45	Switch Seat
30	532 19 33-50	Switch Ign
33	532 14 04-01	Key Ign Molded Generic
34	532 11 07-12	Switch Light/Reset
40	532 40 11-04	Harness Ign. Dash
41	817 72 04-08	Screw Thd Cut 1/4-20 x 1/2
42	532 13 15-63	Cover Terminal Red ®
43	532 19 25-07	Solenoid
46	532 40 17-63	Gauge Hourmeter
50	532 17 46-51	Switch PTO
55	817 06 05-12	Screw Thdrol 5/16-18 x 3/4
71	532 40 04-49	Harness Chassis
79	532 17 52-42	Socket Asm. Bulb Twistlock
90	532 40 07-25	Cover Terminal Battery
92	532 19 66-15	Harness Pigtail Console
93	532 19 25-40	Screw Plastic 10-14 x 2.0
94	532 19 18-34	Module Reverse

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35

CHASSIS



chassis-tex_1_Stealth_II_SRS2

TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35 CHASSIS


KEY NO.	PART NO.	DESCRIPTION
5	532 41 14-10	Dash
14	532 18 13-51	Hood
18	532 18 13-52	Grille
34	532 19 61-25	Plate Engine
36	817 06 05-12	Screw 5/16-18 x 3/4
37	532 41 14-18	Fender
68	817 49 05-08	Screw 5/16-18 x 1/2
99	532 40 50-92	Rod Bypass Asm.
130	532 19 16-11	Screw 10 x 3/4 Single Lead Hex
138	532 40 97-30	Cupholder
148	532 16 46-55	Bumper Extrusion
150	532 17 53-51	Duct Heat Hood
152	532 19 95-35	Shield Browning/Debris
153	532 17 97-61	Lens Asm
162	532 14 24-32	Screw 1/4 x 1/2
175	532 19 32-36	Crossmember
176	532 40 07-76	Screw 10-24 x 5/8 Rnd Qdrx

KEY NO.	PART NO.	DESCRIPTION
177	532 19 52-27	Bushing Steering
178	532 19 56-51	Cargo Asm. Net
180	532 19 54-57	Chassis
181	532 40 47-96	Bushing Mtg. Fender Crgo.
182	532 19 25-51	Dash Lower
183	874 78 05-20	Bolt Hex 5/16-18 x 1-1/4
189	817 00 05-12	Screw 5/16-18 x 3/4
194	873 90 05-00	Nut Lock Hex Flange 5/16-18
195	532 40 41-37	Plug
196	532 40 97-28	Console Asm. Deck Lift
222	532 13 77-29	Screw 1/4-20 x 5/8
228	532 19 51-61	Stud Fastner
230	532 17 01-65	Bolt Shoulder 5/16-18
235	532 40 61-29	Spacer Fender
236	873 93 05-00	Nut Center Lock 5/16-18 unc
237	532 19 63-94	Bracket Hood/Muff
--	532 41 14-11	Phone Holder

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm



TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35 DRIVE



drive-tex_71-lt-hydro

TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35 DRIVE


KEY PART NO. NO.

DESCRIPTION

1	---	Transaxle, Hydro 351-0510 (Order Parts from Transaxle Manufacturer)	172	532 19 76-56	Strap Torque LH
2	532 12 35-83	Key	173	532 19 76-55	Strap Torque RH
15	819 13 13-16	Washer 13/32 x 13/16 x 16 Ga.	174	532 19 72-89	Nut Push
17	532 19 72-96	Spring, Brake	175	532 19 76-53	Shaft Asm
22	532 19 76-60	Rod Shift	176	532 19 62-14	Asm Clevis Rod Shift
23	532 13 05-64	Knob	178	532 19 74-56	Spring Shift
29	532 19 76-59	Rod, Brake	183	532 13 70-57	Spacer Axle
33	812 00 00-01	Ring E	184	532 41 17-16	Handle Parking Brake
35	532 19 72-75	Rod, Brake, Park	185	872 11 06-20	Bolt
37	532 12 17-49	Washer 25/32 x 1-1/4 x 16 Ga.	186	532 19 43-21	Spacer Retainer
42	532 12 48-72	Cover, Foot Pedal	187	819 13 32-10	Washer
49	872 11 06-14	Bolt	188	532 19 43-23	Link Clutch Ground Drive
50	532 19 43-27	Pulley Idler Flat	189	532 19 43-17	Bellcrank Ground Drive
51	873 90 06-00	Lock Nut 3/8-16	190	532 19 43-18	Keeper Bellcrank Ground Drive
52	532 19 43-26	Idler V-Groove 910" Offset	195	532 19 80-12	Bracket Rod Brake
56	532 14 02-18	V-Belt, Drive	196	817 00 06-16	Screw 3/8-16 x 1
64	532 19 62-00	Shaft Asm. Pedal Brake Control	197	532 19 58-04	Link Clutch Anti-Rotation
70	532 41 13-29	Console Shift	199	872 14 05-08	Bolt RDHD SQNK 5/16-18 unc x 1
73	874 49 05-44	Bolt Hex Flghd 5/16-18 Gr. 5	200	873 93 05-00	Nut Center Lock 5/16-18 unc
74	532 14 24-32	Screw Hex WSH Hi-Lo 1/4 x 1/2 unc	201	532 16 96-12	Bolt Shoulder 5/16-18 unc
114	873 80 05-00	Nut Lock Hex W/INS 5/16-18 unc	202	532 19 77-14	Link Trans
116	873 90 05-00	Nut Lock Hex Flange 5/16-18	203	819 11 11-16	Washer 11/32 x 11/16 x 16 Ga.
125	817 00 05-12	Screw 5/16-18 x 3/4	205	532 12 17-48	Washer 25/32 x 1-5/8 x 16 Ga.
143	817 49 05-08	Screw 5/16-18 x 1/2	216	532 19 61-31	Bracket Pulley Idler
148	817 00 06-12	Screw 3/8-16 x 3/4	221	532 40 31-87	Retainer Spring Clip Handle
159	876 02 04-12	Pin Cotter 1/8 x 3/4	268	819 13 16-14	Washer 13/32 x 1 x 14 Ga.
160	532 16 94-84	Retainer Clip	275	532 18 24-02	Guard Muffler
161	532 19 54-03	Spring, Return, Clutch	276	874 78 07-16	Bolt 7/16-14 x 1 Gr. 5
165	532 40 52-57	Bushing	277	532 40 52-96	Washer Serrated
166	532 19 72-90	Nut Push .625			
167	532 40 52-57	Latch Brake Parking			
170	532 19 43-22	Keeper Belt Centerspan			
171	872 11 06-16	Bolt			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35
ENGINE



TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35 ENGINE

KEY NO.	PART NO.	DESCRIPTION
1	---	Engine Briggs Model No. 31G777
2	532 13 73-52	Muffler
9	532 19 43-19	Keeper Belt Engine
11	532 18 05-05	Clutch Electric
12	532 19 43-38	Pulley Engine
15	532 40 75-52	Tank Fuel
18	532 19 77-25	Cap Asm
20	532 18 38-97	Control Throttle
21	532 19 16-11	Screw 10 x 3/4 Single Lead Hex
22	532 19 49-81	Control Choke
28	532 13 70-40	Fuel Line
29	532 13 71-80	Spark Arrester Kit
31	532 14 50-06	Clip Push-In
37	532 12 34-87	Clamp Hose
41	532 12 61-97	Washer 1-1/2 OD x 15/32 ID x .250
42	810 04 07-00	Washer Lock 7/16
45	873 51 04-00	Nut Keps Hex 1/4-20 unc
69	532 16 52-91	Gasket
79	532 19 23-34	Screw 5/16-18 x .75
81	532 14 84-56	Tube Drain Oil Easy
82	532 18 16-54	Plug Drain Oil Easy
84	817 06 06-20	Screw 3/8-16 x 1-1/4
85	532 17 39-37	Bolt Hex 7/16-20 x 4 x Gr. 5-1.5
90	817 00 06-16	Screw 3/8-16 x 1
96	819 09 14-16	Washer 9/32 x 7/8 x 16 GA
97	817 67 04-12	Screw 1/4 - 20 x 3/4

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm


For engine service and replacement parts, call the toll free
number for your engine manufacturer listed below:

Briggs & Stratton 1-800-233-3723

Engine Power Rating Information

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J11940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-5). Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net horsepower). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35
STEERING ASSEMBLY




TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35
STEERING ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION
1	532 19 46-37	Wheel, Steering
2	532 19 56-73	Axle Asm., Front
4	532 40 30-87	Spindle Asm., LH
5	532 40 30-88	Spindle Asm., RH
6	532 12 49-31	Bearing, Race Thrust Harden
7	532 12 17-48	Washer 25/32 x 1-5/8 x 16 Ga.
8	812 00 00-29	Ring, Klip #T5304-75
9	532 12 12-32	Cap, Spindle
13	532 12 17-49	Washer 25/32 x 1-1/4 x 16 Ga.
14	810 04 06-00	Washer, Lock Hvy Hlcl Spr 3/8
15	873 54 06-00	Nut, Crown Lock 3/8-24 unf
16	532 19 47-46	Shaft Steering
19	532 19 47-29	Plate Steering
20	532 41 14-25	Boot
21	532 18 67-37	Adapter, Wheel Steering
22	532 19 48-45	Bushing, Strg. Blk
26	532 19 36-52	Insert, Wheel Steering
28	817 00 06-12	Screw 3/8-16 x 3/4
35	532 19 47-32	Gear, Sector Plate
45	819 11 38-12	Washer 9/16 x 2-3/8 x 12 Ga.
51	873 94 08-00	Nut Hex Jam Toplock 1/2-20 unf
53	532 18 89-67	Washer Hardened .793 x 1.637 x .060
57	532 40 74-65	Bracket Upstop
58	532 19 47-47	Bolt Shoulder Sector Pivot CFM
59	532 19 47-48	Washer Thrust Sector Steering
60	873 97 10-00	Nut Flange Lock 5/8-11
61	532 19 47-40	Draglink LH
62	532 19 47-41	Draglink, RH
63	817 00 05-12	Screw 5/16-18 x 3/4
64	532 19 98-49	Retainer Clip Spring Steering
66	871 02 07-48	Bolt Hex Fghd 7/16-14 x 3 Serr
67	532 19 47-37	Bushing PM Front Axle
68	873 90 07-00	Nut Lock Flange 7/16-14 Gr. 5
69	532 19 91-62	Washer 1.5 x .505 x .118
70	532 19 61-97	Bracket Deck Susp. Front
73	532 12 49-37	Bushing

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

**TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35
MOWER DECK**



42_D_elec-Tex_6


TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35

MOWER DECK

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 19 64-95	Mower Deck Assembly, 42"	40	873 90 06-00	Nut Lock 3/8-16
6	532 19 51-86	Arm Susp. Rear	55	532 19 72-49	Arm, Idler
8	532 19 30-03	Bolt/Washer Asm 7/16-20 unf (The following Blades are available)	56	532 19 90-92	Spacer, Retainer
11	532 13 89-71	Blade Mower 42" Hi-Lift (for bagging and discharging)	57	817 00 06-16	Screw 3/8-16 x 1
13	532 19 28-72	Shaft Assembly, Mandrel	59	532 14 10-43	Guard TUV Idler
14	532 18 72-81	Housing, Mandrel	62	872 11 06-16	Bolt Rdhd Sqnk 3/8-16 unc x 2
15	532 11 04-85	Bearing, Ball, Mandrel	68	532 14 49-59	V-Belt, 42" Mower
16	532 17 44-93	Stripper, Mandrel Deck	69	872 14 05-05	Bolt, Carriage 5/16-18 x 5/8
19	532 19 65-39	Bolt, Shoulder	97	532 17 85-15	Washer Flat Hardened
20	532 15 97-70	Baffle, Vortex	116	532 12 48-42	Bolt, Shoulder
21	873 68 05-00	Nut	117	532 18 86-06	Wheel, Gauge
23	532 19 25-57	Bracket, Deflector Mower 42"	118	873 93 06-00	Nut Centerlock 3/8-16
24	532 10 53-04	Cap, Sleeve 80 x 112 Blk Mower	119	819 12 14-14	Washer 3/8 x 7/8 x 14 Ga.
25	532 19 70-26	Spring, Torsion, Deflector	145	532 19 31-97	Pulley Idler
26	532 11 04-52	Nut, Push Phos & Oil	188	532 19 51-61	Stud Fastner W/D Anti-Rotation
27	532 40 30-04	Shield, Deflector 42" Blk	189	873 90 05-00	Nut Lock Hex Flange 5/16-18
29	532 13 14-91	Rod, Hinge 42" 6 75 W/G	190	532 19 72-51	Spring Mower Drive
30	532 17 39-84	Screw Thdrol	--	532 19 28-70	Mandrel Assembly (Includes Housing Shaft and Shaft Hardware Only - Pulley Not Included)
31	532 18 76-90	Washer, Spacer Mower Vented	--	532 19 97-50	Replacement Mower, Complete (Std. deck Order separately gauge wheel componants Key Nos. 116-119)
32	532 15 35-35	Pulley, Mandrel			
33	532 40 02-34	Nut, Toplock			
34	872 11 06-12	Bolt Carr SH 3/8-16 x 1-1/2 Gr.5			
36	532 19 73-79	Pulley, Idler, Flat			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35
SEAT ASSEMBLY




seat-tex_7-vgt

KEY NO.	PART NO.	DESCRIPTION
1	532 40 66-25	Seat
2	532 18 01-66	Bracket Pivot Fender
3	532 14 06-75	Strap, Asm Fender
6	873 80 06-00	Nut, Lock W/Ins. 3/8-16 unc
7	532 12 41-81	Spring, Seat Cprsn
8	532 17 18-77	Bolt 5/16-18 uncx 3/4 w/Sems
10	532 19 69-77	Pan, Seat

KEY NO.	PART NO.	DESCRIPTION
21	532 17 18-52	Bolt, Shoulder 5/16-18
37	873 80 05-00	Nut, Lock 5/16-18 unc
40	532 19 76-61	Handle Slide Seat
41	532 19 82-00	Spring Latch Seat
43	874 76 06-12	Bolt 3/8-16 x 3/4
44	819 13 38-12	Washer 13/32 x 2-3/8 x 12 Ga.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR - MODEL NO. LT2218A (96041003500), PRODUCT NO. 960 41 00-35
MOWER LIFT



KEY NO.	PART NO.	DESCRIPTION
---------	----------	-------------

2	532 19 52-23	Shaft Asm., Lift
3	532 19 52-31	Lever Lift Handle
7	532 19 64-92	Grip, Lever
10	532 19 63-14	Spring Torsion
87	532 19 42-09	Pin Cotter 7/16 Bow Tie Lock
88	532 19 53-03	Spring Lift Assist

KEY NO.	PART NO.	DESCRIPTION
---------	----------	-------------

89	819 19 19-12	Washer Clear Zinc
90	532 19 42-08	Pin Cotter 5/16 Bow Tie Lock
91	532 19 51-81	Link Lift Susp Mower Rear
97	817 06 06-12	Screw 3/8-16 x .75 Smgml Tap/R.Z
98	532 19 52-70	Link Lift Susp. Front Mower
100	873 93 06-00	Nut 3/8-16 unc

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

