

# CTH155

**Spare parts**

**Ersatzteile**

**Pièces détachées**


**Reserve onderdelen**

**Repuestos**

**Reservdelar**


**GPL®**

# TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84 SCHEMATIC



# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
ELECTRICAL



# REPAIR PARTS


TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
ELECTRICAL

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                       |
|------------|--------------|-----------------------------------|
| 1          | 532 16 34-65 | Battery                           |
| 2          | 874 76 04-12 | Bolt Hex Hd 1/4-20 Unc X 3/4      |
| 16         | 532 17 61-38 | Switch Interlock                  |
| 21         | 532 17 56-88 | Harness Asm Light W/4152J         |
| 22         | 532 00 41-52 | Bulb Light #1156                  |
| 24         | 532 12 47-80 | Cable Starter 6Ga 11" Red         |
| 25         | 532 16 59-87 | Cable Battery Crd 56" Red         |
| 26         | 532 17 51-58 | Fuse                              |
| 27         | 873 51 04-00 | Nut Keps Hex 1/4-20 Unc           |
| 28         | 532 12 77-25 | Cable Ground 6Ga 18" Black        |
| 29         | 532 16 07-84 | Switch Plunger Normal Op Olive    |
| 30         | 532 17 55-66 | Switch Ignition                   |
| 33         | 532 14 04-01 | Key Ign                           |
| 40         | 532 17 97-27 | Harness Ign                       |
| 41         | 871 11 04-08 | Bolt Flk Fin Hex 1/4-20 Unc X 1/2 |
| 42         | 532 13 15-63 | Cover Terminal Red                |
| 43         | 532 17 88-61 | Solenoid                          |
| 48         | 532 14 08-44 | Adapter Ammeter Rectangular       |
| 50         | 532 17 46-51 | Switch PTO                        |
| 51         | 532 14 04-05 | Ring Retainer PTO                 |
| 52         | 532 14 19-40 | Protection Wire Loop              |
| 58         | 532 16 94-19 | Buzzer Crd                        |
| 59         | 532 18 03-79 | Switch FBI CRD                    |
| 66         | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2 Ty-Tt   |
| 81         | 532 10 97-48 | Relay Asm                         |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
CHASSIS AND ENCLOSURES



# REPAIR PARTS

**TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
CHASSIS AND ENCLOSURES**


| KEY NO. | PART NO.     | DESCRIPTION                                     |
|---------|--------------|-------------------------------------------------|
| 1       | 532 17 46-20 | Chassis                                         |
| 2       | 532 18 03-84 | Drawbar                                         |
| 3       | 817 06 06-12 | Screw 3/8-16 x 3/4                              |
| 5       | 532 15 52-72 | Bumper Hood/Dash                                |
| 6       | 532 18 44-19 | Saddle                                          |
| 8       | 532 12 64-71 | Clip Insulator 13/32 Mtg. Hole                  |
| 9       | 532 18 52-09 | Dash                                            |
| 10      | 872 14 06-08 | Bolt, Carriage 3/8-16 x 3/4                     |
| 11      | 532 17 49-96 | Panel, Dash, L.H.                               |
| 13      | 532 17 21-06 | Panel, Asm. Dash R.H.                           |
| 15      | 874 18 05-12 | Screw, Machine, Truss Head<br>5/16-18 UNC x 3/4 |
| 16      | 873 51 05-00 | Nut                                             |
| 17      | 532 18 52-11 | Hood                                            |
| 18      | 532 18 49-21 | Bumper Hood                                     |
| 20      | 532 18 06-79 | Plate Mtg Battery/Tank Fuel Fr.                 |
| 24      | 874 78 06-16 | Bolt                                            |
| 25      | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Gauge                 |
| 26      | 873 80 06-00 | Nut                                             |
| 28      | 532 18 35-38 | Grille /Lens Asm                                |
| 30      | 532 17 96-45 | Fender                                          |
| 31      | 532 16 51-56 | Bracket, Fender Support                         |
| 33      | 532 18 10-57 | Footrest, L.H.                                  |
| 34      | 532 18 10-58 | Footrest, R.H.                                  |
| 35      | 872 11 06-06 | Bolt                                            |
| 37      | 817 49 05-08 | Screw Thdrol 5/16-18 x 1/2 TYT                  |
| 38      | 532 18 17-48 | Bracket Asm Pivot Mower Rear                    |
| 39      | 532 17 47-14 | Bracket Pivot Laser/Elite.LT                    |
| 58      | 532 15 01-27 | Duct Air Engine                                 |
| 69      | 532 14 24-32 | Screw Hex Wsh                                   |
| 89      | 532 18 10-99 | Console                                         |
| 145     | 532 15 65-24 | Rod Pivot Chassis/Hood                          |
| 162     | 532 18 03-82 | Bracket Exten Chassis Lh CRD                    |
| 163     | 532 18 03-83 | Bracket Exten Chassis Rh CRD                    |

| KEY NO. | PART NO.     | DESCRIPTION                         |
|---------|--------------|-------------------------------------|
| 164     | 532 16 56-05 | Support Battery CRD                 |
| 165     | 532 18 11-00 | Cover Battery                       |
| 166     | 532 17 18-75 | Screw HwHd Hi-Lo #13-16 x 3/4       |
| 170     | 532 17 88-62 | Backplate Asm CRD                   |
| 171     | 872 14 06-20 | Bolt Rdhd Sqnk 3/8-16 x 2-1/2 Gr. 5 |
| 172     | 819 13 20-16 | Washer 13/32 x 1-1/4 x 16 Ga.       |
| 173     | 873 51 06-00 | Nut, Keps Hex 3/8-16 UNC            |
| 175     | 532 18 03-10 | Guard Trap                          |
| 179     | 532 18 03-76 | Rod Pivot FBI CRD                   |
| 184     | 532 17 46-62 | Bracket Actuator Bagger CRD         |
| 185     | 532 18 11-01 | Knob Rod Brake Parking              |
| 186     | 532 16 07-93 | Latch Asm Mulch/Bagger              |
| 187     | 532 12 50-04 | Nut Weld                            |
| 188     | 819 06 12-16 | Washer #10                          |
| 189     | 810 07 10-00 | Washer Lock #10                     |
| 190     | 871 08 10-10 | Screw Pan Hd Phillip 10-24 x 5/8    |
| 198     | 532 16 89-37 | Nut, Push                           |
| 205     | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2           |
| 207     | 817 67 05-08 | Screw Thdrol 5/16-18 x 1/2          |
| 208     | 817 67 06-08 | Screw Thdrol 3/8-16 x 1/2           |
| 209     | 817 00 06-12 | Screw Hex Wsh Thdrol 3/8-16         |
| 212     | 532 18 35-48 | Insert Lens Reflect                 |
| 214     | 532 12 47-88 | Retainer Spring                     |
| 219     | 817 00 05-12 | Screw 5/16-18 x 3/4                 |
| 256     | 532 18 13-61 | Cover Fender Rack CRD               |
| 258     | 532 18 52-13 | Lens Husq. Laser LT Clear RH        |
| 259     | 532 18 52-14 | Lens Husq. Laser LT Clear LH        |
| 260     | 532 18 52-16 | Cover Lens Husq. Laser LT           |
| 261     | 532 18 52-12 | Insert Grille                       |
| 265     | 532 18 57-04 | Seal RH Side Bagger                 |
| 266     | 532 18 57-03 | Seal LH Side Bagger                 |
| - -     | 532 00 54-79 | Plug, Button                        |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
DRIVE



# REPAIR PARTS

**TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
DRIVE**


| KEY NO. | PART NO.     | DESCRIPTION                                                                     |
|---------|--------------|---------------------------------------------------------------------------------|
| 1       | -----        | Transaxle Hydro Gear 321-0510<br>(Order parts from transaxle manu-<br>facturer) |
| 8       | 532 16 56-19 | Rod, Shift Fender Adjust Lt                                                     |
| 9       | 532 18 02-20 | Clutch Ele                                                                      |
| 10      | 876 02 04-16 | Pin, Cotter 1/8 x 1                                                             |
| 14      | 810 04 04-00 | Washer, Lock Hvy Helical                                                        |
| 16      | 873 80 05-00 | Nut, Lock Hex w/Ins 5/16-18 UNC                                                 |
| 17      | 532 12 61-97 | Washer 1-1/2 OD x 15 x 32 ID x<br>.250                                          |
| 20      | 871 17 07-64 | Bolt, Hex 7/16-20 x 4 Ga 5 Gr                                                   |
| 21      | 532 12 12-74 | Knob Duckhead 1/4-13 Unc Blk                                                    |
| 22      | 532 17 56-07 | Rod, Brake                                                                      |
| 24      | 873 35 06-00 | Nut                                                                             |
| 25      | 532 10 68-88 | Spring, Rod, Brake                                                              |
| 26      | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga.                                                   |
| 27      | 876 02 04-12 | Pin, Cotter 1/8 x 3/4                                                           |
| 28      | 532 17 57-65 | Rod, Parking Brake                                                              |
| 29      | 532 07 16-73 | Cap, Parking Brake                                                              |
| 30      | 532 16 95-92 | Bracket, Mfg. Transaxle                                                         |
| 34      | 532 17 55-78 | Shaft, Asm Pedal Foot CRD                                                       |
| 35      | 532 12 01-83 | Bearing, Nylon                                                                  |
| 36      | 819 21 16-16 | Washer 21/32 x 1 x 16 Ga.                                                       |
| 37      | 532 12 49-63 | Pin, Roll 3/16 x 1"                                                             |
| 38      | 532 16 59-36 | Pulley Flat Composite 3.06"                                                     |
| 39      | 874 76 06-44 | Bolt Fin Hex 3/8-16 Unc x 2-3/4                                                 |
| 40      | 532 12 49-65 | Spacer, Split 395 x 59 Bzp                                                      |
| 42      | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga.                                                   |
| 43      | 819 11 10-12 | Washer 11/32 x 5/8 x 12 Ga.                                                     |
| 47      | 532 12 77-83 | Pulley, Idler, V Groove Plasic                                                  |
| 48      | 532 15 44-07 | Bellcrank Clutch Grnd Drv                                                       |
| 49      | 532 12 32-05 | Retainer, Belt Style Spring                                                     |
| 50      | 872 11 06-12 | Bolt Carr. sh 3/8-16 x 1-1/2 Gr. 5                                              |
| 51      | 873 68 06-00 | Nut, Crownlock 3/8-16 UNC                                                       |
| 52      | 873 6805-00  | Nut Crownlock 5/16-18                                                           |
| 53      | 532 10 57-10 | Link, Clutch 7.66                                                               |
| 55      | 532 10 57-09 | Spring, Return, Clutch                                                          |
| 56      | 817 06 06-20 | Screw 3/8-16 x 1-1/4                                                            |
| 57      | 532 17 01-40 | V-Belt Kev 112" 0650 CRD                                                        |
| 62      | 532 12 35-33 | Cover, Pedal                                                                    |
| 63      | 532 18 03-97 | Pulley, Engine                                                                  |
| 65      | 810 04 07-00 | Washer                                                                          |
| 66      | 532 15 47-78 | Keeper, Belt Engine F-Proof                                                     |
| 71      | 532 16 91-83 | Strap, Torque, Lh                                                               |
| 73      | 532 16 91-82 | Strap, Torque, Rh                                                               |
| 74      | 532 13 70-57 | Spacer, Split                                                                   |
| 75      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.                                                   |
| 76      | 812 00 00-01 | Ring, E                                                                         |
| 77      | 532 12 35-83 | Key, Square                                                                     |
| 78      | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.                                                   |
| 81      | 532 17 00-06 | Asm, Shaft                                                                      |
| 82      | 532 16 57-11 | Spring, Torsion                                                                 |
| 83      | 819 17 12-16 | Washer 17/32 x 3/4 x 16 Ga.                                                     |
| 84      | 532 17 00-07 | Link, Transaxle                                                                 |

| KEY NO. | PART NO.     | DESCRIPTION                            |
|---------|--------------|----------------------------------------|
| 95      | 532 17 00-15 | Control Asm Bypass Hydro               |
| 96      | 532 12 47-88 | Spring, Retainer 1"                    |
| 116     | 872 14 06-08 | Bolt RDHD SQNK 3/8-16 x 1              |
| 120     | 873 90 06-00 | Nut Lock Flg. 3/8-16 Unc               |
| 145     | 874 49 05-44 | Bolt Hex FGHD 5/16-18 x Gr 5           |
| 150     | 532 16 58-50 | Bushing, Bellcrank Grnd Dr             |
| 151     | 819 13 32-10 | Washer 13/32 x 2 x 10 Ga.              |
| 156     | 532 16 60-02 | Washer Srrted 5/16ID x 1.125           |
| 158     | 532 16 55-89 | Bracket Shift Mount                    |
| 159     | 532 16 54-94 | Hub Tapered Flange Shift Lt            |
| 160     | 819 29 20-16 | Washer 29/32 x 1-1/4 x 16 Ga.          |
| 161     | 872 14 04-06 | Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5       |
| 162     | 873 68 04-00 | Nut Crownlock 1/4-20 Unc               |
| 163     | 874 78 04-16 | Bolt Hex Fin 1/4-20 Unc x 1 Gr 5       |
| 164     | 819 09 10-10 | Washer 5/8 x .281 x 10 Ga.             |
| 165     | 532 16 56-23 | Bracket Pivot Lever                    |
| 166     | 532 16 68-80 | Screw 5/16-18 x 5/8                    |
| 167     | 532 16 55-88 | Bracket Support Shift CRD              |
| 168     | 532 16 54-92 | Bolt Shoulder 5/16-18 x .561           |
| 169     | 532 16 55-80 | Plate Fastening Lt                     |
| 171     | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2 Ty-Tt        |
| 172     | 532 17 02-71 | Shaft Asm Shifter Frt CRD              |
| 177     | 532 16 59-32 | Keeper Flat Idler 3.06" CRD            |
| 178     | 532 16 59-33 | Keeper Belt Idler 1.88" CRD            |
| 179     | 532 12 09-58 | Washer Sintered                        |
| 180     | 532 16 56-30 | Pulley, Idler, Flat 1.88"CRD           |
| 181     | 532 18 02-11 | Bracket Idler Ground Drive CRD         |
| 182     | 532 18 26-82 | Keeper Belt 2.5" Od V-Idler CRD        |
| 183     | 532 17 90-50 | Pulley V-Idler 2.50" Od CRD            |
| 184     | 817 49 06-44 | Screw Hexwsh Thdrol 3/8-16 x 2-<br>3/4 |
| 185     | 532 17 00-08 | Link Shift                             |
| 186     | 532 16 56-14 | Hub Tapered Round CRD                  |
| 187     | 817 58 05-20 | Screw Thdrol 5/16-18 x 1.25            |
| 197     | 532 16 96-13 | Nyliner Snap-In 5/8                    |
| 199     | 532 16 96-12 | Bolt Shoulder 5/16-18 Unc              |
| 200     | 872 14 05-08 | Bolt RDHD SQNK 5/16-18 x 1             |
| 202     | 872 11 06-14 | Bolt Carr. Sh. 3/8-16 x 1-3/4 Gr. 5    |
| 207     | 532 16 98-45 | Washer Nylon Rear                      |
| 212     | 532 14 52-12 | Nut Hex Flange Lock                    |
| 214     | 532 17 56-09 | Shaft Asm. Brake                       |
| 215     | 532 17 56-52 | Rod Brake Hydro                        |
| 243     | 532 17 82-89 | Bracket Anti-Rotation                  |
| 250     | 817 06 06-12 | Screw 3/8-16 x .75                     |
| 255     | 532 17 56-08 | Brace Shaft Brake Mtg.                 |
| 258     | 532 17 80-62 | Clip Retainer                          |
| 259     | 532 18 02-12 | Bracket Pulley Idler Hyd               |
| 260     | 532 18 17-81 | Bracket Idler Chassis                  |
| 261     | 532 13 14-94 | Pulley Idler Flat                      |
| 263     | 817 00 06-12 | Screw Hexwsh Thdr.<br>3/8-16 x 3/4 Blk |
| 269     | 532 18 24-02 | Muffler Guard OHV B&S RH               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
STEERING ASSEMBLY



# REPAIR PARTS


TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
STEERING ASSEMBLY

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                       |
|------------|--------------|-----------------------------------|
| 1          | 532 16 66-27 | Steering Wheel                    |
| 2          | 532 17 23-93 | Front Axle Assembly               |
| 3          | 532 16 98-40 | Spindle Assembly, L.H.            |
| 4          | 532 16 98-39 | Spindle Assembly, R.H.            |
| 5          | 532 12 49-31 | Bearing, Race, Thrust, Hardened   |
| 6          | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Gauge   |
| 8          | 812 00 00-29 | Ring, Klip                        |
| 10         | 532 17 51-21 | Link, Drag                        |
| 11         | 810 04 06-00 | Washer, Lock                      |
| 12         | 873 94 08-00 | Nut Hex Jam Toplock 1/2-20 UNF    |
| 13         | 532 13 65-18 | Spacer Axle                       |
| 15         | 532 14 52-12 | Nut Hex Flange Lock               |
| 17         | 532 18 06-41 | Shaft Assembly, Steering          |
| 29         | 817 06 06-12 | Screw 3/8-16 x 3/4                |
| 32         | 532 17 18-88 | Rod, Tie                          |
| 33         | 819 11 12-16 | Washer 11/32 x 3/4 x 16 Ga.       |
| 34         | 810 04 05-00 | Washer Lock Hvy Hlcl Spr 5/16     |
| 35         | 873 54 05-00 | Crownlock Nut 5/16-24 Unf         |
| 36         | 532 15 50-99 | Bushing, Steering                 |
| 37         | 532 15 29-27 | Screw TT #10-32 x 5 x 3/8 Flange  |
| 38         | 532 16 66-26 | Cap Wheel Steer                   |
| 39         | 819 18 24-11 | Washer 9/16 ID x 1-1/2 OD 11 Ga.  |
| 40         | 532 12 47-01 | Nut Lock Center 3/8-24 Unf        |
| 41         | 532 15 99-45 | Adaptor, Steering Wheel           |
| 42         | 532 16 96-34 | Boot, Steering Dash P/L Mtl       |
| 43         | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Gauge   |
| 44         | 532 18 06-40 | Extension Steering                |
| 46         | 532 12 12-32 | Cap, Spindle                      |
| 51         | 873 54 04-00 | Nut Crownlock 1/4-28              |
| 54         | 871 13 04-20 | Bolt Hex 1/4-28 UNF x 1-1/4 Gr. 8 |
| 65         | 532 16 03-67 | Spacer Axle                       |
| 67         | 872 14 06-18 | Bolt Rdhd Sq 3/8-16 x 2-1/4       |
| 68         | 532 16 98-27 | Brace Axle                        |
| 71         | 532 17 51-46 | Steering Asm.                     |
| 82         | 532 16 98-35 | Bracket Susp. Chassis Front       |
| 87         | 532 17 39-66 | Washer Flat .781 x 1-1/2 x .14    |
| 88         | 532 17 51-18 | Bolt Shoulder 7/16-20 Unc         |
| 91         | 532 17 55-53 | Clip Steering                     |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
SEAT ASSEMBLY




| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 18 49-95 | Seat                           |
| 2       | 532 14 05-51 | Bracket Pnt Pivot Seat (blk )  |
| 3       | 871 11 06-16 | Bolt Fin Hex 3/8-16 x 1        |
| 4       | 819 13 16-10 | Washer Flat 13/32 x 1 x 10 Ga. |
| 5       | 532 14 50-06 | Clip Push In Hinged            |
| 6       | 873 80 06-00 | Nut Lock Hex W/Ins 3/8-16      |
| 7       | 532 12 41-81 | Spring Seat Cprsn 2 250 Blk Zi |
| 8       | 817 00 06-16 | Screw 3/8-16 X 1.5             |
| 9       | 819 13 16-14 | Washer 13/32 X 1 X 14 Ga       |
| 10      | 532 18 24-93 | Pan Pnt Seat (blk )            |
| 11      | 532 16 63-69 | Knob Seat Adj. Wingnut         |
| 12      | 532 12 12-46 | Bracket Pnt Mounting Switch    |

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 13      | 532 12 12-48 | Bushing Snap Blk Nyl 50 Id     |
| 14      | 872 05 04-12 | Bolt Rdhd Sht Nk 1/4-20x1-1/2  |
| 15      | 532 12 12-49 | Spacer Split                   |
| 16      | 532 12 37-40 | Spring Cprsn                   |
| 17      | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr 5 Zinc |
| 21      | 532 17 18-52 | Bolt Shoulder 5/16-18 Unc-2A   |
| 22      | 873 80 05-00 | Nut Hex Lock w/Ins 5/16-18     |
| 24      | 819 17 19-12 | Washer 17/32 X 1-3/16 X 12 Ga. |
| 25      | 532 12 70-18 | Bolt Shoulder 5/16-18 X 62     |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm

# REPAIR PARTS


TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
DECALS



| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 1       | 532 14 54-98 | Decal Read Owner's Manual Sym |
| 2       | 532 18 04-34 | Decal Hp Engine               |
| 3       | 532 18 48-35 | Decal Hood Rh                 |
| 4       | 532 18 48-36 | Decal Hood Lh                 |
| 5       | 532 17 05-64 | Decal Wheel Steering          |
| 6       | 532 18 04-32 | Decal 100 DBA/CE              |
| 7       | 532 15 97-13 | Decal Panel Side B&S Logo     |
| 9       | 532 15 06-17 | Decal Fender Logo             |
| 10      | 532 14 50-05 | Decal Bat Dan/Poi P/L Sym Wpn |
| 11      | 532 18 21-66 | Decal Mower Cut Finger Symbol |
| 12      | 532 15 97-37 | Decal Brake/Clutch Symbol Lt  |

| KEY NO. | PART NO.     | DESCRIPTION                |
|---------|--------------|----------------------------|
| 14      | 532 15 97-36 | Decal Chassis Hot Muffler  |
| 16      | 532 18 04-35 | Decal Backplate            |
| 17      | 532 14 08-37 | Decal Saddle Brake Parking |
| 20      | 532 16 69-60 | Decal Bypass Fender CRD    |
| 21      | 532 16 62-86 | Decal Hex Belt Sch 92 CRD  |
| —       | 532 18 26-21 | Decal Bagger               |
| —       | 532 13 83-11 | Decal Lift Handle          |
| —       | 532 18 10-90 | Pad Footrest RH            |
| —       | 532 18 10-91 | Pad Footrest LH            |
| —       | 532 18 30-70 | Manual Operator's (Euro)   |
| —       | 532 18 30-71 | Manual Operator's (Scan)   |

## WHEELS & TIRES




| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 05 91-92 | Cap Value Tire                 |
| 2       | 532 06 51-39 | Stem Value                     |
| 3       | 532 10 62-22 | Tire F Ts 15 X 6 0 - 6 Service |
| 4       | 532 05 99-04 | Tube Inner Front #35060        |
| 5       | 532 13 83-36 | Rim Asm 6"front Silver Service |
| 6       | 532 12 49-57 | Fitting Grease                 |
| 7       | 532 12 49-59 | Bearing Flange                 |
| 8       | 532 13 83-37 | Rim Asm 8"rear Silver Service  |
| 9       | 532 13 84-68 | Tire R Ts 20 x 8-8 Service     |
| 10      | 532 12 49-26 | Tube Rear 9 5 X 8 Service      |
| 11      | 532 17 50-39 | Cap Axle Blk 1 50 X 1 00       |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. tube)    |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
ENGINE



# REPAIR PARTS


TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
ENGINE

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                                                       |
|------------|--------------|-------------------------------------------------------------------|
| 1          | 532 17 05-51 | Control Throt/Ck                                                  |
| 2          | 817 72 04-08 | Screw Hex Thd Cut 1/4-20 x 1/2                                    |
| 3          | -----        | Engine B&S Model 31G777<br>(Order parts from engine manufacturer) |
| 4          | 532 13 73-52 | Muffler                                                           |
| 13         | 532 16 52-91 | Gasket Muffler                                                    |
| 14         | 532 14 84-56 | Tube Drain Oil Easy                                               |
| 16         | 811 05 06-00 | Washer Lock Ext Tooth 3/8                                         |
| 23         | 532 16 98-37 | Shield Brn/Dbr Guard                                              |
| 25         | 532 18 09-45 | Control Choke                                                     |
| 26         | 873 92 06-00 | Nut Keps 3/8-24 Unf                                               |
| 29         | 532 13 71-80 | Kit Spark Arrestor (Flat Scrn)                                    |
| 31         | 532 18 06-45 | Tank Fuel 2.00                                                    |
| 32         | 532 14 05-27 | Cap Asm Fuel W/sym Vented                                         |
| 33         | 532 12 34-87 | Clamp Hose Blk                                                    |
| 37         | 532 13 70-40 | Line Fuel                                                         |
| 38         | 532 18 16-54 | Plug Drain Oil Easy                                               |
| 40         | 532 12 40-28 | Bushing Snap                                                      |
| 41         | 532 13 92-77 | Stem Fuel Line                                                    |
| 44         | 817 67 04-12 | Screw Hexwsh thdrol 1/4-20 x 3/4                                  |
| 45         | 817 00 06-12 | Screw Hexwsh Thdr 3/8-16 x 3/4                                    |
| 46         | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.                                        |
| 62         | 810 04 05-00 | Washer, Lock Hvy. Hlcl Spr 5/16                                   |
| 72         | 871 07 05-12 | Screw Hex Hd Cap 5/16-18 x 3/4                                    |
| 78         | 817 06 06-20 | Screw 3/8-16 x 1/4                                                |
| 81         | 873 51 04-00 | Nut Keps Hex 1/4-20 Unc                                           |
| 112        | 532 12 49-52 | Bushing                                                           |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
MOWER LIFT



# REPAIR PARTS


TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
MOWER LIFT

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                           |
|------------|--------------|---------------------------------------|
| 1          | 532 15 94-60 | Washer Asm Inner Spring W/<br>Plunger |
| 2          | 532 15 94-71 | Shaft Asm. Lift                       |
| 3          | 532 10 57-67 | Pin Groove                            |
| 4          | 812 00 00-02 | E Ring #5133-62                       |
| 5          | 819 21 16-21 | Washer 21/32 x 1 x 21 Ga.             |
| 6          | 532 12 01-83 | Bearing Nylon                         |
| 7          | 532 12 56-31 | Grip Handle Fluted                    |
| 8          | 532 12 45-26 | Button Plunger Black                  |
| 11         | 532 16 58-29 | Link Asm Lift L.H.                    |
| 12         | 532 16 58-31 | Link Asm Lift R.H.                    |
| 13         | 532 12 46-70 | Retainer Spring                       |
| 15         | 532 17 32-88 | Link Front                            |
| 16         | 873 35 08-00 | Nut Jam Hex 1/2-13 Unc                |
| 17         | 532 17 56-89 | Trunnion Blk Zinc                     |
| 18         | 873 80 08-00 | Nut Lock w/wsh 1/2-13 Unc             |
| 19         | 532 13 98-68 | Arm Suspension Mower                  |
| 20         | 532 16 35-52 | Retainer Spring                       |
| 23         | 532 11 08-07 | Nut Special                           |
| 24         | 819 13 10-16 | Washer 13/32 x 5/8 x 16 Ga.           |
| 25         | 532 12 48-74 | Spring 2-1/8"                         |
| 26         | 532 16 94-84 | Retainer Clip                         |
| 27         | 532 12 69-71 | Rod Adj Lift Zinc 7.49 Wrk Lg         |
| 28         | 873 35 06-00 | Nut Hex Jam 3/8-16 Unc                |
| 29         | 532 13 80-57 | Knob Inf 3/8-16 Unc Blk w/sym         |
| 30         | 532 15 02-33 | Trunnion Infin Height                 |
| 31         | 532 16 98-65 | Bearing, Pvt. Lift.                   |
| 32         | 873 54 06-00 | Nut Crownlock 3/8-24                  |
| 36         | 532 15 50-97 | Pointer Height Indicator              |
| 37         | 532 12 39-35 | Plug Hole Blk 1.485/1.515 Dia         |
| 38         | 817 06 05-16 | Screw 5/16-18 x 1                     |
| 40         | 819 11 24-10 | Washer 11/32 x 1-1/2 x 10 Ga.         |
| 41         | 532 12 39-34 | Scale Ind Height Blk                  |
| 49         | 532 14 52-12 | Nut hex Flange Lock                   |
| 50         | 532 11 04-52 | Nut Push Phos & Oil                   |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
MOWER



# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
MOWER


| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 16 55-52 | Housing Asm. Mower                |
| 2       | 872 14 05-06 | Bolt Rdhd Sqnk 5/16-18 Unc x 3/4  |
| 3       | 532 16 55-69 | Bracket Asm. S-Bar Chass          |
| 4       | 532 16 55-58 | Bracket Bar Sway Deck             |
| 5       | 532 12 46-70 | Retainer Spring                   |
| 6       | 532 16 55-57 | Bar Sway                          |
| 8       | 532 18 17-12 | Bolt 3/8-24 x 1.25 Gr8 Patched    |
| 9       | 810 03 06-00 | Washer Lock Hvy 3/8 Unplated      |
| 11      | 532 17 00-37 | Blade 3-1 Lh                      |
| 13      | 532 13 76-45 | Shaft Asm. W/Lower Bearing        |
| 14      | 532 12 87-74 | Housing Mandrel Vented (Machd)    |
| 15      | 532 11 04-85 | Bearing Ball Mandrel              |
| 16      | 532 17 00-38 | Blade 3-1 Rh                      |
| 17      | 872 14 06-10 | Bolt Carriage 3/8-16 x 1-1/4      |
| 18      | 872 11 06-06 | Bolt Rdhd Sqnk 3/8-16 x 3/4       |
| 19      | 532 13 28-27 | Bolt Shoulder 5/16-18 Thd Form    |
| 20      | 532 18 17-13 | Bolt 3/8-24 x 1.25 Gr8 Ptch Lhthd |
| 21      | 873 68 05-00 | Nut Crown Lock 5/16-18            |
| 22      | 532 16 52-43 | Bracket Idler Sprt RR             |
| 23      | 532 16 54-46 | Bracket Idler Sprt RF             |
| 24      | 532 16 52-42 | Bracket Suspension LF             |
| 25      | 532 16 52-44 | Bracket Suspension RF             |
| 26      | 532 16 52-37 | Brace Support Susp Frt            |
| 27      | 532 16 55-68 | Bracket Asm. Susp RR              |
| 28      | 532 16 55-67 | Bracket Asm. Susp LR              |
| 30      | 532 17 39-84 | Screw Thd Rolling                 |
| 31      | 532 12 99-63 | Washer Spacer Mower Vented        |
| 32      | 532 15 35-31 | Mandrel Pulleys                   |
| 33      | 532 17 83-42 | Nut Flg Top Lock                  |
| 34      | 532 16 52-39 | Bracket Gauge Wheel Lf            |

| KEY NO. | PART NO.            | DESCRIPTION                       |
|---------|---------------------|-----------------------------------|
| 35      | 532 16 52-38        | Bracket Gauge Wheel Rf            |
| 36      | 532 14 67-63        | Pulley Idler V-Groove Dim 4.25    |
| 37      | 819 13 13-16        | Washer 11/32 x 13/16 x 16 Ga      |
| 40      | 873 68 06-00        | Nut Crownlock 3/8-16 Unc          |
| 44      | 532 17 55-38        | Cover Mandrel Lh                  |
| 45      | 532 17 55-39        | Cover Mandrel Rh                  |
| 46      | 532 13 77-29        | Screw Thd Roll 1/4-20 x 5/8       |
| 55      | 532 16 54-45        | Arm Idler                         |
| 56      | 532 16 57-23        | Spacer Retainer Mower             |
| 61      | 532 16 59-45        | Spring Tension Belt               |
| 68      | 532 18 02-17        | Hex-Belt                          |
| 69      | 532 16 54-82        | Shaft Asm W/Lwr Brg Rh Thd CRD    |
| 84      | 532 15 60-85        | Keeper Belt Idler                 |
| 116     | 532 18 42-19        | Bolt Shoulder                     |
| 117     | 532 13 39-57        | Wheel Gage Donut Wide             |
| 118     | 873 93 06-00        | Nut Centerlock 3/8-16 Unc         |
| 119     | 819 12 14-14        | Washer 3/8 x 7/8 x 14 Ga.         |
| 124     | 872 11 06-12        | Bolt Carr Sh 3/8-16 x 1-1/2 Gr5   |
| 130     | 872 11 05-06        | Bolt Rdhdsqnk 5/16-18 Unc x 3/4   |
| 131     | 532 16 56-61        | Chute Bagger CRD 92cm             |
| 161     | 532 18 04-18        | Blade Cross LH 92                 |
| 162     | <b>532 18 60-13</b> | Adapter Blade Cross               |
| 163     | 532 18 04-19        | Blade Cross RH 92                 |
| --      | 532 18 18-57        | Mandrel Asm Service               |
| --      | 532 18 18-58        | Mandrel Asm CRD Lh Threads<br>SVC |
| --      | 532 18 17-65        | Replacement Mower, Complete       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH155 (HECTH155D), PRODUCT NO. 954 17 00-84  
BAGGER



| KEY NO. | PART NO.     | DESCRIPTION                           |
|---------|--------------|---------------------------------------|
| 1       | 532 16 52-49 | Tube Handle Bagger CRD                |
| 2       | 872 14 04-16 | Bolt Carriage 1/4-20 x 2.0 Gr.5       |
| 3       | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr. 5 Zinc       |
| 4       | 532 16 99-16 | Handle Bagger w/Lvrs Blk CRD          |
| 5       | 874 98 10-24 | Screw Pan Head #10-24 x 1.50 Blk      |
| 6       | 874 98 10-32 | Screw Pan Hd                          |
| 7       | 873 40 10-00 | Nut Wiz Lock Hex Serr/Hd 10-24        |
| 8       | 532 18 10-95 | Cover Bagger                          |
| 9       | 872 14 04-18 | Bolt Carriage 1/4-20 x 2.25d x Gr.5   |
| 10      | 532 18 12-82 | Tube Support Bagger CRD               |
| 11      | 532 16 57-19 | Bracket Support Upper Bag CRD         |
| 12      | 532 16 96-85 | Bracket Horiz Adj Bagger Lh           |
| 13      | 872 11 06-06 | Bolt Rdhd Sht Sqnk 3/8-16 x 3/4       |
| 14      | 874 52 06-36 | Bolt Fin Hex 3/8-16 x 2-1/4 Gr.5      |
| 15      | 532 12 46-70 | Retainer Spring                       |
| 16      | 873 90 06-00 | Nut Lock Flg 3/8-16 Unc               |
| 17      | 872 14 05-06 | Bolt Rdhd Sht Sqnk 5/16 -18 Unc x 3/4 |
| 18      | 819 11 12-16 | Washer 11/32 x 3/4 x 16 Ga.           |
| 19      | 873 90 05-00 | Nut Lock Hex Flange 5/16-18           |
| 20      | 532 16 96-84 | Bracket Horiz Adj Bagger Rh           |
| 21      | 532 18 08-80 | Bag Asm CRD                           |

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 22      | 532 16 57-81 | Bracket Side Bagger CRD        |
| 23      | 532 16 57-82 | Tube Upper Bagger CRD          |
| 24      | 532 16 57-83 | Tube Pivot Bagger CRD          |
| 25      | 532 18 01-24 | Tube Front Bagger CRD          |
| 26      | 532 16 57-85 | Tube Lower Bagger CRD          |
| 28      | 532 16 57-87 | Grip Handle Black              |
| 31      | 532 12 47-88 | Retainer Spring 1" Zinc/Cad    |
| 32      | 532 12 68-75 | Rivet Rd Hd Drilled 3/8 Dia    |
| 33      | 532 16 55-71 | Plug Mulcher                   |
| 34      | 532 16 55-70 | Handle Mulcher                 |
| 35      | 532 16 55-72 | Pin Mulcher                    |
| 36      | 819 13 20-16 | Washer 13/32 x 1-1/4 x 16 Ga.  |
| 37      | 532 17 54-01 | Plug Support Bagger CRD        |
| 38      | 872 01 05-20 | Bolt 5/16-18 x 2-1/2           |
| 39      | 532 18 09-85 | Seal Trim                      |
| 41      | 532 16 96-83 | Bracket Pnt Adj Pvt Bagger CRD |
| 42      | 873 80 05-00 | Nut Crownlock 5/16-18 Blk D    |
| 43      | 532 17 40-83 | Plug Tube End                  |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm