

# CTH191

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**


**GPL®**

# ILLUSTRATED PARTS LIST

**MFG. ID NO. 96061007701**


**CUSTOMER CATALOG NO. CTH191**

**PRODUCT NO. 960 61 00-77**



# REPAIR PARTS


TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
DECALS



| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 1       | 532 40 03-89 | Decal Warning Symbols CE      |
| 2       | 532 19 38-24 | Decal Sidepnl                 |
| 3       | 532 18 89-23 | Decal Hood                    |
| 4       | 532 18 91-49 | Decal Replacement             |
| 5       | 532 18 89-25 | Decal Wheel Steering          |
| 6       | 532 18 04-32 | Decal 100 DBA                 |
| 7       | 532 18 89-21 | Decal Hood                    |
| 8       | 532 19 68-41 | Decal Warning Eng. Sym        |
| 9       | 532 19 38-23 | Decal Fender Logo             |
| 10      | 532 14 50-05 | Decal Bat Dan/Poi P/L Sym Wpn |
| 11      | 532 18 21-66 | Decal Mower Cut Finger Symbol |
| 12      | 532 15 97-37 | Decal Brake/Clutch Symbol Lt  |

| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 13      | 532 40 11-46 | Decal Warning Service/Fire   |
| 14      | 532 15 97-36 | Decal Chassis Hot Muffler    |
| 15      | 532 19-68-42 | Defal Warning Cut Finger     |
| 17      | 532 14 08-37 | Decal Saddle Brake Parking   |
| 20      | 532 16 69-60 | Decal Bypass Fender CRD      |
| 21      | 532 16 62-86 | Decal Hex Belt Sch 92 CRD    |
| --      | 532 18 04-32 | Decal Rear Plate CRD Symbols |
| --      | 532 13 83-11 | Decal Lift Handle            |
| --      | 532 18 10-90 | Pad Footrest RH              |
| --      | 532 18 10-91 | Pad Footrest LH              |
| --      | 532 40 09-65 | Manual Operator's (Euro)     |

## WHEELS & TIRES




| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 1       | 532 05 91-92 | Cap Value Tire                  |
| 2       | 532 06 51-39 | Stem Value                      |
| 3       | 532 10 62-22 | Tire F Ts 15 x 6 0 - 6 Service  |
| 4       | 532 05 99-04 | Tube Inner Front #35060         |
| 5       | 532 13 83-36 | Rim Asm 6" front Silver Service |
| 6       | 532 12 49-57 | Fitting Grease                  |
| 7       | 532 12 49-59 | Bearing Flange                  |
| 8       | 532 13 83-37 | Rim Asm 8" rear Silver Service  |
| 9       | 532 12 20-82 | Tire R Ts 20 x 10-8 Service     |
| 10      | 532 12 49-26 | Tube Rear 9 5 x 8 Service       |
| 11      | 532 17 50-39 | Cap Axle Blk 1 50 x 1 00        |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. tube)     |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77


SCHEMATIC

03050\_197436 (WITH LIGHTS)



# REPAIR PARTS

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
ELECTRICAL



# REPAIR PARTS


TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
ELECTRICAL

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                       |
|------------|--------------|-----------------------------------|
| 1          | 532 14 49-27 | Battery                           |
| 2          | 874 76 04-12 | Bolt Hex Hd 1/4-20 unc x 3/4      |
| 16         | 532 17 61-38 | Switch Interlock                  |
| 21         | 532 17 56-88 | Harness Asm Light W/4152J         |
| 22         | 532 00 41-52 | Bulb Light #1156                  |
| 24         | 532 12 47-80 | Cable Starter 6 Ga. 11" Red       |
| 25         | 532 16 59-87 | Cable Battery Crd 56" Red         |
| 26         | 532 17 51-58 | Fuse                              |
| 27         | 873 51 04-00 | Nut Keps Hex 1/4-20 unc           |
| 28         | 532 12 77-25 | Cable Ground 6 Ga. 18" Black      |
| 29         | 532 19 27-49 | Switch Seat                       |
| 30         | 532 19 33-50 | Switch Ignition                   |
| 33         | 532 14 04-01 | Key Ignition                      |
| 34         | 532 11 07-12 | Switch Light                      |
| 40         | 532 19 74-36 | Harness Ignition                  |
| 41         | 871 11 04-08 | Bolt Flk Fin Hex 1/4-20 unc x 1/2 |
| 42         | 532 13 15-63 | Cover Terminal Red                |
| 43         | 532 19 25-07 | Solenoid                          |
| 48         | 532 14 08-44 | Adapter Ammeter Rectangular       |
| 58         | 532 16 94-19 | Buzzer Crd                        |
| 59         | 532 18 03-79 | Switch FBI CRD                    |
| 66         | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2 Ty-Tt   |
| 81         | 532 10 97-48 | Relay Asm                         |
| 92         | 532 19 66-15 | Harness Pigtail                   |
| 93         | 532 19 25-40 | Screw Plastite 10-44 x 2.0        |
| 94         | 532 19 18-34 | Module Reverse                    |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
CHASSIS AND ENCLOSURES



# REPAIR PARTS


## TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77 CHASSIS AND ENCLOSURES

| KEY NO. | PART NO.     | DESCRIPTION                                          | KEY NO. | PART NO.     | DESCRIPTION                            |
|---------|--------------|------------------------------------------------------|---------|--------------|----------------------------------------|
| 1       | 532 17 46-20 | Chassis                                              | 165     | 532 18 11-00 | Cover Battery                          |
| 2       | 532 18 03-84 | Drawbar                                              | 170     | 532 19 94-88 | Backplate CRD                          |
| 3       | 817 06 06-12 | Screw 3/8-16 x 3/4                                   | 171     | 872 14 06-20 | Bolt Rdhd Sqnk<br>3/8-16 x 2-1/2 Gr. 5 |
| 5       | 532 15 52-72 | Bumper Hood/Dash                                     | 172     | 819 13 20-16 | Washer 13/32 x 1-1/4 x 16 Ga.          |
| 6       | 532 18 44-19 | Saddle                                               | 173     | 873 51 06-00 | Nut, Keps Hex 3/8-16 unc               |
| 8       | 532 12 64-71 | Clip Insulator 13/32 Mtg. Hole                       | 175     | 532 18 82-03 | Guard Trap                             |
| 9       | 532 19 42-89 | Dash                                                 | 179     | 532 18 82-02 | Rod Pivot FBI CRD                      |
| 10      | 872 14 06-08 | Bolt, Carriage 3/8-16 x 3/4                          | 184     | 532 17 46-62 | Bracket Actuator Bagger CRD            |
| 11      | 532 17 49-96 | Panel, Dash, L.H.                                    | 185     | 532 18 11-01 | Knob Rod Brake Parking                 |
| 13      | 532 17 21-06 | Panel, Asm. Dash R.H.                                | 186     | 532 16 07-93 | Latch Asm Mulch/Bagger                 |
| 15      | 874 18 05-12 | Screw, Machine, Truss Head<br>5/16-18 unc x 3/4      | 187     | 532 12 50-04 | Nut Weld                               |
| 16      | 873 51 05-00 | Nut                                                  | 188     | 819 06 12-16 | Washer #10                             |
| 17      | 532 18 88-93 | Hood                                                 | 189     | 810 07 10-00 | Washer Lock #10                        |
| 18      | 532 18 49-21 | Bumper Hood                                          | 190     | 871 08 10-10 | Screw Pan Hd Phillip 10-24 x 5/8       |
| 24      | 874 78 06-16 | Bolt                                                 | 198     | 532 16 89-37 | Nut, Push                              |
| 25      | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga.                        | 205     | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2              |
| 26      | 873 80 06-00 | Nut                                                  | 207     | 817 67 05-08 | Screw Thdrol 5/16-18 x 1/2             |
| 28      | 532 18 35-38 | Grille /Lens Asm (Includes Key<br>Nos. 212, 258-261) | 208     | 817 67 06-08 | Screw Thdrol 3/8-16 x 1/2              |
| 30      | 532 19 73-76 | Fender                                               | 209     | 817 00 06-12 | Screw Hex Wsh Thdrol 3/8-16            |
| 31      | 532 16 51-56 | Bracket, Fender Support                              | 212     | 532 18 35-48 | Insert Lens Reflect                    |
| 33      | 532 18 10-57 | Footrest, L.H.                                       | 256     | 532 18 13-61 | Cover Fender Rack                      |
| 34      | 532 18 10-58 | Footrest, R.H.                                       | 258     | 532 18 52-13 | Lens RH                                |
| 35      | 872 11 06-06 | Bolt                                                 | 259     | 532 18 52-14 | Lens LH                                |
| 37      | 817 49 05-08 | Screw Thdrol 5/16-18 x 1/2 TYT                       | 260     | 532 18 52-16 | Cover Lens                             |
| 38      | 532 18 17-48 | Bracket Asm Pivot Mower Rear                         | 261     | 532 18 52-12 | Insert Grille                          |
| 39      | 532 17 47-14 | Bracket Pivot                                        | 265     | 532 18 57-04 | Seal RH Side Bagger                    |
| 58      | 532 18 71-54 | Duct Air                                             | 266     | 532 18 57-03 | Seal LH Side Bagger                    |
| 69      | 532 14 24-32 | Screw Hx Wsh Hi-Lo 1/4-1/2                           | 272     | 532 18 88-95 | Vent Hood LH                           |
| 89      | 532 19 73-77 | Console Crd Auto Grey                                | 273     | 532 18 88-96 | Vent Hood RH                           |
| 145     | 532 15 65-24 | Rod Pivot Chassis/Hood                               | 278     | 532 19 16-11 | Screw 10 x 3/4 Single Lead-Hex         |
| 162     | 532 18 03-82 | Bracket Exten Chassis Lh CRD                         | --      | 532 18 78-01 | Plug Dome Plastic                      |
| 163     | 532 18 03-83 | Bracket Exten Chassis Rh CRD                         |         |              |                                        |
| 164     | 532 16 56-05 | Support Battery CRD                                  |         |              |                                        |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
DRIVE



drive-hydro\_CRD\_Laser\_18

# REPAIR PARTS


**TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
DRIVE**

| KEY NO. | PART NO.            | DESCRIPTION                                                                     | KEY NO. | PART NO.            | DESCRIPTION                      |
|---------|---------------------|---------------------------------------------------------------------------------|---------|---------------------|----------------------------------|
| 1       | -----               | Transaxle Hydro Gear 321-0510<br>(Order parts from transaxle manu-<br>facturer) | 96      | 532 12 47-88        | Spring, Retainer 1"              |
| 8       | 532 19 27-06        | Rod, Shift Fender Adjust Lt                                                     | 112     | 819 09 12-10        | Washer 9/32 x 3/4 x 10 Ga.       |
| 9       | <b>532 18 03-54</b> | Clutch Asm Noram                                                                | 120     | 873 90 06-00        | Nut Lock Flg. 3/8-16 unc         |
| 10      | 876 02 04-16        | Pin, Cotter 1/8 x 1                                                             | 150     | 532 16 58-50        | Bushing, Bellcrank Grnd Dr       |
| 14      | 810 04 04-00        | Washer, Lock Hvy Helical                                                        | 151     | 819 13 32-10        | Washer 13/32 x 2 x 10 Ga.        |
| 15      | 874 49 05-44        | Bolt Hex FGHD 5/16-18 x Gr 5                                                    | 156     | 532 16 60-02        | Washer Srrted 5/16 ID x 1.125    |
| 16      | 873 80 05-00        | Nut Lock Hex W/Ins 5/16-18 unc                                                  | 158     | 532 16 55-89        | Bracket Shift Mount              |
| 19      | 873 80 06-00        | Nut Lock Hex w/Ins 3/8-16 unc                                                   | 159     | 532 18 39-00        | Hub Shift                        |
| 21      | 532 12 12-74        | Knob Duckhead 1/4-13 unc Blk                                                    | 161     | 872 14 04-06        | Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5 |
| 22      | 532 17 56-07        | Nut                                                                             | 162     | 873 68 04-00        | Nut Crownlock 1/4-20 unc         |
| 24      | 873 35 06-00        | Nut Hex Jam 3/8-16 unc                                                          | 163     | 874 78 04-16        | Bolt Hex Fin 1/4-20 unc x 1 Gr 5 |
| 25      | 532 19 20-36        | Spring, Rod, Brake                                                              | 165     | 532 16 56-23        | Bracket Pivot Lever              |
| 27      | 876 02 04-12        | Pin, Cotter 1/8 x 3/4                                                           | 166     | 817 49 05-10        | Screw 5/16-18 x 5/8              |
| 28      | 532 17 57-65        | Rod, Parking Brake                                                              | 167     | 532 16 55-88        | Bracket Support Shift CRD        |
| 29      | 532 07 16-73        | Cap, Parking Brake                                                              | 168     | 532 16 54-92        | Bolt Shoulder 5/16-18 x .561     |
| 30      | 532 16 95-92        | Bracket, Mfg. Transaxle                                                         | 169     | 532 16 55-80        | Plate Fastening Lt               |
| 34      | 532 17 55-78        | Shaft, Asm Pedal Foot CRD                                                       | 171     | 817 49 06-08        | Screw Thdrol 3/8-16 x 1/2 Ty-Tt  |
| 35      | 532 12 01-83        | Bearing, Nylon                                                                  | 172     | 532 17 02-71        | Shaft Asm Shifter Frt CRD        |
| 36      | 819 21 16-16        | Washer 21/32 x 1 x 16 Ga.                                                       | 177     | 532 16 59-32        | Keeper Flat Idler 3.06" CRD      |
| 37      | 532 12 49-63        | Pin, Roll 3/16 x 1"                                                             | 181     | 532 18 02-11        | Bracket Idler Ground Drive CRD   |
| 38      | 532 13 14-94        | Pulley Flat Composite 3.06"                                                     | 182     | 532 18 26-82        | Keeper Belt 2.5" Od V-Idler CRD  |
| 39      | 874 76 06-44        | Bolt Fin Hex 3/8-16 unc x 2-3/4                                                 | 183     | <b>532 19 95-32</b> | Pulley V-Idler                   |
| 40      | 532 12 49-65        | Spacer, Split 395 x 59 Bzp                                                      | 185     | 532 17 00-08        | Link Shift                       |
| 42      | 819 13 13-12        | Washer 13/32 x 13/16 x 12 Ga.                                                   | 186     | 532 16 56-14        | Hub Tapered Round CRD            |
| 43      | 819 11 10-12        | Washer 11/32 x 5/8 x 12 Ga.                                                     | 187     | 817 58 05-20        | Screw Thdrol 5/16-18 x 1.25      |
| 47      | 532 12 77-83        | Pulley, Idler, V Groove Plasic                                                  | 197     | 532 16 96-13        | Nyliner Snap-In 5/8              |
| 48      | 532 15 44-07        | Bellcrank Clutch Grnd Drv                                                       | 199     | 532 16 96-12        | Bolt Shoulder 5/16-18 unc        |
| 49      | 532 12 32-05        | Retainer, Belt Style Spring                                                     | 200     | 872 14 05-08        | Bolt RDHD SQNK 5/16-18 x 1       |
| 50      | 872 11 06-12        | Bolt Carr. Sh. 3/8-16 x 1-1/2 Gr. 5                                             | 203     | 871 17 07-80        | Bolt Hex 7/16-20 x 5             |
| 51      | 873 68 06-00        | Nut, Crownlock 3/8-16 unc                                                       | 207     | 532 16 98-45        | Washer Nylon Rear                |
| 52      | 873 68 05-00        | Nut Crownlock 5/16-18                                                           | 214     | 532 17 56-09        | Shaft Asm. Brake                 |
| 53      | 532 19 96-52        | Link, Clutch 7.66                                                               | 215     | 532 17 56-52        | Rod Brake Hydro                  |
| 55      | 532 10 57-09        | Spring, Return, Clutch                                                          | 252     | 819 13 16-16        | Washer 13/32 x 1 x 16 Ga.        |
| 56      | 817 06 06-20        | Screw 3/8-16 x 1-1/4                                                            | 253     | 532 17 50-28        | Bracket Cable Chassis            |
| 57      | 532 17 01-40        | V-Belt Kev 112" 0650 CRD                                                        | 254     | 817 00 06-16        | Screw 3/8-16 x 1                 |
| 62      | 532 12 35-33        | Cover, Pedal                                                                    | 255     | 532 17 56-08        | Brace Shaft Brake Mtg.           |
| 65      | 810 04 07-00        | Washer                                                                          | 258     | 532 17 80-62        | Clip Retainer                    |
| 66      | 532 15 47-78        | Keeper, Belt Engine F-Proof                                                     | 259     | 532 18 02-12        | Bracket Pulley                   |
| 71      | 532 16 91-83        | Strap, Torque, Lh                                                               | 261     | 532 13 14-94        | Pulley Idler                     |
| 73      | 532 16 91-82        | Strap, Torque, Rh                                                               | 262     | 872 11 06-22        | Bolt Carr. 3/8-16 x 2-3/4 Gr.5   |
| 74      | 532 13 70-57        | Spacer, Split                                                                   | 263     | 817 00 06-12        | Screw 3/8-16 x 3/4               |
| 75      | 532 12 17-49        | Washer 25/32 x 1-1/4 x 16 Ga.                                                   | 264     | 532 19 76-08        | Bracket Idler Chassis            |
| 76      | 812 00 00-01        | Ring, E                                                                         | 265     | 532 18 20-13        | Spacer Idler Chassis             |
| 77      | 532 12 35-83        | Key, Square                                                                     | 266     | 532 18 20-61        | Shield Idler Mower               |
| 78      | 532 12 17-48        | Washer 25/32 x 1-5/8 x 16 Ga.                                                   | 268     | 532 18 24-02        | Guard Muffler RH                 |
| 81      | 532 17 00-06        | Asm, Shaft,Cross Rear                                                           | 275     | 819 13 16-14        | Washer 13/32 x 1 x 14 Ga.        |
| 82      | 532 16 57-11        | Spring, Torsion                                                                 | 293     | 872 14 06-28        | Bolt 3/8-16 x 3-1/2              |
| 83      | 819 17 12-16        | Washer 17/32 x 3/4 x 16 Ga.                                                     | 294     | 532 19 70-33        | Nut 3/8-16                       |
| 84      | 532 17 00-07        | Link, Transaxle                                                                 | 295     | 532 17 91-14        | Pulley Idler Composite           |
| 95      | 532 17 00-15        | Control Asm Bypass Hydro                                                        |         |                     |                                  |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
STEERING ASSEMBLY



# REPAIR PARTS


TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
STEERING ASSEMBLY

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                         |
|------------|--------------|-------------------------------------|
| 1          | 532 19 36-51 | Steering Wheel                      |
| 2          | 532 18 47-06 | Front Axle Assembly                 |
| 3          | 532 16 98-40 | Spindle Assembly, L.H.              |
| 4          | 532 16 98-39 | Spindle Assembly, R.H.              |
| 5          | 532 12 49-31 | Bearing, Race, Thrust, Hardened     |
| 6          | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.       |
| 8          | 812 00 00-29 | Ring, Klip                          |
| 10         | 532 17 51-21 | Link, Drag                          |
| 11         | 810 04 06-00 | Washer, Lock                        |
| 13         | 532 13 65-18 | Spacer Axle                         |
| 15         | 532 14 52-12 | Nut Hex Flange Lock                 |
| 17         | 532 19 07-53 | Shaft Assembly, Steering            |
| 29         | 817 00 06-12 | Screw 3/8-16 x 3/4                  |
| 32         | 532 17 01-62 | Rod, Tie                            |
| 33         | 819 11 12-16 | Washer 11/32 x 3/4 x 16 Ga.         |
| 34         | 810 04 05-00 | Washer Lock Hvy Hlcl Spr 5/16       |
| 35         | 873 54 05-00 | Crownlock Nut 5/16-24 unf           |
| 36         | 532 15 50-99 | Bushing, Steering                   |
| 37         | 532 15 29-27 | Screw TT #10-32 x 5 x 3/8 Flange    |
| 38         | 532 19 36-52 | Cap Wheel Steering                  |
| 39         | 819 11 38-12 | Washer 11/32 ID x 2-3/8 OD x 12 Ga. |
| 40         | 873 54 06-00 | Nut Crownlock 3/8-24                |
| 41         | 532 18 67-37 | Adaptor, Steering Wheel             |
| 42         | 532 16 96-34 | Boot, Steering Dash P/L Mtl         |
| 43         | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.       |
| 44         | 532 19 07-52 | Extension Steering                  |
| 46         | 532 12 12-32 | Cap, Spindle                        |
| 65         | 532 16 03-67 | Spacer Axle                         |
| 67         | 872 11 06-18 | Bolt Rdhd Sq 3/8-16 x 2-1/4         |
| 68         | 532 16 98-27 | Brace Axle                          |
| 71         | 532 17 51-46 | Steering Asm.                       |
| 82         | 532 19 99-78 | Bracket Susp. Chassis Front         |
| 87         | 532 17 39-66 | Washer Flat .781 x 1-1/2 x .14      |
| 88         | 532 17 51-18 | Bolt Shoulder 7/16-20 unc           |
| 91         | 532 17 55-53 | Clip Steering                       |
| 95         | 532 18 89-67 | Washer                              |
| 97         | 874 78 05-64 | Bolt 5/16-18 unc x 4" L Gr. 5       |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
SEAT ASSEMBLY



seat\_lt.knob\_7(CRD)


| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 18 87-13 | Seat                           |
| 2       | 532 14 05-51 | Bracket Pnt Pivot Seat (blk )  |
| 3       | 871 11 06-16 | Bolt Fin Hex 3/8-16 x 1        |
| 4       | 819 13 16-10 | Washer Flat 13/32 x 1 x 10 Ga. |
| 5       | 532 14 50-06 | Clip Push In Hinged            |
| 6       | 873 80 06-00 | Nut Lock Hex W/Ins 3/8-16      |
| 7       | 532 12 41-81 | Spring Seat Cprsn 2 250 Blk Zi |
| 8       | 817 00 06-16 | Screw 3/8-16 x 1.5             |
| 9       | 819 13 16-14 | Washer 13/32 x 1 x 14 Ga       |
| 10      | 532 19 55-30 | Pan Pnt Seat                   |
| 11      | 532 16 63-69 | Knob Seat Adj. Wingnut         |
| 12      | 532 17 46-48 | Bracket Pnt Mounting Switch    |

| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 13      | 532 12 12-48 | Bushing Snap Blk Nyl 50 Id      |
| 14      | 872 05 04-12 | Bolt Rdhd Sht Nk 1/4-20 x 1-1/2 |
| 15      | 532 12 12-49 | Spacer Split                    |
| 16      | 532 12 37-40 | Spring Cprsn                    |
| 17      | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr. 5 Zinc |
| 21      | 532 17 18-52 | Bolt Shoulder 5/16-18 unc-2A    |
| 22      | 873 80 05-00 | Nut Hex Lock w/Ins 5/16-18      |
| 24      | 819 17 19-12 | Washer 17/32 x 1-3/16 x 12 Ga.  |
| 25      | 532 12 70-18 | Bolt Shoulder 5/16-18 x 62      |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
ENGINE



# REPAIR PARTS


TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
ENGINE

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                                                   |
|------------|--------------|---------------------------------------------------------------|
| 1          | 532 17 08-05 | Control Throt /Ch Flag                                        |
| 2          | 817 72 04-08 | Screw Hex Thd Cut 1/4-20 x 1/2                                |
| 3          | -----        | Engine Kohler SV590<br>(Order Parts from Engine Manufacturer) |
| 4          | 532 18 86-55 | Muffler                                                       |
| 8          | 532 17 18-77 | Bolt 5/16-18 x 3/4                                            |
| 13         | 532 18 59-09 | Gasket                                                        |
| 14         | 532 14 84-56 | Tube Drain Oil Easy                                           |
| 23         | 532 16 98-37 | Shield Browning/Debris Guard                                  |
| 29         | 532 13 71-80 | Arrestor Spark                                                |
| 31         | 532 18 55-34 | Tank Fuel                                                     |
| 32         | 532 19 77-25 | Cap Asm Fuel                                                  |
| 33         | 532 12 34-87 | Clamp Hose Blk                                                |
| 37         | 532 13 70-40 | Line Fuel 20"                                                 |
| 38         | 532 18 16-54 | Plug Drain Oil Easy                                           |
| 44         | 817 67 04-12 | Screw Hexwsh Thdrol 1/4-20 x 3/4                              |
| 45         | 817 00 06-12 | Screw Hexwsh Thdr 3/8-16 x 3/4                                |
| 46         | 819 09 14-16 | Washer 9/32 x 7/8 x 16ga                                      |
| 81         | 873 51 04-00 | Nut Keps 1/4-20 unc                                           |
| 105        | 817 12 06-16 | Screw 3/8-16 x 1                                              |
| 116        | 532 18 43-62 | Nut Hex Flange Toplock M8-1.25                                |
| 117        | 532 18 86-54 | Tube Exhaust                                                  |
| 119        | 532 40 06-01 | Guard Asm. Engine LH                                          |
| 120        | 532 40 06-00 | Guard Asm. Engine RH                                          |
| 121        | 532 19 66-88 | Clip Threaded                                                 |
| 122        | 532 13 77-29 | Screw 1/4-20 x 5/8                                            |
| 123        | 817 67 05-08 | Screw 5/16-18 x 1/2                                           |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
MOWER LIFT



lift-rh.1piece\_9

# REPAIR PARTS

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
MOWER LIFT

| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 15 94-60 | Washer Asm Inner Spring W/Plunger |
| 2       | 532 15 94-71 | Shaft Asm. Lift                   |
| 3       | 532 10 57-67 | Pin Groove                        |
| 4       | 812 00 00-02 | E Ring #5133-62                   |
| 5       | 819 21 16-21 | Washer 21/32 x 1 x 21 Ga.         |
| 6       | 532 12 01-83 | Bearing Nylon                     |
| 7       | 532 12 56-31 | Grip Handle Fluted                |
| 8       | 532 12 45-26 | Button Plunger Black              |
| 11      | 532 16 58-29 | Link Asm Lift L.H.                |
| 12      | 532 16 58-31 | Link Asm Lift R.H.                |
| 13      | 532 12 46-70 | Retainer Spring                   |
| 15      | 532 17 32-88 | Link Front                        |
| 16      | 873 35 08-00 | Nut Jam Hex 1/2-13 unc            |
| 17      | 532 17 56-89 | Trunnion Blk Zinc                 |
| 18      | 873 80 08-00 | Nut Lock w/wsh 1/2-13 unc         |
| 19      | 532 13 98-68 | Arm Suspension Mower              |
| 20      | 532 19 42-09 | Pin Cotter 7/16 Bowtie Lock       |
| 23      | 532 11 08-07 | Nut Special                       |
| 24      | 819 13 10-16 | Washer 13/32 x 5/8 x 16 Ga.       |
| 25      | 532 12 48-74 | Spring 2-1/8"                     |
| 26      | 532 16 94-84 | Retainer Clip                     |
| 27      | 532 12 69-71 | Rod Adj Lift Zinc 7.49 Wrk Lg     |
| 28      | 873 35 06-00 | Nut Hex Jam 3/8-16 unc            |
| 29      | 532 13 80-57 | Knob Inf 3/8-16 unc Blk w/sym     |
| 30      | 532 15 02-33 | Trunnion Infin Height             |
| 31      | 532 16 98-65 | Bearing, Pvt. Lift.               |
| 32      | 873 54 06-00 | Nut Crownlock 3/8-24              |
| 36      | 532 15 50-97 | Pointer Height Indicator          |
| 37      | 532 12 39-35 | Plug Hole Blk 1.485/1.515 Dia     |
| 38      | 817 06 05-16 | Screw 5/16-18 x 1                 |
| 40      | 819 11 24-10 | Washer 11/32 x 1-1/2 x 10 Ga.     |
| 41      | 532 12 39-34 | Scale Ind Height Blk              |
| 49      | 532 14 52-12 | Nut hex Flange Lock               |
| 50      | 532 11 04-52 | Nut Push Phos & Oil               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



# REPAIR PARTS

TRACTOR- -MODEL NO. CTH191 (96061007701), PRODUCT NO. 960 61 00-77  
MOWER

| KEY NO. | PART NO.            | DESCRIPTION                         | KEY NO. | PART NO.            | DESCRIPTION                       |
|---------|---------------------|-------------------------------------|---------|---------------------|-----------------------------------|
| 1       | 532 16 91-60        | Housing Asm. Mower                  | 45      | 532 17 55-39        | Cover Mandrel Rh                  |
| 2       | 872 14 05-06        | Bolt Rdhd Sqnk 5/16-18 unc x 3/4    | 46      | 532 13 77-29        | Screw Thd Roll 1/4-20 x 5/8       |
| 3       | 532 16 55-69        | Bracket Asm. S-Bar Chass            | 55      | 532 16 98-49        | Arm Idler                         |
| 4       | 532 16 91-67        | Bracket Bar Sway Deck               | 61      | <b>532 17 51-59</b> | Spring Tension Belt               |
| 5       | 532 12 46-70        | Retainer Spring                     | 67      | 532 10 69-32        | Knob                              |
| 6       | 532 16 55-57        | Bar Sway                            | 68      | <b>532 40 20-09</b> | Hex-Belt Mower                    |
| 8       | 532 18 17-12        | Bolt 3/8-24 x 1.25 Gr. 8 Patched    | 69      | 532 16 54-82        | Shaft Asm W/Lwr Brg Rh Thd CRD    |
| 9       | 810 03 06-00        | Washer Lock Hvy 3/8 Unplated        | 84      | 532 15 60-85        | Keeper Belt Idler                 |
| 11      | 532 18 05-83        | Blade 3-1 Lh                        | 116     | 532 18 42-19        | Bolt Shoulder                     |
| 13      | 532 13 76-45        | Shaft Asm. W/Lower Bearing          | 117     | 532 17 48-73        | Wheel Gage                        |
| 14      | 532 12 87-74        | Housing Mandrel Vented (Machd)      | 118     | 873 93 06-00        | Nut Centerlock 3/8-16 unc         |
| 15      | 532 11 04-85        | Bearing Ball Mandrel                | 119     | 819 12 14-14        | Washer 3/8 x 7/8 x 14 Ga.         |
| 16      | 532 18 05-84        | Blade 3-1 Rh                        | 124     | 872 11 06-12        | Bolt Carr Sh 3/8-16 x 1-1/2 Gr. 5 |
| 18      | 872 11 06-06        | Bolt Rdhd Sqnk 3/8-16 x 3/4 Gr. 5   | 130     | 872 11 05-06        | Bolt Rdhdsqnk 5/16-18 unc x 3/4   |
| 19      | 532 13 28-27        | Bolt Shoulder 5/16-18 Thd Form      | 131     | 532 16 56-61        | Chute Bagger CRD 92cm             |
| 20      | 532 18 17-13        | Bolt 3/8-24 x 1.25 Gr. 8 Ptch Lhthd | 152     | 532 17 60-74        | Cable Clutch                      |
| 21      | 873 68 05-00        | Nut Crown Lock 5/16-18              | 158     | 817 72 04-08        | Screw 1/4-20 x 1/2                |
| 22      | 532 16 91-65        | Bracket Idler Sprt RR               | 161     | 532 18 04-24        | Blade Cross LH 107                |
| 23      | 532 16 91-66        | Bracket Idler Sprt RF               | 162     | 532 18 08-78        | Adapter Weldment Blade 107        |
| 24      | 532 16 91-70        | Bracket Suspension LF               | 163     | 532 18 04-25        | Blade Cross RH 107                |
| 25      | 532 40 01-05        | Bracket Suspension RF               | 164     | 532 12 49-37        | Bearing                           |
| 26      | 532 40 01-10        | Brace Susp Frt CRD                  | 169     | 532 40 02-76        | Guard Asm. Fabric LH              |
| 27      | 532 16 91-72        | Bracket Asm. Susp RR                | 170     | 532 40 02-77        | Guard Asm. Fabric RH              |
| 28      | 532 16 91-68        | Bracket Asm. Susp LR                | 171     | 817 49 06-08        | Screw 3/8-16 x 1/2                |
| 30      | 532 17 39-84        | Screw Thd Rolling Dod.PT Hex        | 172     | 532 40 12-20        | Push Nut round 3/8 Diameter       |
| 31      | 532 18 76-90        | Washer Spacer Mower Vented          | 173     | 873 80 06-00        | Nut Lock Hex 3/8-16 unc           |
| 32      | <b>532 17 57-07</b> | Mandrel Pulleys                     | 174     | 532 40 02-40        | Guard Susp. Front                 |
| 33      | 532 40 02-34        | Nut Flg Top Lock                    | 175     | 872 11 06-08        | Bolt 3/8-16 x 1 Gr.5              |
| 34      | 532 40 01-03        | Bracket Gauge Wheel Lf              | 185     | 532 18 82-34        | Head Asm Cable Clutch             |
| 35      | 532 40 01-04        | Bracket Gauge Wheel Rf              | 254     | <b>817 00 06-16</b> | Screw 3/8-16 x 1                  |
| 36      | 532 14 67-63        | Pulley Idler V-Groove Dim 4.25      | --      | 532 18 18-57        | Mandrel Asm Service               |
| 38      | 532 16 98-51        | Spacer Hub Arm Idler                | --      | 532 18 18-58        | Mandrel Asm CRD Lh Threads VC     |
| 39      | 872 11 06-22        | Bolt RhHd 3/8-16 unc x 2-3/4 Gr.5   | --      | <b>532 40 03-18</b> | Replacement Mower Complete        |
| 40      | 873 68 06-00        | Nut Crownlock 3/8-16 unc            |         |                     |                                   |
| 41      | 873 90 06-00        | Nut Flangelock 3/8-16 unc           |         |                     |                                   |
| 44      | 532 17 55-38        | Cover Mandrel Lh                    |         |                     |                                   |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

