





SPARE PARTS LIST

FRONTRIDERS®


FR2218 FA 4x4, 966773701, 2012



Ref	Part No	Description	Remark	QTY KIT	
40	523 09 53-02	BRACKET		1	
41	725 24 51-71	SCREW EHHM		4	
42	732 21 18-01	LOCK NUT		4	
43	502 64 18-06	CROSS BAR		1	
44	523 09 45-04	CROSS BAR		1	
45	506 86 96-01	BEARING		8	
46	506 81 38-01	REINFORCING PLATE		4	
47	725 24 61-51	SCREW EHHM		8	
48	732 21 18-01	LOCK NUT		8	
49	523 11 42-01	PARALLELL ROD ASSY		1	
50	502 64 23-01	PARALLEL ROD		1	
51	506 83 98-01	GAFFELLÄNK		1	
52	721 61 83-01	SPLIT PIN		1	
53	523 08 65-04	DECK FRAME		1	
54	574 56 19-01	BEARING		4	
55	574 21 01-02	PIVOT WHEEL ASSY		2	
57	506 96 30-01	WHEEL ASSY		1	55
58	506 81 08-02	WHEEL AXLE TUBE		1	55
59	506 87 41-02	SPACER		2	55
60	725 25 19-51	SCREW EHHM		1	55
61	732 21 20-51	NUT		1	55
62	503 89 47-02	SNÄPPE		1	
63	506 57 01-04	SCREW EHHFM		2	
64	734 11 64-41	WASHER		2	
65	574 03 48-01	PLUG		2	
66	725 23 68-61	SCREW EHHFT		4	
67	732 21 18-01	LOCK NUT		2	
68	523 08 75-02	DECK ATTACHMENT		1	
69	523 11 46-01	LOCK		1	
70	725 23 68-61	SCREW EHHFT		2	




Ref	Part No	Description	Remark	QTY KIT	
1	574 21 08-02	CUTTING DECK		1	
2	506 91 62-01	BLIND RIVET NUT		1	
3	544 44 92-01	PLUG		1	
4	506 57 01-04	SCREW EHHFM		1	
5	576 38 41-01	BLADE HOUSING ASSY		1	
6	576 38 42-01	BEARING HOUSING		1	5
7	576 38 43-01	SHAFT		1	5
8	576 38 44-01	SPACING SLEEVE		1	5
9	738 23 04-34	BALL BEARING		2	5
10	576 38 41-02	BLADE HOUSING ASSY		2	
11	576 38 42-01	BEARING HOUSING		1	10
12	576 38 43-02	SHAFT		1	10
13	576 38 44-01	SPACING SLEEVE		1	10
14	738 23 04-34	BALL BEARING		2	10
15	535 42 38-01	SCREW RSQM		12	
16	734 11 64-01	WASHER		12	
17	732 21 18-01	LOCK NUT		12	
18	506 92 21-01	PULLEY		3	
19	506 53 35-01	PARALLEL KEY		7	
20	544 06 80-02	SPACING SLEEVE		1	
21	734 11 74-41	WASHER		3	
22	544 11 41-01	SCREW EHHM		3	
23	535 50 42-02	BLADE BRACKET		3	
24	504 18 82-01	RIDE ON BLADE		3	
25	506 79 23-01	KNIFE PLATE		3	
26	544 11 41-01	SCREW EHHM		3	
27	506 54 07-01	BELT TENSIONER ASSY		1	
28	506 51 95-01	SPÄNNARM KPL.		1	27
29	506 53 27-01	PULLEY		1	27
30	734 11 64-41	WASHER		1	27
31	506 55 83-02	SCREW EHHFT		1	27
32	506 91 87-02	WASHER		1	
33	725 24 51-71	SCREW EHHM		1	
34	732 21 18-01	LOCK NUT		1	
35	506 53 31-01	SPRING		1	
36	506 76 85-01	DRIVE BELT		1	
37	544 09 61-02	BELT COVER		1	
38	544 40 05-01	SCREW		2	
39	506 77 86-01	PULLEY		1	
72	506 78 97-01	LABEL		1	
74	506 92 90-01	LABEL		1	
76	574 51 00-01	DECAL		2	




Ref	Part No	Description	Remark	QTY KIT	
40	523 09 53-02	BRACKET		1	
41	725 24 51-71	SCREW EHHM		4	
42	732 21 18-01	LOCK NUT		4	
43	502 64 18-06	CROSS BAR		1	
44	523 09 45-04	CROSS BAR		1	
45	506 86 96-01	BEARING		8	
46	506 81 38-01	REINFORCING PLATE		4	
47	725 24 61-51	SCREW EHHM		8	
48	732 21 18-01	LOCK NUT		8	
49	523 11 42-01	PARALLELL ROD ASSY		1	
50	502 64 23-01	PARALLEL ROD		1	
51	506 83 98-01	GAFFELLÄNK		1	
52	721 61 83-01	SPLIT PIN		1	
53	523 08 65-04	DECK FRAME		1	
54	574 56 19-01	BEARING		4	
55	574 21 01-02	PIVOT WHEEL ASSY		2	
57	506 96 30-01	WHEEL ASSY		1	55
58	506 81 08-02	WHEEL AXLE TUBE		1	55
59	506 87 41-02	SPACER		2	55
60	725 25 19-51	SCREW EHHM		1	55
61	732 21 20-51	NUT		1	55
62	503 89 47-02	SNÄPPE		1	
63	506 57 01-04	SCREW EHHFM		2	
64	734 11 64-41	WASHER		2	
65	574 03 48-01	PLUG		2	
66	725 23 68-61	SCREW EHHFT		4	
67	732 21 18-01	LOCK NUT		2	
68	523 08 75-02	DECK ATTACHMENT		1	
69	523 11 46-01	LOCK		1	
70	725 23 68-61	SCREW EHHFT		2	

GPL®




Ref	Part No	Description	Remark	QTY KIT	
1	574 20 95-02	CUTTING DECK		1	
2	506 91 62-01	BLIND RIVET NUT		1	
3	544 44 93-01	PLUG		1	
4	506 57 01-04	SCREW EHHFM		1	
5	576 38 41-01	BLADE HOUSING ASSY		1	
6	576 38 42-01	BEARING HOUSING		1	5
7	576 38 43-01	SHAFT		1	5
8	576 38 44-01	SPACING SLEEVE		1	5
9	738 23 04-34	BALL BEARING		2	5
10	576 38 41-02	BLADE HOUSING ASSY		2	
11	576 38 42-01	BEARING HOUSING		1	10
12	576 38 43-02	SHAFT		1	10
13	576 38 44-01	SPACING SLEEVE		1	10
14	738 23 04-34	BALL BEARING		2	10
15	535 42 38-01	SCREW RSQM		12	
16	734 11 64-01	WASHER		12	
17	732 21 18-01	LOCK NUT		12	
18	506 92 21-01	PULLEY		3	
19	506 53 35-01	PARALLEL KEY		7	
20	544 06 80-02	SPACING SLEEVE		1	
21	734 11 74-41	WASHER		3	
22	544 11 41-01	SCREW EHHM		3	
23	535 50 42-02	BLADE BRACKET		3	
24	544 10 28-01	RIDE ON BLADE		3	
25	506 79 23-01	KNIFE PLATE		3	
26	544 11 41-01	SCREW EHHM		3	
27	506 54 07-01	BELT TENSIONER ASSY		1	
28	506 51 95-01	SPÄNNARM KPL.		1	27
29	506 53 27-01	PULLEY		1	27
30	734 11 64-41	WASHER		1	27
31	506 55 83-02	SCREW EHHFT		1	27
32	506 91 87-02	WASHER		1	
33	725 24 51-71	SCREW EHHM		1	
34	732 21 18-01	LOCK NUT		1	
35	506 53 31-01	SPRING		1	
36	535 41 19-01	BELT		1	
37	544 09 62-02	BELT COVER		1	
38	544 40 05-01	SCREW		2	
39	506 77 86-01	PULLEY		1	
72	506 78 97-01	LABEL		1	
74	506 92 90-01	LABEL		1	
75	535 43 74-01	LABEL WARNING		1	
76	574 51 00-01	DECAL		2	

F FR2218 FA 4X4
CHASSIS

Ref	Part No	Description	Remark	QTY KIT
1	577 93 91-02	CHASSIS		1
2	506 91 62-01	BLIND RIVET NUT		4




J1 FR2218 FA 4X4
CHASSIS, REAR

CHASSIS REAR

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY	KIT
10	535 40 60-02	BRACKET		1	
11	506 98 61-02	GLIDLAGER		2	10
26	544 26 21-01	BRACKET		1	
27	506 56 65-01	CLIP		1	
28	725 23 64-61	SCREW EHHFT		1	
45	506 88 99-01	HITCH		1	
46	725 25 00-51	SCREW EHHM		2	
47	544 03 96-03	COUNTERWEIGHT		1	




J2FR2218 FA 4X4
CHASSIS, REAR

CHASSIS REAR

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT	
12	544 11 61-01	TRANSMISSION		1	
13	725 24 67-51	SCREW EHHM		4	
14	734 11 64-01	WASHER		4	
15	731 23 18-01	HEXAGON NUT		4	
16	506 98 72-01	MOMENTFÄSTE		1	
17	725 24 59-51	SCREW EHHM		1	
18	725 24 62-51	SCREW EHHM		1	
19	506 59 93-01	LINK		1	
20	731 23 18-01	HEXAGON NUT		2	
21	506 98 74-03	LEVER		1	
22	506 91 87-02	WASHER		1	
23	725 24 51-71	SCREW EHHM		1	
24	506 98 75-01	ADJUSTING ROD		1	
25	732 21 14-01	LOCK NUT		2	
29	506 98 82-01	FRIKOPPLINGSSTÅNG		1	
30	506 83 43-01	SPRING		1	
31	506 98 84-01	BELT TENSIONER ASSY		1	
32	506 98 85-01	BELT TENSIONER		1	31
33	506 94 69-01	BELT TENS WHEEL ASSY		1	31
34	725 24 55-51	SCREW		1	31
35	734 11 64-41	WASHER		1	31
36	732 21 18-01	LOCK NUT		1	31
37	506 91 87-02	WASHER		1	
38	725 24 51-51	SCREW		1	
39	506 98 86-01	SPRING		1	
40	725 24 67-51	SCREW EHHM		1	
41	544 10 01-01	EXPANSION TANK		1	
42	544 12 17-01	BRACKET		1	
43	725 23 64-61	SCREW EHHFT		1	
44	506 67 33-01	TANK CAP ASSY		1	

N FR2218 FA 4X4
CONTROLS




CONTROLS

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT
1	502 29 56-01	THROTTLE CONTROL		1
2	544 30 17-01	WIRE		1
3	506 88 91-01	KNOB		1
4	725 23 64-61	SCREW EHHFT		2






COVER

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY	KIT
1	504 05 92-01	FOOT PLATE		1	
2	504 06 02-01	MAT		1	1
3	504 05 93-02	FOOT PLATE		1	
4	504 06 02-03	MAT		1	3
5	544 40 05-01	SCREW		4	
20	544 23 92-02	COVER		1	
21	544 42 75-01	MAT		1	
22	544 40 05-01	SCREW		2	
23	504 06 01-01	COVER		1	
24	544 40 05-01	SCREW		2	
25	544 43 32-02	PROTECTIVE COVER		1	
26	525 56 24-02	UNIT COVER		1	






COVER

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT
13	504 05 95-01	CONTROL COVER		1
14	504 05 97-02	CONTROL COVER		1
15	504 05 98-02	COVER		1
16	535 42 91-01	SPRING NUT		1
17	544 40 05-01	SCREW		7




C1 FR2218 FA 4X4
COVER

COVER

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT	
6	535 41 90-04	ENGINE HOOD ASSY		1	
7	535 41 99-01	HINGE		1	6
8	535 41 99-02	HINGE		1	6
9	722 79 54-02	RIVET		6	6
10	503 89 47-02	SNÄPPE		1	
18	578 26 12-02	TRANSMISSION COVER		1	
19	574 85 62-01	SCREW		2	




S FR2218 FA 4X4
DECALS

DECALS


FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT
1	544 43 86-01	LABEL		1
2	502 29 14-01	LABEL		1
3	544 43 88-02	LABEL		1
4	544 43 90-03	LABEL		1
5	544 43 92-02	LABEL		1
7	501 00 27-01	LABEL		2
8	505 21 77-05	LABEL		1
9	535 43 47-01	DECAL		3
10	544 21 14-01	LABEL		2
11	574 44 32-01	LABEL		2
12	502 29 26-05	LABEL		1





Ref	Part No	Description	Remark	QTY KIT
1	510 13 85-01	BATTERY		1
2	535 44 11-01	BATTERY MAT		1
3	510 02 69-01	COVER		1
4	506 83 68-02	BATTERY BELT		1
5	522 62 21-01	SCREW EHHM		2
6	522 62 43-01	NUT		2
7	725 23 64-61	SCREW EHHFT		1
8	506 89 98-01	NUT		3
9	544 96 76-03	CABLE		1
10	544 44 21-01	IGNITION SWITCH		1
11	544 44 22-01	IGNITION SWITCH		1 10
12	544 44 23-01	NUT		1 10
13	544 44 24-01	IGNITION KEY		1 10
14	578 33 83-01	WIRING		1
15	544 92 86-01	CABLE		1
16	544 92 61-04	CABLE		1
17	544 43 98-01	RELAY		1
19	576 18 54-01	WIRING		1
20	506 90 93-01	PLATE SPRING		1
21	722 78 39-02	BLIND RIVET		2
22	574 31 60-01	SWITCH		1
23	544 44 07-01	RIVET		2
24	506 90 96-01	SWITCH		1
25	506 90 97-01	SPRING WASHER		1
26	544 44 12-01	SPRING		1
27	506 90 99-02	SPACING TUBE		1
28	725 24 60-51	SCREW EHHM		1
29	734 11 64-01	WASHER		1
30	574 31 61-01	SWITCH		1
31	544 41 57-01	BRACKET		1
32	544 44 07-01	RIVET		2




ENGINE

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT
1	577 34 36-01	ENGINE		1
2	725 24 57-51	SCREW		4
3	734 11 64-01	WASHER		4
4	506 55 63-02	SCREW UNC		1
5	732 21 18-01	LOCK NUT		4
6	535 48 52-02	EXHAUST PIPE ASSY		1
7	506 91 45-01	GASKET		1
8	506 55 63-01	SCREW UNC		2
9	535 40 08-01	MUFFLER ASSY		1
10	725 23 68-61	SCREW EHHFT		4
11	506 82 79-01	DEFLECTOR		1
12	722 79 23-09	RIVET		4
13	506 66 84-01	CLAMP ASSY		1
14	535 41 62-01	HEAT PROTECTOR		1
15	506 59 74-01	SCREW		2
16	506 83 94-01	SPRING WASHER		2
17	732 21 18-01	LOCK NUT		2




B FR2218 FA 4X4
FUEL SYSTEM

FUEL SYSTEM

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT
1	504 05 99-01	FUEL TANK		1
2	544 32 93-01	BRACKET		1
3	732 21 16-01	NUT		2
4	734 11 56-01	WASHER		1
5	506 67 33-01	TANK CAP ASSY		1
6	504 80 00-07	FUEL HOSE		1
7	535 46 97-01	HOSE BRACE		2
8	725 23 64-61	SCREW EHHFT		1
9	504 55 66-01	SUPPORT		1
10	725 24 93-71	SCREW EHHM		2




D FR2218 FA 4X4
HEIGHT ADJUSTMENT

HEIGHT ADJUSTMENT

FR2218 FA 4x4, 966773701, 2012


Ref	Part No	Description	Remark	QTY KIT
1	535 50 14-02	CONTROL PLATE		1
2	506 57 01-03	SCREW EHHFM		2
3	504 73 45-01	ADJUSTER		1
4	506 54 20-02	HANDLE		1
5	506 55 43-01	BEARING		2
6	735 31 22-20	E-CLIP		1
7	506 90 82-01	HEIGHT ROD		1
8	506 78 46-01	PEN		1
9	734 11 72-01	WASHER		1
10	732 21 18-01	LOCK NUT		1
11	731 23 18-01	HEXAGON NUT		1
12	721 61 83-01	SPLIT PIN		2
13	578 04 07-01	LINK		1
14	735 31 22-20	E-CLIP		1
15	523 11 45-01	CONNECTION ROD		1






Ref	Part No	Description	Remark	QTY KIT	
1	544 11 61-01	TRANSMISSION		1	
2	506 98 65-01	SPRING WASHER		1	
3	506 98 66-01	DISTANCE		2	
4	502 45 19-01	PULLEY		1	
5	506 98 68-01	FAN		1	
6	735 31 15-00	CIRCLIP		1	
7	502 45 16-01	TUBE		1	
8	506 98 70-01	HOSE CLAMP		2	
9	535 40 28-07	CLIP		1	1
10	535 40 28-32	PLUG		1	1
11	535 40 28-29	MAGNET		1	1
12	502 45 20-01	MAGNET HOLDER		1	1
13	535 40 28-37	SEALING		2	1
14	502 45 32-01	CONTROL LEVER		1	1
15	535 40 28-09	PIN RETAINING SCREW		1	1
16	535 40 28-17	LEVER		1	1
17	535 40 28-16	PIN RETAINING SCREW		1	1
18	535 40 28-33	PIN RETAINING SCREW		1	1
19	535 40 28-38	LEVER		1	1
20	535 40 28-39	RETURN SPRING		1	1
21	535 40 28-40	PIN RETAINING SCREW		1	1
22	535 40 28-41	PIN RETAINING SCREW		1	1






Ref	Part No	Description	Remark	QTY	KIT
1	575 48 43-01	TRANSMISSION		1	
2	725 24 67-51	SCREW EHHM		1	
3	725 24 64-51	SCREW EHHM		1	
4	535 42 38-03	SCREW RSQM		1	
5	734 11 64-01	WASHER		3	
6	732 21 18-01	LOCK NUT		3	
7	544 00 89-02	BEARING		1	
8	544 00 90-02	BEARING HOUSING		2	
9	506 57 01-05	SCREW EHHFM		2	
10	734 11 64-01	WASHER		2	
11	732 21 18-01	LOCK NUT		2	
24	544 37 33-02	PIPE CLAMP		1	
25	544 37 38-02	COVER PLATE		1	
26	506 57 01-07	SCREW EHHFM		1	
27	544 81 17-01	CAGE NUT		1	
28	535 49 97-01	ARM		1	
29	503 73 58-01	BUSHING		1	
30	578 29 19-01	LEVER		1	
31	721 43 47-01	SPRING PIN		1	
33	535 49 28-02	BRACKET		1	
34	544 45 67-03	ROD		1	
35	535 48 66-02	ROD END		1	34
36	503 22 10-18	HEXAGON NUT		1	34
37	535 48 65-03	ROD		1	34
38	731 23 16-01	HEXAGON NUT		1	34
39	535 48 66-01	ROD END		1	34
40	544 84 17-01	SCREW		1	
41	725 23 70-71	SCREW EHHM		1	34
42	732 21 16-01	NUT		1	
43	535 49 74-02	LEVER		1	
44	506 95 17-01	ROD END		2	
45	535 47 52-12	SCREW EHHFM		2	
46	544 44 19-01	ADJUSTING ROD		1	
47	732 21 16-01	NUT		1	
48	725 24 93-71	SCREW EHHM		2	
49	725 23 66-51	HEXAGONAL SCREW M6X12		2	
50	732 21 16-01	NUT		3	
51	544 80 80-01	HYDRAULIC PIPE		2	
52	544 80 79-01	HYDRAULIC PIPE		2	
53	535 42 68-06	PIPE FITTING		2	
54	505 45 11-01	O-RING		2	
55	578 04 78-01	BRACKET		1	
56	725 23 68-61	SCREW EHHFT		1	

E FR2218 FA 4X4
MOWER LIFT


Ref	Part No	Description	Remark	QTY KIT
1	501 01 86-02	LIFTING LEVER ASSY		1
2	506 55 65-01	BEARING		2
3	525 40 66-01	PEN		1
5	721 61 83-01	SPLIT PIN		1
6	506 78 43-01	LINK ASSY		1
7	725 24 97-51	SCREW		1
8	731 23 20-51	HEXAGON NUT		1
9	544 43 36-01	LIFTING ARM		1
10	725 25 42-51	SCREW EHHM		1
11	732 25 22-01	HEXAGON LOCKING NUT		1
12	506 91 68-01	SPRING		1
13	506 90 56-01	OFFSET PULLEY		2
14	506 90 57-01	SHAFT		1
15	506 90 57-02	SHAFT		1
16	735 31 18-20	E-CLIP		2
17	506 55 46-07	CHAIN		1
18	506 55 47-01	LINKAGE		1
19	544 93 42-01	CHAIN STOP		1
20	506 96 66-01	HAIR PIN COTTER		1
21	544 45 69-01	CONNECTION ROD		1
22	721 61 83-01	SPLIT PIN		1
23	544 37 86-01	LINK		1
24	735 31 14-20	E-CLIP		1
25	544 44 88-01	CONNECTION ROD		1
26	734 11 64-41	WASHER		1
27	721 61 83-01	SPLIT PIN		1



P FR2218 FA 4X4
PEDALS



PEDALS




PEDALS

FR2218 FA 4x4, 966773701, 2012


Ref	Part No	Description	Remark	QTY KIT	
1	544 12 60-01	PEDAL PLATE ASSY		1	
2	535 47 37-01	KNOB		1	
3	506 57 01-04	SCREW EHHFM		4	
4	544 40 31-01	BRAKE LEVER ASSY		1	
6	506 94 63-01	BRAKE SPRING		1	
7	576 71 21-01	BRAKE WIRE		1	
8	735 31 09-20	HARNESS		1	
10	574 41 12-02	CONTROL CABLE		1	
11	506 55 73-01	VINKELL.AS8 DIN71802		2	
12	732 21 14-01	LOCK NUT		2	
13	731 23 14-01	HEXAGON NUT		2	
14	522 43 08-01	BRACKET		1	
15	725 23 64-61	SCREW EHHFT		4	
16	738 21 02-04	BALL BEARING		1	
17	535 48 02-01	ROLLER		1	1
18	535 48 06-01	PROTECTIVE PLATE		1	1
19	535 48 07-01	SPRING		1	1
20	535 48 08-01	BEARING SUPPORT		4	1
21	535 48 09-01	BEARING SUPPORT		5	1
22	535 48 10-01	REINFORCEMENT PLATE		3	1
23	535 47 88-01	PEDAL RUBBER		1	1
24	535 47 88-02	PEDAL RUBBER		1	1
25	506 57 64-02	CABLE HOLDER		1	1
26	506 56 65-01	CLIP		1	



A FR2218 FA 4X4
SEAT, TS2500

Ref	Part No	Description	Remark	QTY KIT
1	573 99 50-04	SEAT BRACKET		1
2	506 91 53-01	COMPRESSION SPRING		1
3	734 11 74-41	WASHER		1
4	725 24 93-71	SCREW EHHM		1
5	502 60 97-01	SEAT		1
6	506 56 55-01	JUSTERVRED		2
7	506 56 53-01	BUSHING		2
8	734 11 64-41	WASHER		2
9	506 55 63-01	SCREW UNC		2
10	506 59 74-01	SCREW		2






STEERING

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT	
1	506 67 19-01	SPRING		1	
2	506 57 63-01	SPRING RETAINER		1	
3	506 67 08-01	LINK		1	
4	506 59 74-01	SCREW		1	
5	544 37 52-03	STEERING WHEEL		1	
6	728 74 55-05	SCREW IHSETM		1	
7	731 23 18-01	HEXAGON NUT		1	
8	535 49 95-01	ROD STEERING ASSY		1	
9	506 86 34-01	DRIVER		3	
10	728 84 43-05	SCREW IHSETM		3	
11	578 06 52-01	BRACKET		1	
12	506 88 78-01	SPACER		1	
13	738 21 04-04	BALL BEARING		1	
14	506 57 01-04	SCREW EHHFM		3	
15	506 50 09-03	BARRING WHEEL		1	
16	535 42 41-01	BARRING WHEEL		1	15
17	735 31 40-10	CIRCLIP		1	15
18	738 22 04-19	BALL BEARING		1	15
19	506 50 08-02	BUSHING		1	15
20	506 67 54-03	SCREW EHHFM		1	
21	734 11 74-41	WASHER		1	
22	506 58 91-04	WIRE ASSY		2	
23	506 52 24-01	STARTER PULLEY		2	
24	506 53 94-03	SHAFT		1	
25	735 31 14-20	E-CLIP		2	
26	506 55 46-01	CHAIN		1	
27	506 55 47-01	LINKAGE		2	
28	544 42 73-01	WIRE GUIDE		1	
29	731 23 20-51	HEXAGON NUT		2	
30	577 65 93-02	SPINDLE		1	
31	738 21 05-04	BALL BEARING		1	
32	738 21 10-04	BALL BEARING		1	
33	735 31 40-10	CIRCLIP		1	
34	735 31 26-00	CIRCLIP		1	
35	506 98 59-01	SWING AXLE		1	
36	735 31 26-00	CIRCLIP		2	
37	506 77 34-01	WASHER		2	
38	740 68 14-21	V-RING		1	
39	732 21 20-51	NUT		2	


G FR2218 FA 4X4
TRANSMISSION

TRANSMISSION

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT
1	522 93 03-01	BELT		1
2	544 40 02-01	BELT		1
3	535 41 19-01	BELT		1
4	506 50 92-01	SPACING SLEEVE		1
5	506 55 59-01	WEDGE		1
6	535 48 24-01	PULLEY		1
7	506 59 75-01	WASHER		1
8	506 55 60-02	SCREW UNC		1
9	506 66 45-01	BELT GUIDE		1
10	731 23 20-51	HEXAGON NUT		4
11	535 48 44-01	BELT TENSIONER ASSY		1
12	735 31 26-00	CIRCLIP		1
13	506 66 56-01	SPRING		1
14	544 42 61-01	SHAFT		1
15	506 67 54-02	SCREW EHHFM		1
16	535 48 22-01	MELLANHJUL		1
17	506 77 57-01	WASHER		1
18	544 40 53-01	BELT GUIDE		1
20	506 59 75-01	WASHER		1
22	506 57 01-05	SCREW EHHFM		1





WHEELS & TIRES

FR2218 FA 4x4, 966773701, 2012

Ref	Part No	Description	Remark	QTY KIT	
1	523 01 26-01	WHEEL		4	
2	523 03 48-01	RIM		1	1
3	523 03 46-01	TYRE		1	1
4	523 03 47-01	VALVE		1	1
5	506 50 48-03	WASHER		2	
6	506 94 58-01	WASHER		1	
7	506 59 62-03	SPACING SLEEVE		2	
8	544 13 26-01	SLEEVE		1	
9	544 13 26-02	SLEEVE		1	
10	506 50 48-05	WASHER		4	
11	506 89 90-01	E-CLIP		4	
12	577 77 29-01	HUB CAP		4	

