

# ICT16 A

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**


**Repuestos**

**Reservdelar**

**GPL®**

# REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
ELECTRICAL



# REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
ELECTRICAL

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                       |
|------------|--------------|-----------------------------------|
| 1          | 532 16 34-65 | Battery                           |
| 2          | 874 76 04-12 | Bolt Hex Hd 1/4-20 Unc X 3/4      |
| 16         | 532 17 61-38 | Switch Interlock                  |
| 21         | 532 17 56-88 | Harness Asm Light W/4152J         |
| 22         | 532 00 41-52 | Bulb Light #1156                  |
| 24         | 532 12 47-80 | Cable Starter 6Ga 11" Red         |
| 25         | 532 16 59-87 | Cable Battery Crd 56" Red         |
| 26         | 532 17 51-58 | Fuse                              |
| 27         | 873 51 04-00 | Nut Keps Hex 1/4-20 Unc           |
| 28         | 532 12 77-25 | Cable Ground 6Ga 18" Black        |
| 29         | 532 16 07-84 | Switch Plunger Normal Op Olive    |
| 30         | 532 17 55-66 | Switch Ignition                   |
| 33         | 532 14 04-01 | Key Ign                           |
| 40         | 532 17 97-28 | Harness Ign                       |
| 41         | 871 11 04-08 | Bolt Flk Fin Hex 1/4-20 Unc X 1/2 |
| 42         | 532 13 15-63 | Cover Terminal Red                |
| 43         | 532 17 88-61 | Solenoid                          |
| 48         | 532 14 08-44 | Adapter Ammeter Rectangular       |
| 52         | 532 14 19-40 | Protection Wire Loop              |
| 58         | 532 16 94-19 | Buzzer Crd                        |
| 59         | 532 18 03-79 | Switch FBI CRD                    |
| 66         | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2 Ty-Tt   |
| 81         | 532 10 97-48 | Relay Asm                         |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
CHASSIS AND ENCLOSURES



# REPAIR PARTS


## TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66 CHASSIS AND ENCLOSURES

| KEY NO. | PART NO.            | DESCRIPTION                                  | KEY NO. | PART NO.            | DESCRIPTION                         |
|---------|---------------------|----------------------------------------------|---------|---------------------|-------------------------------------|
| 1       | 532 17 46-20        | Chassis                                      | 57      | 874 78 04-12        | Bolt Fin Hex 1/4-20 Unc x .75       |
| 2       | 532 18 03-84        | Drawbar                                      | 69      | 532 14 24-32        | Screw Hex Wsh                       |
| 3       | 817 06 06-12        | Screw 3/8-16 x 3/4                           | 89      | 532 18 13-60        | Console                             |
| 5       | 532 15 52-72        | Bumper Hood/Dash                             | 145     | 532 15 65-24        | Rod Pivot Chassis/Hood              |
| 6       | 532 15 59-23        | Saddle                                       | 161     | <b>532 16 46-55</b> | Extrusion Bumper                    |
| 8       | 532 12 64-71        | Clip Insulator 13/32 Mtg. Hole               | 162     | 532 18 03-82        | Bracket Exten Chassis Lh CRD        |
| 9       | 532 17 22-43        | Dash                                         | 163     | 532 18 03-83        | Bracket Exten Chassis Rh CRD        |
| 10      | 872 14 06-08        | Bolt, Carriage 3/8-16 x 3/4                  | 164     | 532 16 56-05        | Support Battery CRD                 |
| 11      | <b>532 17 49-96</b> | Panel, Dash, L.H.                            | 165     | 532 18 13-56        | Cover Battery                       |
| 12      | 532 14 56-60        | Clip Tinnerman                               | 170     | 532 17 88-62        | Backplate Asm CRD                   |
| 13      | <b>532 17 21-06</b> | Panel, Asm. Dash R.H.                        | 171     | 872 14 06-20        | Bolt Rdhd Sqnk 3/8-16 x 2-1/2 Gr. 5 |
| 15      | 874 18 05-12        | Screw, Machine, Truss Head 5/16-18 UNC x 3/4 | 172     | 819 13 20-16        | Washer 13/32 x 1-1/4 x 16 Ga.       |
| 16      | 873 51 05-00        | Nut                                          | 173     | 873 51 06-00        | Nut, Keps Hex 3/8-16 UNC            |
| 17      | 532 15 07-60        | Hood                                         | 175     | 532 18 03-10        | Guard Trap                          |
| 20      | 532 18 06-79        | Plate Mtg Battery/Tank Fuel Fr.              | 179     | 532 18 03-76        | Rod Pivot FBI CRD                   |
| 24      | 874 78 06-16        | Bolt                                         | 184     | 532 17 46-62        | Bracket Actuator Bagger CRD         |
| 25      | 819 13 13-12        | Washer 13/32 x 13/16 x 12 Gauge              | 185     | 532 18 11-01        | Knob Rod Brake Parking              |
| 26      | 873 80 06-00        | Nut                                          | 186     | 532 16 07-93        | Latch Asm Mulch/Bagger              |
| 28      | 532 17 93-51        | Grille /Lens Asm                             | 187     | 532 12 50-04        | Nut Weld                            |
| 29      | 532 17 90-14        | Lens, Grille                                 | 188     | 819 06 12-16        | Washer #10                          |
| 30      | 532 18 13-59        | Fender                                       | 189     | 810 07 10-00        | Washer Lock #10                     |
| 31      | 532 16 51-56        | Bracket, Fender Support                      | 190     | 871 08 10-10        | Screw Pan Hd Phillip 10-24 x 5/8    |
| 33      | 532 18 11-93        | Footrest, L.H.                               | 198     | 532 16 89-37        | Nut, Push                           |
| 34      | 532 18 11-94        | Footrest, R.H.                               | 205     | 817 49 06-08        | Screw Thdrol 3/8-16 x 1/2           |
| 35      | 872 11 06-06        | Bolt                                         | 207     | 817 67 05-08        | Screw Thdrol 5/16-18 x 1/2          |
| 37      | 817 49 05-08        | Screw Thdrol 5/16-18 x 1/2 TYT               | 208     | 817 67 06-08        | Screw Thdrol 3/8-16 x 1/2           |
| 38      | <b>532 18 17-48</b> | Bracket Asm Pivot Mower Rear                 | 209     | 817 00 06-12        | Screw Hex Wsh Thdrol 3/8-16         |
| 51      | 873 80 04-00        | Nut Lock W/Insrt 1/4-20 Unc                  | 212     | 532 16 59-19        | Insert Lens Reflective              |
| 52      | 819 09 14-16        | Washer 9/32 x 7/8 x 16 Ga.                   | 214     | 532 12 47-88        | Retainer Spring                     |
| 53      | 532 14 52-01        | Bracket Grille Pick off LH                   | 219     | <b>817 00 05-12</b> | Screw 5/16-18 x 3/4                 |
| 54      | 532 16 14-64        | Screw Hex Wshd 8-18 x 7/8                    | 256     | 532 18 13-61        | Cover Fender Rack CRD               |
| 55      | 532 14 52-02        | Bracket Grille Pick off RH                   |         |                     |                                     |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

## REPAIR PARTS

**TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
DRIVE**



# REPAIR PARTS

**TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66**  
**DRIVE**


| KEY NO. | PART NO.            | DESCRIPTION                                                                |
|---------|---------------------|----------------------------------------------------------------------------|
| 1       | -----               | Transaxle Hydro Gear 321-0510<br>(Order parts from transaxle manufacturer) |
| 8       | 532 16 56-19        | Rod, Shift Fender Adjust Lt                                                |
| 9       | 532 18 03-54        | Clutch Noram                                                               |
| 10      | 876 02 04-16        | Pin, Cotter 1/8 x 1                                                        |
| 14      | 810 04 04-00        | Washer, Lock Hvy Helical                                                   |
| 16      | 873 80 05-00        | Nut, Lock Hex w/Ins 5/16-18 UNC                                            |
| 21      | <b>532 13 05-64</b> | Knob 1/2-13                                                                |
| 22      | 532 17 56-07        | Rod, Brake                                                                 |
| 24      | 873 35 06-00        | Nut                                                                        |
| 25      | 532 10 68-88        | Spring, Rod, Brake                                                         |
| 26      | 819 13 13-16        | Washer 13/32 x 13/16 x 16 Ga.                                              |
| 27      | 876 02 04-12        | Pin, Cotter 1/8 x 3/4                                                      |
| 28      | 532 17 57-65        | Rod, Parking Brake                                                         |
| 29      | 532 07 16-73        | Cap, Parking Brake                                                         |
| 30      | 532 16 95-92        | Bracket, Mfg. Transaxle                                                    |
| 34      | 532 17 55-78        | Shaft, Asm Pedal Foot CRD                                                  |
| 35      | 532 12 01-83        | Bearing, Nylon                                                             |
| 36      | 819 21 16-16        | Washer 21/32 x 1 x 16 Ga.                                                  |
| 37      | 532 12 49-63        | Pin, Roll 3/16 x 1"                                                        |
| 38      | 532 16 59-36        | Pulley Flat Composite 3.06"                                                |
| 39      | 874 76 06-44        | Bolt Fin Hex 3/8-16 Unc x 2-3/4                                            |
| 40      | 532 12 49-65        | Spacer, Split 395 x 59 Bzp                                                 |
| 42      | 819 13 13-12        | Washer 13/32 x 13/16 x 12 Ga.                                              |
| 43      | 819 11 10-12        | Washer 11/32 x 5/8 x 12 Ga.                                                |
| 47      | 532 12 77-83        | Pulley, Idler, V Groove Plasic                                             |
| 48      | 532 15 44-07        | Bellcrank Clutch Grnd Drv                                                  |
| 49      | 532 12 32-05        | Retainer, Belt Style Spring                                                |
| 50      | <b>872 11 06-12</b> | Bolt Carr. Sh. 3/8-16 x 1-1/2 Gr. 5                                        |
| 51      | 873 68 06-00        | Nut, Crownlock 3/8-16 UNC                                                  |
| 52      | 873 68 05-00        | Nut Crownlock 5/16-18                                                      |
| 53      | 532 10 57-10        | Link, Clutch 7.66                                                          |
| 55      | 532 10 57-09        | Spring, Return, Clutch                                                     |
| 56      | 817 06 06-20        | Screw 3/8-16 x 1-1/4                                                       |
| 57      | 532 17 01-40        | V-Belt Kev 112" 0650 CRD                                                   |
| 62      | 532 12 48-72        | Cover, Pedal                                                               |
| 65      | 810 04 07-00        | Washer                                                                     |
| 66      | 532 15 47-78        | Keeper, Belt Engine F-Proof                                                |
| 71      | 532 16 91-83        | Strap, Torque, Lh                                                          |
| 73      | 532 16 91-82        | Strap, Torque, Rh                                                          |
| 74      | 532 13 70-57        | Spacer, Split                                                              |
| 75      | 532 12 17-49        | Washer 25/32 x 1-1/4 x 16 Ga.                                              |
| 76      | 812 00 00-01        | Ring, E                                                                    |
| 77      | 532 12 35-83        | Key, Square                                                                |
| 78      | 532 12 17-48        | Washer 25/32 x 1-5/8 x 16 Ga.                                              |
| 81      | 532 17 00-06        | Asm, Shaft                                                                 |
| 82      | 532 16 57-11        | Spring, Torsion                                                            |
| 83      | 819 17 12-16        | Washer 17/32 x 3/4 x 16 Ga.                                                |
| 84      | 532 17 00-07        | Link, Transaxle                                                            |
| 95      | 532 17 00-15        | Control Asm Bypass Hydro                                                   |
| 96      | 532 12 47-88        | Spring, Retainer 1"                                                        |
| 120     | 873 90 06-00        | Nut Lock Flg. 3/8-16 Unc                                                   |

| KEY NO. | PART NO.            | DESCRIPTION                        |
|---------|---------------------|------------------------------------|
| 145     | 874 49 05-44        | Bolt Hex FGHD 5/16-18 x Gr 5       |
| 150     | 532 16 58-50        | Bushing, Bellcrank Grnd Dr         |
| 151     | 819 13 32-10        | Washer 13/32 x 2 x 10 Ga.          |
| 156     | 532 16 60-02        | Washer Srrted 5/16ID x 1.125       |
| 158     | 532 16 55-89        | Bracket Shift Mount                |
| 159     | 532 16 54-94        | Hub Tapered Flange Shift Lt        |
| 160     | 819 29 20-16        | Washer 29/32 x 1-1/4 x 16 Ga.      |
| 161     | 872 14 04-06        | Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5   |
| 162     | 873 68 04-00        | Nut Crownlock 1/4-20 Unc           |
| 163     | 874 78 04-16        | Bolt Hex Fin 1/4-20 Unc x 1 Gr 5   |
| 164     | 819 09 10-10        | Washer 5/8 x .281 x 10 Ga.         |
| 165     | 532 16 56-23        | Bracket Pivot Lever                |
| 166     | 532 16 68-80        | Screw 5/16-18 x 5/8                |
| 167     | 532 16 55-88        | Bracket Support Shift CRD          |
| 168     | 532 16 54-92        | Bolt Shoulder 5/16-18 x .561       |
| 169     | 532 16 55-80        | Plate Fastening Lt                 |
| 171     | 817 49 06-08        | Screw Thdrol 3/8-16 x 1/2 Ty-Tt    |
| 172     | 532 17 02-71        | Shaft Asm Shifter Frt CRD          |
| 177     | 532 16 59-32        | Keeper Flat Idler 3.06" CRD        |
| 178     | 532 16 59-33        | Keeper Belt Idler 1.88" CRD        |
| 179     | 532 12 09-58        | Washer Sintered                    |
| 180     | 532 16 56-30        | Pulley, Idler, Flat 1.88" CRD      |
| 181     | 532 18 02-11        | Bracket Idler Ground Drive CRD     |
| 182     | <b>532 18 26-82</b> | Keeper Belt 2.5" STL V-Idler       |
| 183     | 532 17 90-50        | Pulley V-Idler 2.50" Od CRD        |
| 184     | 817 49 06-44        | Screw Hexwsh Thdrol 3/8-16 x 2-3/4 |
| 185     | 532 17 00-08        | Link Shift                         |
| 186     | 532 16 56-14        | Hub Tapered Round CRD              |
| 187     | 817 58 05-20        | Screw Thdrol 5/16-18 x 1.25        |
| 197     | 532 16 96-13        | Nyliner Snap-In 5/8                |
| 199     | 532 16 96-12        | Bolt Shoulder 5/16-18 Unc          |
| 200     | 872 14 05-08        | Bolt RDHD SQNK 5/16-18 x 1         |
| 202     | 872 11 06-14        | Bolt 3/8-16 x 1-3/4 Gr. 5          |
| 203     | 871 17 07-80        | Bolt Hex 7/16-20 x 5               |
| 207     | 532 16 98-45        | Washer Nylon Rear                  |
| 214     | 532 17 56-09        | Shaft Asm. Brake                   |
| 215     | 532 17 56-52        | Rod Brake Hydro                    |
| 250     | 817 06 06-12        | Screw 3/8-16 x .75                 |
| 253     | 532 17 50-28        | Bracket Cable Chassis              |
| 254     | 817 06 06-16        | Screw 3/8-16 x 1                   |
| 255     | 532 17 56-08        | Brace Shaft Brake Mtg.             |
| 258     | 532 17 80-62        | Clip Retainer                      |
| 259     | 532 18 02-12        | Bracket Pulley Idl Hygrd           |
| 261     | <b>532 13 14-94</b> | Pulley Idler Flt                   |
| 263     | <b>817 00 06-12</b> | Screw Hexwsh Thdrl. 3/8-16 x 3/4   |
| 264     | 532 18 19-95        | Bracket Clutch Mounting            |
| 265     | 532 18 20-13        | Spacer Idler Chassis               |
| 266     | 532 18 20-61        | Shield Idler Mower                 |
| 267     | 872 14 06-26        | Bolt Rdhd 3/8-16unc x 3            |
| 268     | <b>532 18 24-02</b> | Guard Muffler                      |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
STEERING ASSEMBLY



# REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
STEERING ASSEMBLY

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                       |
|------------|--------------|-----------------------------------|
| 1          | 532 17 20-92 | SteeringWheel                     |
| 2          | 532 17 23-93 | Front Axle Assembly               |
| 3          | 532 16 98-40 | Spindle Assembly, L.H.            |
| 4          | 532 16 98-39 | Spindle Assembly, R.H.            |
| 5          | 5321249-31   | Bearing,Race,Thrust,Hardened      |
| 6          | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Gauge   |
| 8          | 812 00 00-29 | Ring, Klip                        |
| 10         | 532 17 51-21 | Link, Drag                        |
| 11         | 810 04 06-00 | Washer, Lock                      |
| 12         | 873 94 08-00 | Nut Hex Jam Toplock 1/2-20 Unf    |
| 13         | 532 13 65-18 | Spacer Axle                       |
| 15         | 532 14 52-12 | Nut Hex Flange Lock               |
| 17         | 532 18 06-41 | Shaft Assembly, Steering          |
| 29         | 817 06 06-12 | Screw 3/8-16 x 3/4                |
| 32         | 532 17 01-62 | Rod, Tie                          |
| 33         | 819 11 12-16 | Washer 11/32 x 3/4 x 16 Ga.       |
| 34         | 810 04 05-00 | Washer Lock Hvy Hlcl Spr 5/16     |
| 35         | 873 54 05-00 | Crownlock Nut 5/16-24 Unf         |
| 36         | 532 15 50-99 | Bushing, Steering                 |
| 37         | 532 15 29-27 | Screw TT #10-32 x 5 x 3/8 Flange  |
| 38         | 532 17 20-93 | Cap Wheel Steer                   |
| 39         | 819 18 24-11 | Washer 9/16 X 1-1/2 11 Ga.        |
| 40         | 532 12 47-01 | Nut Lock Center 3/8-24 Unf        |
| 41         | 532 15 99-45 | Adaptor, Steering Wheel           |
| 42         | 532 16 96-33 | Boot, Steering Dash P/L Mtl       |
| 43         | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Gauge   |
| 44         | 532 18 06-40 | Extension Steering                |
| 46         | 532 12 12-32 | Cap, Spindle                      |
| 51         | 873 54 04-00 | Nut Crownlock 1/4-28              |
| 54         | 871 13 04-20 | Bolt Hex 1/4-28 Unf x 1-1/4 Gr. 8 |
| 65         | 532 16 03-67 | Spacer Axle                       |
| 67         | 872 14 06-18 | Bolt Rdhd Sq 3/8-16 x 2-1/4       |
| 68         | 532 16 98-27 | Brace Axle                        |
| 71         | 532 17 51-46 | Steering Asm.                     |
| 82         | 532 16 98-35 | Bracket Susp. Chassis Front       |
| 87         | 532 17 39-66 | Washer Flat .781 x 1-1/2 x .14    |
| 88         | 532 17 51-18 | Bolt Shoulder 7/16-20 Unc         |
| 91         | 532 17 55-53 | Clip Steering                     |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
SEAT ASSEMBLY




| KEY NO. | PART NO.            | DESCRIPTION                     |
|---------|---------------------|---------------------------------|
| 1       | 532 14 01-18        | Seat                            |
| 2       | 532 14 05-51        | Bracket Pnt Pivot Seat (blk )   |
| 3       | 871 11 06-16        | Bolt Fin Hex 3/8-16 Unc x 1 Blk |
| 4       | 819 13 16-10        | Washer Flat 13/32 x 1 x 10 Ga.  |
| 5       | 532 14 50-06        | Clip Push In Hinged             |
| 6       | 873 80 06-00        | Nut Lock Hex W/Ins. 3/8-16 Unc  |
| 7       | 532 12 41-81        | Spring Seat Cprsn 2 250 Blk Zi  |
| 8       | 817 00 06-16        | Screw 3/8-16 X 1.5              |
| 9       | 819 13 16-14        | Washer 13/32 X 1 X 14 Ga        |
| 10      | <b>532 18 24-93</b> | Pan Pnt Seat (blk )             |
| 11      | 532 16 63-69        | Knob Seat Adj. Wingnut          |
| 12      | 532 12 12-46        | Bracket Pnt Mounting Switch     |

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 13      | 532 12 12-48 | Bushing Snap Blk Nyl 50 Id     |
| 14      | 872 05 04-12 | Bolt Rdhd Sht Nk 1/4-20x1-1/2  |
| 15      | 532 12 12-49 | Spacer Split                   |
| 16      | 532 12 37-40 | Spring Cprsn                   |
| 17      | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr 5 Zinc |
| 21      | 532 17 18-52 | Bolt Shoulder 5/16-18 Unc-2A   |
| 22      | 873 80 05-00 | Nut Hex Lock w/Ins 5/16-18     |
| 24      | 819 17 19-12 | Washer 17/32 X 1-3/16 X 12 Ga. |
| 25      | 532 12 70-18 | Bolt Shoulder 5/16-18 X 62     |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm

# REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
DECALS



| KEY NO. | PART NO.            | DESCRIPTION                   |
|---------|---------------------|-------------------------------|
| 1       | 532 14 54-98        | Decal Read Owner's Manual Sym |
| 2       | 532 18 04-34        | Decal Hp Engine               |
| 3       | <b>532 17 05-33</b> | Decal Hood Rh                 |
| 4       | <b>532 17 05-34</b> | Decal Hood Lh                 |
| 5       | 532 17 05-65        | Decal Steering Wheel          |
| 6       | <b>532 18 04-32</b> | Decal 100 DB/CE               |
| 7       | 532 16 29-27        | Decal Panel Side              |
| 9       | 532 14 17-61        | Decal Fender Logo             |
| 10      | 532 14 50-05        | Decal Bat Dan/Poi P/L Sym Wpn |
| 11      | <b>532 18 21-66</b> | Decal Mower Cut Finger        |
| 12      | 532 15 97-37        | Decal Brake/Clutch Symbol Lt  |
| 13      | 532 15 22-62        | Decal Grille                  |

| KEY NO. | PART NO.     | DESCRIPTION                |
|---------|--------------|----------------------------|
| 14      | 532 15 97-36 | Decal Chassis Hot Muffler  |
| 15      | 532 17 06-54 | Decal Bagger Top           |
| 16      | 532 18 04-35 | Decal Backplate            |
| 17      | 532 14 08-37 | Decal Saddle Brake Parking |
| 20      | 532 16 69-60 | Decal Bypass Fender CRD    |
| 21      | 532 16 62-86 | Decal Hex Belt Sch 92 CRD  |
| —       | 532 13 83-11 | Decal Lift Handle          |
| —       | 532 18 10-90 | Pad Footrest RH            |
| —       | 532 18 10-91 | Pad Footrest LH            |
| —       | 532 18 30-95 | Manual Operator's (Euro)   |
| —       | 532 18 30-96 | Manual Operator's (Scan)   |

## WHEELS & TIRES




| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 05 91-92 | Cap Value Tire                 |
| 2       | 532 06 51-39 | Stem Valve                     |
| 3       | 532 10 62-22 | Tire F Ts 15 X 6 0 - 6 Service |
| 4       | 532 05 99-04 | Tube Inner Front #35060        |
| 5       | 532 13 83-36 | Rim Asm 6"front Silver Service |
| 6       | 532 12 49-57 | Fitting Grease                 |
| 7       | 532 12 49-59 | Bearing Flange                 |
| 8       | 532 13 83-37 | Rim Asm 8"rear Silver Service  |
| 9       | 532 13 84-68 | Tire R Ts 20 x 8-8 Service     |
| 10      | 532 12 49-26 | Tube Rear 9 5 X 8 Service      |
| 11      | 532 17 50-39 | Cap Axle Blk 1 50 X 1 00       |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. tube)    |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
ENGINE



# REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
ENGINE

|     |              |                                                                                                               |
|-----|--------------|---------------------------------------------------------------------------------------------------------------|
| 1   | 532 17 05-51 | Control Throt/Ck                                                                                              |
| 2   | 817 72 04-08 | Screw Hex Thd Cut 1/4-20 x 1/2                                                                                |
| 3   | -----        | Engine B&S Model 31G777<br>(Order parts from engine manufacturer)                                             |
| 4   | 532 13 73-52 | Muffler                                                                                                       |
| 13  | 532 16 52-91 | Gasket Muffler                                                                                                |
| 14  | 532 14 84-56 | Tube Drain Oil Easy                                                                                           |
| 16  | 811 05 06-00 | Washer Lock Ext Tooth 3/8                                                                                     |
| 23  | 532 16 98-37 | Shield Brn/Dbr Guard                                                                                          |
| 25  | 532 18 09-45 | Control Choke                                                                                                 |
| 26  | 873 92 06-00 | Nut Keps 3/8-24 Unf                                                                                           |
| 29  | 532 13 71-80 | Kit Spark Arrestor (Flat Scrn)                                                                                |
| 31  | 532 18 06-45 | Tank Fuel 2.00                                                                                                |
| 32  | 532 14 05-27 | Cap Asm Fuel W/sym Vented  |
| 33  | 532 12 34-87 | Clamp Hose Blk                                                                                                |
| 37  | 532 13 70-40 | Line Fuel                                                                                                     |
| 38  | 532 14 83-15 | Plug Drain Oil Easy                                                                                           |
| 40  | 532 12 40-28 | Bushing Snap                                                                                                  |
| 41  | 532 13 92-77 | Stem Tank Fuel                                                                                                |
| 44  | 817 67 04-12 | Screw Hexwsh thdrol 1/4-20 x 3/4                                                                              |
| 45  | 817 00 06-12 | Screw Hexwsh Thdr 3/8-16 x 3/4                                                                                |
| 46  | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.                                                                                    |
| 62  | 810 04 05-00 | Washer, Lock Hvy. Hlcl Spr 5/16                                                                               |
| 72  | 871 07 05-12 | Screw Hex Hd Cap 5/16-18 x 3/4                                                                                |
| 78  | 817 06 06-20 | Screw 3/8-16 x 1/4                                                                                            |
| 81  | 873 51 04-00 | Nut Keps Hex 1/4-20 Unc                                                                                       |
| 112 | 532 12 49-52 | Bushing                                                                                                       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
MOWER LIFT



# REPAIR PARTS


TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
MOWER LIFT

| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 15 94-60 | Washer Asm Inner Spring W/Plunger |
| 2       | 532 15 94-71 | Shaft Asm. Lift                   |
| 3       | 532 10 57-67 | Pin Groove                        |
| 4       | 812 00 00-02 | E Ring #5133-62                   |
| 5       | 819 21 16-21 | Washer 21/32 x 1 x 21 Ga.         |
| 6       | 532 12 01-83 | BearingNylong                     |
| 7       | 532 12 56-31 | Grip Handle Fluted                |
| 8       | 532 12 45-26 | Button Plunger Black              |
| 11      | 532 16 58-29 | Link Asm Lift L.H.                |
| 12      | 532 16 58-31 | Link Asm Lift R.H.                |
| 13      | 532 12 46-70 | Retainer Spring                   |
| 15      | 532 17 32-88 | Link Front                        |
| 16      | 873 35 08-00 | Nut Jam Hex 1/2-13 Unc            |
| 17      | 532 17 56-89 | Trunnion Blk Zinc                 |
| 18      | 873 80 08-00 | Nut Lock w/wsh 1/2-13 Unc         |
| 19      | 532 13 98-68 | Arm Suspension Mower              |
| 20      | 532 16 35-52 | Retainer Spring                   |
| 23      | 532 11 08-07 | Nut Special                       |
| 24      | 819 13 10-16 | Washer 13/32 x 5/8 x 16 Ga.       |
| 25      | 532 12 48-74 | Spring 2-1/8"                     |
| 26      | 532 16 94-84 | RetainerClip                      |
| 27      | 532 12 69-71 | Rod Adj Lift Zinc 7.49 Wrk Lg     |
| 28      | 873 35 06-00 | Nut Hex Jam 3/8-16 Unc            |
| 29      | 532 13 80-57 | Knob Inf 3/8-16 Unc Blk w/sym     |
| 30      | 532 15 02-33 | Trunnion Infin Height             |
| 31      | 532 16 98-65 | Bearing, Pvt. Lift.               |
| 32      | 873 54 06-00 | Nut Crownlock 3/8-24              |
| 36      | 532 15 50-97 | Pointer Height Indicator          |
| 37      | 532 12 39-35 | Plug Hole Blk 1.485/1.515 Dia     |
| 38      | 817 06 05-16 | Screw 5/16-18 x 1                 |
| 40      | 819 11 24-10 | Washer 11/32 x 1-1/2 x 10 Ga.     |
| 41      | 532 12 39-34 | Scale Ind Height Blk              |
| 49      | 532 14 52-12 | Nut hex Flange Lock               |
| 50      | 532 11 04-52 | Nut Push Phos & Oil               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
MOWER



# REPAIR PARTS


**TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66**  
**MOWER**

| KEY NO. | PART NO.     | DESCRIPTION                       | KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|-----------------------------------|---------|--------------|---------------------------------|
| 1       | 532 16 55-52 | Housing Asm. Mower                | 44      | 532 17 55-38 | Cover Mandrel Lh                |
| 2       | 872 14 05-06 | Bolt Rdhd Sqnk 5/16-18 Unc x 3/4  | 45      | 532 17 55-39 | Cover Mandrel Rh                |
| 3       | 532 16 55-69 | Bracket Asm. S-Bar Chass          | 46      | 532 13 77-29 | Screw Thd Roll 1/4-20 x 5/8     |
| 4       | 532 16 55-58 | Bracket Bar Sway Deck             | 55      | 532 16 54-45 | Arm Idler                       |
| 5       | 532 12 46-70 | Retainer Spring                   | 56      | 532 16 57-23 | Spacer Retainer Mower           |
| 6       | 532 16 55-57 | Bar Sway                          | 61      | 532 16 59-45 | Spring Tension Belt             |
| 8       | 532 18 17-12 | Bolt 3/8-24 x 1.25 Gr8 Patched    | 67      | 532 10 69-32 | Knob                            |
| 9       | 810 03 06-00 | Washer Lock Hvy 3/8 Unplated      | 68      | 532 18 02-17 | Hex-Belt                        |
| 10      | 532 14 02-96 | Washer Hard Blade Mower vented    | 69      | 532 16 54-82 | Shaft Asm W/Lwr Brg Rh Thd CRD  |
| 11      | 532 17 00-37 | Blade 3-1 Lh                      | 84      | 532 15 60-85 | Keeper Belt Idler               |
| 13      | 532 13 76-45 | Shaft Asm. W/Lower Bearing        | 116     | 532 13 76-44 | Bolt Shoulder                   |
| 14      | 532 12 87-74 | Housing Mandrel Vented (Machd)    | 117     | 532 13 39-57 | Wheel Gage Donut Wide           |
| 15      | 532 11 04-85 | Bearing Ball Mandrel              | 118     | 873 93 06-00 | Nut Centerlock 3/8-16 Unc       |
| 16      | 532 17 00-38 | Blade 3-1 Rh                      | 119     | 819 12 14-14 | Washer 3/8 x 7/8 x 14 Ga.       |
| 17      | 872 14 06-10 | Bolt Carriage 3/8-16 x 1-1/4      | 124     | 872 11 06-12 | Bolt Carr Sh 3/8-16 x 1-1/2 Gr5 |
| 18      | 872 11 06-08 | Bolt Rdhd Sqnk 3/8-16 x 1 Gr5     | 130     | 872 11 05-06 | Bolt Rdhdsqnk 5/16-18 Unc x 3/4 |
| 19      | 532 13 28-27 | Bolt Shoulder 5/16-18 Thd Form    | 131     | 532 16 56-61 | Chute Bagger CRD 92cm           |
| 20      | 532 18 17-13 | Bolt 3/8-24 x 1.25 Gr8 Ptch Lhthd | 151     | 532 16 96-70 | Bracket Clutch Cable            |
| 21      | 873 68 05-00 | Nut Crown Lock 5/16-18            | 152     | 532 17 60-74 | Cable Clutch                    |
| 22      | 532 16 52-43 | Bracket Idler Sprt RR             | 153     | 532 16 96-74 | Washer Flat                     |
| 23      | 532 16 54-46 | Bracket Idler Sprt RF             | 154     | 532 16 96-75 | Spring Retainer                 |
| 24      | 532 16 52-42 | Bracket Suspension LF             | 155     | 532 16 96-71 | Spring Retention Lever Clutch   |
| 25      | 532 16 52-44 | Bracket Suspension RF             | 156     | 532 16 96-72 | Spacer Clutch Cable             |
| 26      | 532 16 52-37 | Brace Support Susp Frt            | 157     | 532 16 96-69 | Rod Clutch Cable                |
| 27      | 532 16 55-68 | Bracket Asm. Susp RR              | 158     | 817 72 04-08 | Screw Thd Cut 1/4-20 x 1/2      |
| 28      | 532 16 55-67 | Bracket Asm. Susp LR              | 161     | 532 18 04-18 | Blade Cross LH                  |
| 30      | 532 17 39-84 | Screw Thd Rolling                 | 162     | 532 18 04-20 | Adapter                         |
| 31      | 532 12 99-63 | Washer Spacer Mower Vented        | 163     | 532 18 04-19 | Blade Cross RH                  |
| 32      | 532 15 35-31 | Mandrel Pulleys                   | -       | 532 18 18-57 | Mandrel Asm Service             |
| 33      | 532 17 83-42 | Nut Flg Top Lock                  | -       | 532 18 18-58 | Mandrel Asm CRD Lh Threads SVC  |
| 34      | 532 16 52-39 | Bracket Gauge Wheel Lf            | -       | 532 18 17-65 | Replacement Mower Complete      |
| 35      | 532 16 52-38 | Bracket Gauge Wheel Rf            |         |              |                                 |
| 36      | 532 14 67-63 | Pulley Idler V-Groove Dim 4.25    |         |              |                                 |
| 37      | 819 13 13-16 | Washer 11/32 x 13/16 x 16 Ga      |         |              |                                 |
| 40      | 873 68 06-00 | Nut Crownlock 3/8-16 Unc          |         |              |                                 |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
BAGGER



# REPAIR PARTS

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
BAGGER

| KEY NO. | PART NO.            | DESCRIPTION                           |
|---------|---------------------|---------------------------------------|
| 1       | 532 16 52-49        | Tube Handle Bagger CRD                |
| 2       | 872 14 04-16        | Bolt Carriage 1/4-20 x 2.0 Gr.5       |
| 3       | 532 12 39-76        | Nut Lock 1/4 Lge Flg Gr. 5 Zinc       |
| 4       | 532 16 99-16        | Handle Bagger w/Lvrs Blk CRD          |
| 5       | 874 98 10-24        | Screw Pan Head #10-24 x 1.50 Blk      |
| 6       | 874 98 10-32        | Screw Pan Hd                          |
| 7       | 873 40 10-00        | Nut Wiz Lock Hex Serr/Hd 10-24        |
| 8       | 532 18 13-54        | Cover Bagger                          |
| 9       | 872 14 04-18        | Bolt Carriage 1/4-20 x 2.25d x Gr.5   |
| 10      | 532 18 12-82        | Tube Support Bagger CRD               |
| 11      | 532 16 57-19        | Bracket Support Upper Bag CRD         |
| 12      | 532 16 96-85        | Bracket Horiz Adj Bagger Lh           |
| 13      | 872 11 06-06        | Bolt Rdhd Sht Sqnk 3/8-16 x 3/4       |
| 14      | <b>874 52 06-36</b> | Bolt Fin Hex 3/8-16 x 2-1/4 Gr. 5     |
| 15      | 532 12 46-70        | Retainer Spring                       |
| 16      | 873 90 06-00        | Nut Lock Flg 3/8-16 Unc               |
| 17      | 872 14 05-06        | Bolt Rdhd Sht Sqnk 5/16 -18 Unc x 3/4 |
| 18      | 819 11 12-16        | Washer 11/32 x 3/4 x 16 Ga. ®         |
| 19      | 873 90 05-00        | Nut Lock Hex Flange 5/16-18           |
| 20      | 532 16 96-84        | Bracket Horiz Adj Bagger Rh           |
| 21      | <b>532 18 08-80</b> | Bag Asm CRD                           |
| 22      | 532 16 57-81        | Bracket Side Bagger CRD               |
| 23      | 532 16 57-82        | Tube Upper Bagger CRD                 |
| 24      | 532 16 57-83        | Tube Pivot Bagger CRD                 |
| 25      | 532 18 01-24        | Tube Front Bagger CRD                 |
| 26      | 532 16 57-85        | Tube Lower Bagger CRD                 |
| 28      | 532 16 57-87        | Grip Handle Black                     |
| 31      | 532 12 47-88        | Retainer Spring 1" Zinc/Cad           |
| 32      | 532 12 68-75        | Rivet Rd Hd Drilled 3/8 Dia           |
| 33      | 532 16 55-71        | Plug Mulcher                          |
| 34      | 532 16 55-70        | Handle Mulcher                        |
| 35      | 532 16 55-72        | Pin Mulcher                           |
| 36      | 819 13 20-16        | Washer 13/32 x 1-1/4 x 16 Ga.         |
| 37      | 532 17 54-01        | Plug Support Bagger CRD               |
| 38      | 872 01 05-20        | Bolt 5/16-18 x 2-1/2                  |
| 39      | 532 18 09-85        | Seal Trim                             |
| 41      | 532 16 96-83        | Bracket Pnt Adj Pvt Bagger CRD        |
| 42      | 873 80 05-00        | Nut Crownlock 5/16-18 Blk CRD         |
| 43      | <b>532 17 40-83</b> | Plug Tubing End                       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR- -MODEL NO. ICT16A (JICTH16K), PRODUCT NO. 954 13 00-66  
SCHEMATIC

