

LR122, 954140014A, 1998-08




The logo for CPL, consisting of the letters 'CPL' in a stylized, bold, sans-serif font. A registered trademark symbol (®) is located to the upper right of the 'L'.

SPARE PARTS LIST

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

SEAT




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	872050412	BOLT		1	
2	532140838	SEAT		1	
3	532155925	BRACKET		1	
4	873800500	LOCK NUT		1	
5	532153236	SCREW		1	
6	532145006	CLIP		1	
8	874760616	BOLT		1	
9	532140551	BRACKET		1	
11	819133210	WASHER		1	
12	873800600	NUT		1	
13	874780814	BOLT		1	
14	810040800	WASHER		1	
15	819171912	WASHER		1	
16	532127018	BOLT		1	
17	532121246	BRACKET		1	
18	532123976	LOCKNUT		1	
19	532121248	BUSHING		1	
20	532121250	SPRING		1	
21	532134300	SPACER		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

SECTOR GEAR / AXLE SUPPORT




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532132566	LINK		1	
2	874780828	BOLT		1	
3	873680500	NUT		1	
4	873680600	NUT		1	
5	532121926	GEAR RIM		1	
6	532121927	BUSHING		1	
7	873030800	NUT		1	
8	532126472	CLIP		1	
9	873680800	NUT		1	
10	876020412	SPLIT PIN		1	
11	819131316	WASHER		1	
12	532126847	BUSHING		1	
13	874760512	BOLT		1	
14	819111416	WASHER		1	
15	872110606	BOLT		1	
16	532137096	SUPPORT		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

HOOD




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
6	532140051	BRACKET		1	
7	532140050	BRACKET		1	
10	532130850	BRACE		1	
11	532165791	HOOD		1	
12	532165794	LENS		1	
13	532165792	GRILL		1	
17	874780410	BOLT		1	
20	819091016	WASHER		1	
21	532126938	DAMPER		1	
22	532165793	LENS		1	
23	532139969	LATCH		1	
24	532142873	BRACKET		1	
25	532131028	CLIP		1	
26	532052921	CLIP		1	
27	532131037	CLIP		1	
28	811050400	WASHER		1	
29	532120537	SEALING		1	
32	532123840	AIR INTAKE		1	
33	532131319	PLUG		1	
34	873680400	NUT		1	
35	817490512	SCREW		1	
36	532128445	BRACKET		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

DECALS




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
3	532150616	DECAL		1	
7	532137259	DECAL		1	
8	532150617	DECAL		1	
13	532145005	DECAL		1	
16	532136830	DECAL		1	
--	532138311	DECAL		1	



REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

BRAKE / REAR MOWER LIFT ASSEMBLY




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532071673	COVER		1	
2	532123436	ROD		1	
3	532123437	HOLDER		1	
4	532008156	PEDAL RUBBER		1	
5	532122504	HOLDER		1	
6	876020312	SPLIT PIN		1	
7	819131016	WASHER		1	
8	817490508	SCREW		1	
9	876020412	SPLIT PIN		1	
10	819131316	WASHER		1	
11	532123543	ROD		1	
12	532139933	PEDAL CPL.		1	
13	532123394	ROD		1	
14	532121978	HOLDER		1	
15	532133332	LEVER		1	
16	819251816	WASHER		1	
17	812000034	RETAINER RING		1	
18	532151332	SPRING		1	
19	873350600	NUT		1	
20	873800600	NUT		1	
21	532131460	ROD		1	
22	532144585	BRACKET		1	
24	819132012	WASHER		1	
25	532124961	CLIP		1	
26	873930600	NUT		1	
27	532127369	LINK		1	
28	532140776	SUPPORT, REAR		1	
29	872110506	BOLT		1	
30	873510500	NUT		1	
31	532124660	CIRCLIP		1	
34	873680600	NUT		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

WHEELS & TIRES




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532059192	CAP VALVE		1	
2	532065139	NIPPLE		1	
3	532124957	FITTING		1	
4	532123410	TIRE		1	
4	532106230	TIRE		1	
5	532059904	HOSE		1	
5	532008134	HOSE		1	
6	532142039	RIM, FRONT		1	
6	532141652	RIM, REAR		1	
7	532104757	HUB CAP		1	
8	532124959	BEARING		1	
9	532121748	WASHER		1	
--	532144334	SEALING FOAM		1	



REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

FRONT AXLE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532121232	HUB CAP		1	
2	812000029	RETAINER RING		1	
3	532121748	WASHER		1	
4	532124937	BEARING COL. STRG.		1	
5	532142033	AXLE		1	
6	532124931	WASHER		1	
7	532161826	SPINDLE		1	
8	532121749	WASHER		1	
9	876020412	SPLIT PIN		1	
10	819131316	WASHER		1	
11	532126847	BUSHING		1	
12	532130465	ROD		1	
13	532161827	SPINDLE		1	
14	874011056	BOLT		1	
15	873901000	NUT		1	
16	532110438	SPACER		1	
17	532124836	NIPPLE		1	
18	819272016	WASHER		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

DASH




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532142187	TANK CAP		1	
2	532138394	FUEL TANK		1	
3	532123487	HOSE CLAMP		1	
4	532008544	LINE FUEL LT 10/36		1	
5	532008548	HOSE		1	
6	873640400	NUT		1	
7	532124996	CLIP		1	
8	819091216	WASHER		1	
9	874760428	BOLT		1	
10	819091413	WASHER		1	
11	532121249	SPACER		1	
12	532003720	SPRING		1	
13	532126450	CLIP		1	
14	532126115	KNOB		1	
15	532122023	SEGMENT		1	
16	532124346	NUT		1	
17	872110404	BOLT		1	
18	532130745	BRACKET		1	
19	532134744	CROSS BRACE		1	
20	817060408	SCREW		1	
21	532134014	PLUG		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

ELECTRICAL




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	873640400	NUT		1	
2	532108423	CABLE ASSY		1	
3	532144924	BATTERY		1	
4	532069180	NUT		1	
5	532108236	BRACKET		1	
6	532109553	SWITCH		1	
7	532146374	HOLDER		1	
8	817021008	SCREW		1	
9	532140402	KEY		1	
10	532141226	COVER		1	
11	532140400	NUT		1	
12	532163088	IGNITION SWITCH		1	
15	532121305	SWITCH		1	
17	532108824	FUSE		1	
18	532128353	CABLE ASSY		1	
19	532146063	HARNESS		1	
20	873350400	NUT		1	
21	810090400	WASHER		1	
22	871110408	BOLT		1	
24	532131563	COVER		1	
25	532145673	SOLENOID		1	
26	874760412	BOLT		1	
27	819091016	WASHER		1	
28	810040400	WASHER		1	
30	873220400	NUT		1	
36	811150400	LOCKWASHER		1	
39	532141735	BRACKET		1	
55	817490508	SCREW		1	
70	532140413	HARNESS		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

DANA TRANSAXLE MODEL NUMBER 4360-119




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532123385	PULLEY		1	
2	812000028	CLIP		1	
4	532125096	WOODRUFF KEY		1	
5	873680500	NUT		1	
6	872140506	BOLT		1	
7	532123378	HOLDER		1	
8	817490512	SCREW		1	
9	532146682	SPRING		1	
10	532121749	WASHER		1	
11	532123583	KEY		1	
12	874760644	BOLT		1	
15	819171616	WASHER		1	
16	532124600	BRACKET		1	
17	532123632	LINK		1	
18	874550412	BOLT		1	
19	810040400	WASHER		1	
20	819091210	WASHER		1	
21	532123484	ARM		1	
22	532105701	WASHER		1	
23	532106933	KNOB		1	
24	532128215	GEAR LEVER		1	
25	876020416	SPLIT PIN		1	
26	873810500	NUT		1	
28	532128085	SPRING		1	
29	532128084	BRACKET		1	
31	532109502	SPACER		1	
33	873680600	NUT		1	
35	812000001	RETAINER RING		1	
36	817720408	SCREW		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

TRANSAXLE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
11	134793	BEILAGSCHEIBENSATZ LR120		1	
12	148268	FLANGE		1	
14	142674	WEDGE		1	
22	138236	ZIEHKEIL 1PAAR		1	
24	142676	GETRIEBEWELLE LR120		1	
29	142677	GEAR WHEEL		1	
33	134796	GEAR WHEEL		1	
34	134797	SPACING BLOCK		1	
43	134394	BEILAGSCHEIBENSATZ LR120		1	
45	142678	GEAR WHEEL		1	
52	134401	SEALING RING		1	
61	142680	GETRIEBEGEH[USEUNTERTEIL LR120		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

MOWER DECK




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532140064	SPRING		1	
2	532122052	SPACER		1	
3	873680600	NUT		1	
4	532130840	BRAKE LEVER		1	
5	532131251	BELT GUIDE		1	
6	532121316	PULLEY		1	
7	872110616	BOLT		1	
8	819131410	WASHER		1	
9	532127744	IDLE ARM ASSY LT10/36D		1	
10	872140610	BOLT		1	
11	532130841	ARM		1	
12	532127356	BRACKET		1	
13	872140506	BOLT		1	
14	873680500	NUT		1	
15	532127357	BRACKET		1	
16	532153298	HOLDER		1	
17	532128508	SUPPORT		1	
18	532128511	PIN RETAINING SCREW		1	
19	532127380	BRACKET		1	
20	532140101	RIDE ON BLADE		1	
21	532140296	WASHER		1	
22	810030600	WASHER		1	
23	532850857	BOLT		1	
24	532140329	STRIPPER		1	
25	532157722	SCREW		1	
27	532156600	HOUSING		1	
28	532153531	PULLEY		1	
29	532137266	NUT		1	
30	532136631	BRACKET		1	
31	817490508	SCREW		1	
32	532122051	HOLDER		1	
33	532131560	GUARD DISCHARGE LT10/36D		1	
34	532160793	LATCH		1	
35	532125004	NUT		1	
36	532121980	ROD		1	
37	532123713	SPRING		1	
38	532105304	HUB CAP		1	
39	819111016	WASHER		1	
40	532110452	NUT		1	
41	532131264	BELT		1	
42	819171616	WASHER		1	
43	532124660	CIRCLIP		1	
44	532140608	HOLDER		1	
45	532110485	BEARING		1	
46	532128774	BEARING HOUSING		1	
47	532129895	BEARING		1	
48	532137645	SHAFT		1	
49	532133943	WASHER		1	
55	810071000	WASHER		1	
56	871161010	SCREW		1	
57	874930516	SCREW		1	
58	873800500	LOCK NUT		1	
59	532133841	ACORN NUT		1	
60	532140102	PLATE		1	
61	819061216	WASHER		1	
62	532153390	GASKET		1	
--	532130794	MANDREL		1	
--	532156866	HOUSING		1	

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

MOWER LIFT LEVER




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532126470	CLIP		1	
2	532122018	HOLDER		1	
3	871110408	BOLT		1	
4	873680600	NUT		1	
5	532145187	CONTROL		1	
6	532106451	BOLT		1	
7	532135371	LEVER		1	
8	874760636	BOLT		1	
9	532121930	LINK		1	
10	876020412	SPLIT PIN		1	
11	819131316	WASHER		1	
12	532131861	HANDLE		1	
13	532139352	LIFT HANDLE		1	
14	532123496	SPRING		1	
15	819131212	WASHER		1	
16	532124961	CLIP		1	
17	532127359	LINK		1	
18	532142028	BRACKET		1	
19	873640400	NUT		1	
20	874760644	BOLT		1	
23	876020416	SPLIT PIN		1	
24	819171612	WASHER		1	
25	532121933	SPACER		1	
26	532141470	ROD		1	
27	532106932	KNOB		1	
28	876020312	SPLIT PIN		1	
29	532131655	LINK		1	
30	873350600	NUT		1	
31	819132012	WASHER		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

GROUND DRIVE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	873680500	NUT		1	
2	874760512	BOLT		1	
3	532141342	KEEPER		1	
4	532138029	PULLEY		1	
5	810040700	WASHER		1	
6	871170744	BOLT		1	
7	532124525	BELT		1	
8	532123405	BELT GUIDE		1	
9	872140612	BOLT		1	
10	532123396	BELT GUIDE		1	
11	532150926	LEVER		1	
12	532123674	PULLEY		1	
13	819131316	WASHER		1	
14	873930600	NUT		1	
15	873680600	NUT		1	
16	532126471	CLIP		1	
17	532150932	SPACER		1	
18	532131459	SPRING		1	
19	873510500	NUT		1	
20	532139919	KEEPER		1	
21	819111016	WASHER		1	
22	532123404	BELT GUIDE		1	
23	532140916	BELT GUIDE		1	
24	817720408	SCREW		1	
25	532150935	BUSHING		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

STEERING WHEEL




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532124416	INSERT		1	
2	810040600	WASHER		1	
3	819133808	WASHER		1	
4	532124415	STEERING WHEEL		1	
5	532127396	SLEEVE		1	
6	532152927	SCREW		1	
7	532155104	BUSHING		1	
8	532147391	ROD		1	
9	532124210	CLIP		1	
10	532123438	BUSHING		1	
11	812000045	RETAINER RING		1	
12	819211616	WASHER		1	
13	532100711	ADAPTER		1	
14	532153720	STEERING PINION		1	
15	874780520	BOLT		1	
16	873800500	LOCK NUT		1	
17	874780616	BOLT		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

ENGINE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	817060408	SCREW		1	
2	532132752	THROTTLE TRIGGER		1	
4	871070512	BOLT		1	
5	810040500	WASHER		1	
6	532165291	GASKET		1	
7	811050600	WASHER		1	
9	819101216	WASHER		1	
10	810040400	WASHER		1	
12	532137437	MUFFLER		1	
13	532101326	DEFLECTOR		1	
14	817030808	SCREW		1	
15	532137180	SPARK ARRESTER KIT		1	
17	817490624	SCREW		1	
39	532128861	NUT		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NUMBER LR122 (954140014A)

FENDER / CHASSIS



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532156417	BOX		1	
2	819132012	WASHER		1	
3	817490612	SCREW		1	
4	532124181	SPRING		1	
5	532125142	PLATE		1	
7	532124144	MAT		1	
8	817490512	SCREW		1	
9	532126993	BRACKET		1	
10	532139783	BAR		1	
11	532124346	NUT		1	
12	532145190	FRAME		1	
15	873640400	NUT		1	
16	532141736	SWITCH		1	
17	532140782	DRAWBAR		1	
18	532126470	CLIP		1	
19	532141393	COVER		1	
20	819091413	WASHER		1	
25	817190516	SCREW		1	

GPL®