

LRH130

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar

GPL®

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

ELECTRICAL



REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

ELECTRICAL


KEY NO.	PART NO.	DESCRIPTION
1	873640400	Nut, Hex, Keps 1/4-20
2	532108423	Assembly, Cable
3	532144924	Battery
4	532069180	Nut Lock #10-24 UNC
5	532108236	Bracket, Switch
6	532109553	Switch, Interlock, 4 Terminal
7	532146374	Keeper Actuator
8	817021008	Screw, Hex Head, Tapping #10-24 x 1/2
9	532140401	Key, Steel Delta
10	532141226	Cover, Ignition Key
11	532140400	Nut, Ignition
12	532163088	Switch, Ignition
15	532121305	Switch, Plunger
17	532166180	Fuse
18	532128353	Assembly, Cable
19	532166144	Harness, Ignition
20	873350400	Nut, Hex, Jam 1/4-20
21	810090400	Washer, Lock 1/4
22	871110408	Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5
24	532131563	Cover, Terminal
25	532145673	Solenoid
26	874760412	Bolt, Hex Head 1/4-20 UNC x 3/4
30	873510400	Nut, Hex, Keps 1/4-20 UNC
31	532004152	Bulb, Light #1156
32	532169985	Harness, Headlight
33	532110712	Switch, Light
36	811150400	Washer, Lock, Internal Tooth 1/4
39	532141735	Bracket, Switch Clutch
55	817490508	Screw, Thdrol 5/16-18 x 1/2
70	532166658	Harness, Engine

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

HOOD



KEY NO.	PART NO.	DESCRIPTION
6	532140051	Bracket, Asm. Pivot Hood RH
7	532140050	Bracket, Asm. Pivot Hood LH
10	532130850	Brace, Hood
11	532165791	Hood
12	532165794	Lens, LH
13	532165792	Grille
17	874780410	Bolt, Fin Hex 1/4-20 x 5/8
20	819091016	Washer, Flat 1/4
21	532126938	Bumper, Hood


KEY NO.	PART NO.	DESCRIPTION
22	532165793	Lens, RH
23	532139969	Latch, Hood
24	532142873	Bracket, Pivot Hood RH
26	532052921	Clip, Tinnerman
28	811050400	Washer, Lock, Ext. Tooth
34	873680400	Nut, Crownlock 1/4-20
35	817490512	Screw, Thdrol 5/16-28 x 3/4
36	532128445	Bracket, Pivot Hood LH

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

FENDER/CHASSIS




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532156417	Case, Battery	12	532145190	Assembly, Frame
2	819132012	Washer 13/32 x 1-1/4 x 12 Ga.	15	873640400	Nut, Keps 1/4-20 UNC
3	817490612	Screw, Hex Wsh. Thrdrol 3/8-16 x 3/4	16	532141736	Switch, Actuator
4	532124181	Spring, Compression, Seat	17	532140782	Drawbar
5	532125142	Plate, Asm. Battery	18	532126470	Clip, Insulated
7	532126700	Pad, Footrest	19	532141393	Fender/Footrest
8	817060512	Screw 5/16-18 x 3/4	20	819091413	Washer 9/32 x 7/8 x 13 Ga.
9	532166614	Console, Shift Control	25	817060514	Screw Tapping 5/16-18 UNC
11	532124346	Nut, Self-Threading, Wsher Hd 3/16	33	817190516	Screw, Hex. S.T. 5/16-18 UNC x 1

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

SEAT



KEY NO.	PART NO.	DESCRIPTION
---------	----------	-------------

1	872050412	Bolt, Carriage 1/4-20 x 1-1/2
2	532140838	Seat
3	532155925	Pan, Seat
4	873800500	Nut, Lock, Hex. w/Ins. 5/16-18
5	532153236	Bolt, Shoulder 5/16-18 UNC
6	532145006	Clip, Push-in, Hinged
7	532166369	Knob, Seat
8	874760616	Bolt, Fin. Hex. 3/8-16 UNC x 1
9	532140551	Bracket, Pivot Seat

KEY NO.	PART NO.	DESCRIPTION
---------	----------	-------------


11	819133210	Washer 12/32 x 2 x 10 Ga.
12	873800600	Nut, Lock Hex w/Wsh 3/8-16
15	819171912	Washer, 17/32 x 1-3/16 x 12 Ga.
16	532127018	Bolt, Shoulder
17	532121246	Bracket, Switch Mounting
18	532123976	Nut, Lock, Hex. Large Flange
19	532121248	Bushing, Snap
20	532121250	Spring, Compression
21	532134300	Spacer, Split 28 Id. x .88 Lg.

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

DASH




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532142187	Cap, Fuel	12	532003720	Spring
2	532138395	Assembly, Dash & Fuel Tank	13	532126450	Clip, Height Adjustment
3	532123487	Clamp, Hose	14	532126115	Knob, Height Stop
4	532008544	Line, Fuel	15	532122023	Adjustment, Quadrant Height
5	532008548	Line, Fuel	16	532124346	Nut, Self-Threading 3/16-18
6	873640400	Nut, Hex, Keps 1/4-20	17	872110404	Bolt, Carriage 1/4-20 x 1/2 Gr. 5
7	532124996	Clip, Fuel Line	18	532130745	Support, Assembly Dash
8	819091216	Washer 9/32 x 3/4 x 16 Ga.	19	532134744	Brace, Cross
9	874760428	Bolt, Hex, Fin 1/4-20 x 1-3/4	20	817060408	Screw, Self-Tapping 1/4-20 x 1/2
10	819091413	Washer 11/32 x 11/16 x 16 Ga.	21	532134014	Plug, Dome, Black
11	532121249	Spacer, Split	25	817720410	Screw Hex Thd Cut 1/4-20 x 5/8

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

STEERING WHEEL




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532124416	Insert, Wheel, Steering	10	532123438	Bushing, Lower, Steering
2	810040600	Washer, Lock Hvy Hlcl	11	812000045	Ring, Retaining
3	819133812	Washer 13/32 x 2-3/8 x 12 Ga.	12	819211616	Washer 21/32 x 1 x 16 Ga.
4	532124415	Wheel, Steering	13	532100711	Adaptor, Wheel, Steering
5	532127396	Sleeve, Steering	14	532153720	Extension Shaft Steering
6	532152927	Screw, TT #10-32 x 5 x 3/8 Flange	15	874780520	Bolt, Fin Hex
7	532155104	Bushing, Steering			5/116-18 UNC x 1-1/4
8	532147391	Shaft, Steering	16	873800500	Nut Lock Hex w/Ins 5/16-18 UNC
9	532124210	Clip, Steering	17	874780616	Bolt Fin Hex 3/8-16unc x 1

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

SECTOR GEAR/AXLE SUPPORT




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532132566	Link, Drag	9	873680800	Nut, Crownlock 3/8-16
2	874780828	Bolt, Fin Hex 1/2-13 x 1-3/4	10	876020412	Pin, Cotter 1/8 x 3/4
3	873680500	Nut, Crownlock 5/16-18	11	819131316	Washer, 13/32 x 13/16 x 16 Ga.
4	873680600	Nut, Crownlock 3/8-16	12	532126847	Bushing
5	532121926	Gear, Sector	13	874760512	Bolt, Hex Hd. 5/16-18 UNC x 3/4
6	532121927	Bushing	14	819111416	Washer 11/32 x 7/8 x 16 Ga.
7	873030800	Nut, Heavy Hex Top Lock 1/2-13 UNC	15	872110606	Bolt, Carriage 3/8-16 UNC x 3/4
8	532126472	Clip, Insulated	16	532137096	Support, Front Axle

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

FRONT AXLE




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532121232	Cap, Spindle	10	819131316	Washer 13/32 x 13/16 x 16 Ga.
2	812000029	Ring, Clip	11	532126847	Bushing
3	532121748	Washer 25/32 x 1-5/8 x 16 Ga.	12	532130465	Rod, Tie
4	532124937	Nyliner	13	532161827	Spindle, L.H. Asm.
5	532142033	Axle, Front	14	874011056	Bolt Hex 5/1-11 x 3-1/2
6	532124931	Bearing, Thrust	15	873901000	Nut, Lock Flange 5/8-11
7	532161826	Spindle, R.H. Asm.	16	532110438	Spacer Bearing Axle
8	532121749	Washer 25/32 x 1-1/4 x 16 Ga.	17	532124836	Fitting Grease
9	876020412	Pin, Cotter 1/8 x 3/4	18	819272016	Washer 27/32 x 1-1/4 x 16 Ga.

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

BRAKE / REAR MOWER LIFT ASSEMBLY




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532071673	Cap, Plunger	16	819251816	Washer 25/32 x 1-1/8 x 16 Ga.
2	532123436	Rod, Parking Brake	17	812000034	Ring, Klip
3	532123437	Bracket, Parking Brake	18	532151332	Spring, Brake Rod
4	532008156	Cover, Pedal	19	873350600	Nut, Hex, Jam 3/8-16 UNC
5	532122504	Bracket, Clutch/Brake Pedal, L.H.	20	873800600	Nut Lock Hex w/Ins. 3/18-16 UNC
6	876020312	Pin, Cotter 3/32 x 3/4	21	532144413	Rod, Brake
7	819131016	Washer 13/32 x 5/8 x 16 Ga.	22	532144585	Trunnion, Lift
8	817490508	Screw, Hex. Thdrol. 5/16-18 x 1/2	24	819132012	Washer 13/32 x 1-1/4 x 12 Ga.
9	876020412	Pin, Cotter 1/8 x 3/4	25	532124961	Retainer, Spring
10	819131316	Washer 13/32 x 13/16 x 16 Ga.	26	873930600	Nut, Centerlock 3/8-16 UNC
11	532123543	Rod, Brake, Front	27	532127369	Link, Threaded
12	532139933	Assembly, Clutch/Brake	28	532140776	Assembly, Rear Mower Lift
13	532123394	Rod, Clutch	29	872110506	Bolt, Carriage 5/16-18 UNC x 3/4
14	532121978	Bracket, Lift Shaft	30	873510500	Nut, Keps 5/16-16 UNC
15	532133332	Assembly, Brake Pivot Arm	31	532124660	Retainer, Spring, Zinc
			34	873680600	Nut, Crownlock 3/16-18

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

ENGINE




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	817720410	Screw, Hex, Thd. Cut 1/4-20 x 5/8	11	-----	Screw (Order from Engine Mfg.)
2	532132752	Control, Throttle	12	532137437	Muffler
3	-----	Engine Briggs Model 28R707 (Order parts from engine manufacturer)	13	532101326	Deflector, Muffler
4	871070512	Screw, Hex. Hd. Cap 5/16-18 x 3/4	14	817030808	Screw, Spiderloc, Hex Hd. #8 x 1/2
5	810040500	Washer, Lock, Heavy Helical Spring 5/16	15	532137180	Arrester, Spark (Optional equipment)
6	532165291	Gasket, Exhaust	16	532127951	Stop, Throttle
7	811050600	Washer, Lock Ext. Tooth 3/8	17	817490624	Screw, Hex Washer Head, Thdrol. 3/8-16 x 1-1/2
9	819101216	Washer 5/16 x 3/4 x 16	18	873510600	Nut, Keps Hex 3/8-16 UNC
10	810040400	Washer, Lock, Heavy Helical Spring 1/4	19	532124996	Clip, Fuel Line
			39	532128861	Nut, Flange 1/4-20

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

GROUND DRIVE




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	873800500	Nut, Lock, Hex. w/Ins. 5/16-18	17	532150932	Spacer, Retainer
2	874760512	Bolt, Hex. Hd 5/16-18 x 3/4	18	532131459	Spring, Extension
3	532141297	Keeper, Belt, Mower Drive, R. H.	20	532140909	Keeper, Belt, L.H.
4	532138029	Pulley, Engine	22	532123404	Keeper, Belt, Frame, Ground Drive
5	810040700	Washer, Lock 7/16	23	532140916	Keeper, Belt, Front, L. H.
6	871170744	Bolt, Hex., 7/16-20 Gr.5	24	817720408	Screw, Thd. Cut 1/4-20 x 1/2
7	532140910	Traction, V-Belt Drive	25	532150935	Bushing, Nylon
8	532140785	Keeper, Belt, R.H. Hydro	26	532140913	Keeper, Belt
10	532140780	Keeper, Belt, Ground Drive, Idler	27	532140914	Spacer
11	532150926	Arm, Ground Drive Clutch	28	532139123	Pulley, V-Idler
12	532123674	Idler, Flat	29	872140618	Bolt, Carr. 3/8-16 UNC x 2-1/4
13	819131316	Washer 13/32 x 13/16 x 16 Ga.	30	819111116	Washer
14	873930600	Nut, Centerlock 3/8-16 UNC	31	819111216	Washer
15	873680600	Nut, Lock, Hex. w/Wsh 3/8-16	32	872140620	Bolt, Carriage
16	532126471	Clip, Insulated	33	532000160	Sleeve, Pivot
			34	872140506	Bolt, Carriage

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

TRANSAXLE




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532140779	Pulley, V-Groove	28	532140772	Spring, Torsion
3	532140607	Transaxle, Hydro 0319-0500 (Order parts from transaxle manufacturer)	30	532124788	Retainer, Spring
			31	532121199	Spacer
6	872140506	Bolt, Carriage	32	819111116	Washer 11/32 x 11/16 x 16
7	532140774	Strap, Torque	34	874760516	Bolt, Rdhd 5/16-18 x 1
9	532146682	Spring, Brake	35	812000001	E-Ring
10	532121749	Washer 25/32 x 1-1/4 x 16 Gauge	36	817720408	Screw, Thd. Cut 1/4-20 x 1/2
11	532123583	Key, Square	37	873800500	Nut
13	532140778	Fan, Transaxle, Hydro	38	874490540	Bolt, Hex Flghd 5/16-18
14	873750800	Nut, Lock 1/2-20	39	819171912	Washer
16	532140763	Support, Shift Handle	40	874760524	Bolt
17	532140767	Link, Shift	41	819212013	Washer 21/32 x 1-1/4 x 13 Gauge
21	532140773	Lever, Shift	42	532140769	Pin, Pivot
23	532121274	Knob, Shifter	43	819171216	Washer
24	532140765	Rod, Shifter	44	532156047	Pivot Shaft Assembly
25	876020416	Pin, Cotter	45	812000002	E-Ring
27	532142564	Hose, Vent	46	-----	Cap, Vent Hose
			47	-----	Nipple, Vent Hose
			48	532140912	Actuator, Bypass, Hydro
			49	819111216	Washer

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

MOWER LIFT LEVER



KEY NO.	PART NO.	DESCRIPTION
1	532126470	Clip, Insulated
2	532122018	Bracket, Mower Clutch
3	871110408	Bolt, Fin. Hex 1/4-20 UNC x 1/2
4	873680600	Nut, Crownlock 3/8-16
5	532145187	Assembly, Clutch Lever
6	532106451	Bolt, Shoulder
7	532135371	Assembly, Mower Clutch Arm
8	874760636	Bolt, Hex 3/8-16 UNC x 2-1/4
9	532121930	Assembly, Bellcrank Lift
10	876020412	Pin, Cotter 1/8 x 3/4
11	819131316	Washer 13/32 x 13/16 x 16 Ga.
12	532122027	Grip, Handle
13	532139352	Assembly, Lift Handle
14	532123496	Spring, Compression
15	819131212	Washer 13/32 x 3/4 x 12 Ga.
16	532124961	Retainer, Spring


KEY NO.	PART NO.	DESCRIPTION
17	532127359	Link, Front Lift
18	532142028	Trunnion, Threaded 3/8-16
19	873680400	Nut, Crownlock 1/4-20
20	874760644	Bolt, Fin. Hex 3/8-16 UNC x 2-3/4
23	876020416	Pin, Cotter 1/8 x 1
24	819171612	Washer 17/32 x 1 x 12 Ga.
25	532121933	Tube, Spacer
26	532141470	Rod, Mower Lift
27	532121466	Knob
28	876020312	Pin, Cotter 3/32 x 3/4
29	532131655	Link, Mower Clutch
30	873350600	Nut, Hex Jam 3/8-16 x 1.30
31	819132012	Washer 13/32 x 1-1/4 x 12 Ga.
43	873900600	Nut Lock Flg. 3/8-16 Unc

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

MOWER DECK



REPAIR PARTS

TRACTOR - - MODEL NO. LRH130 (HA13H36A)

MOWER DECK


KEY NO.	PART NO.	DESCRIPTION
1	532140064	Spring, Mower Clutch
2	532165723	Spacer, Retainer
3	873680600	Nut, Crownlock 3/8-16
4	532130840	Brake Asm.
5	532131251	Guide, Belt Idler
6	532121316	Pulley, Flat Idler
7	872110616	Bolt, Carr. 3/8-16 x 1-3/4 Gr. 5
8	819131410	Washer 13/21 x 7/8 x 10 Ga.
9	532127744	Arm Asm., Idler Mower
10	872140610	Bolt, Carriage 3/8-16 x 1-1/4
11	532130841	Rod, Brake
12	532127356	Bracket, Lift R. H. Rear
13	872140506	Bolt, Carriage 5/16-18 x 3/4
14	873680500	Nut, Crownlock 5/16-18
15	532127357	Bracket, Lift L. H. Rear
16	532153298	Keeper, R. H.
17	532128508	Link, Asm. Mower Stabilizer
18	532128511	Pin, Drive
19	532127380	Bracket, Asm. Front
20	532138496	Blade Hi Lift
21	532140296	Washer, Hard
22	810030600	Washer, Lock 3/8
23	532850857	Bolt 3/8-24 x 1-1/4 Gr. 8
24	532140329	Stripper
25	532157722	Screw Thd Rolling Washer Head
27	532156600	Deck Assembly
28	532153531	Pulley, Mandrel
29	532137266	Nut, Flangelock 9/16
30	532136631	Bracket, Asm. Deflector
31	817490508	Screw, Hex Wsh. Thdrol. 5/16-18 x 1/2
32	532122051	Arm, Support Idler Mower
33	532131560	Deflector
36	532121980	Rod, Hinge
37	532123713	Spring, Torsion Deflector
38	532105304	Cap, Sleeve
39	819111016	Washer 11/32 x 5/8 x 16 Ga.
40	532110452	Pushnut
41	532131264	V-Belt
42	819171616	Washer 11/32 x 5/8 16 Ga.
43	532163552	Retainer, Spring
44	532140608	Keeper, L. H.
45	532110485	Bearing
46	532128774	Housing Mandrel Vented
47	532129895	Bearing
48	532137645	Shaft, Mandrel (Includes Key # 47)
49	532133943	Washer Hardened
62	532153390	Washer, Felt
--	532130794	Mandrel Asm. (Includes Key No.'s 22-23, 26, 29 and 45-48)
--	532156866	Deck, Mower Complete

HARDWARE SHOWN LARGER FOR EASIER IDENTIFICATION

REPAIR PARTS


TRACTOR - - MODEL NO. LRH130 (HA13H36A)

DECALS



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
2	532168869	Decal, Tick Mark	11	532145494	Decal, Cutfinger
3	532155861	Decal, Hood, L. H.	12	532141484	Decal, Drawbwr Cntrl
4	532155860	Decal, Hood, R. H.	13	532155862	Decal Fender Automatic Husq.
5	532150616	Decal, Logo, Grill	14	532159713	Decal Panel Side B&S Husq.
6	532165363	Decal, Engine	16	532136830	Decal, V-Belt Sch.
7	532124433	Decal, DBA	17	532156874	Decal, Oper. Inst.
8	532150617	Decal, Logo, Fender	--	532138311	Decal, Height, Adjust
9	532145005	Decal, Battery Danger/Poison	--	532146968	Manual, Operator's (Eng)
10	532157002	Decal, Fender Danger Eng.			

WHEELS & TIRES



KEY NO.	PART NO.	DESCRIPTION
1	532059192	Cap, Valve
2	532065139	Stem, Valve
3	532124957	Fitting, Grease (Front Wheels Only)
4	532137422	Tire, Front
4	532132703	Tire, Rear
5	532059904	Tube, Front (Optional Service Items Only)
5	532008134	Tube, Rear (Optional Service Items Only)
6	532142039	Rim, Front
6	532141652	Rim, Rear
7	532104757	Cap, Hub, Axle
8	532124959	Bearing, Flange
9	532121748	Washer 25/32 x 1-5/8 x 16 Ga.
--	532144334	Sealant, Tire (10 oz. Tube)

NOTE: All component dimensions given in U. S. inches
1 inch = 25.4 mm