


LT1538, LT1538B, 954569776, 2002-11



SPARE PARTS LIST

REPAIR PARTS

TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76
SEAT ASSEMBLY




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532140116	SEAT		1	
2	532140551	BRACKET		1	
3	871110616	SCREW		1	
4	819131610	WASHER		1	
5	532145006	CLIP		1	
6	873800600	NUT		1	
7	532124181	SPRING		1	
8	817000616	SCREW		1	
9	819131614	WASHER		1	
10	532182493	BRACKET		1	
12	532121246	BRACKET		1	
13	532121248	BUSHING		1	
14	872050412	BOLT		1	
15	532134300	SPACER		1	
16	532121250	SPRING		1	
17	532123976	LOCKNUT		1	
21	532171852	BOLT		1	
22	873800500	LOCK NUT		1	
23	871110814	BOLT		1	
24	819171912	WASHER		1	
25	532127018	BOLT		1	
26	810040800	WASHER		1	



REPAIR PARTS

TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76
ENGINE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532170805	CONTROL THROT /CH FLAG		1	
2	817720408	SCREW		1	
14	532148456	TUBE		1	
16	811050600	WASHER		1	
23	532169837	HEAT SHIELD		1	
29	532137180	SPARK ARRESTER KIT		1	
31	532184900	FUEL TANK ASSY		1	
32	532140527	FUEL CAP		1	
33	532123487	HOSE CLAMP		1	
37	532137040	HOSE		1	
38	532181654	PLUG		1	
40	532124028	BUSHING		1	
44	817670412	SCREW		1	
45	817000612	SCREW		1	
46	819091416	WASHER		1	
77	819101216	WASHER		1	
80	874760508	BOLT		1	
101	532163305	NUT FLANGE M8-1.25 NON-		1	
105	817120616	SCREW		1	



REPAIR PARTS

TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76

WHEELS & TIRES




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532059192	CAP VALVE		1	
2	532065139	NIPPLE		1	
3	532106222	TIRE		1	
4	532059904	HOSE		1	
5	532138336	RIM		1	
6	532124957	FITTING		1	
7	532124959	BEARING		1	
8	532138337	RIM SPROCKET		1	
9	532124635	TIRE		1	
10	532124926	HOSE		1	
11	532175039	HUB CAP		1	
--	532144334	SEALING FOAM		1	

GPL®

REPAIR PARTS


TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76
MOWER DECK



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532170280	MOWER HOUSING ASSEMBLY		1	
2	872140506	BOLT		1	
3	532138017	BRACKE		1	
4	532169970	BRACKET		1	
5	532124670	RETAINER RING		1	
6	532178024	LEVER		1	
8	532850857	BOLT		1	
9	810030600	WASHER		1	
10	532140296	WASHER		1	
11	532134148	RIDE ON BLADE		1	
532 1384-97	532138497	BLADE		1	
13	532137645	SHAFT		1	
14	532128774	BEARING HOUSING		1	
15	532110485	BEARING		1	
16	532174493	STRIPPER. MANDREL BLACK		1	
19	532132827	SPEC. BOLT		1	
21	873680500	NUT		1	
23	532137607	BRACKET		1	
24	532105304	HUB CAP		1	
25	532123713	SPRING		1	
26	532110452	NUT		1	
27	532175943	SHIELD		1	
28	819111016	WASHER		1	
29	532106735	ROD		1	
30	532173984	SCREW		1	
31	532129963	WASHER		1	
32	532153532	PULLEY		1	
33	532178342	NUT		1	
36	532131494	PULLEY		1	
40	873680600	NUT		1	
45	532124788	RETAINER RING		1	
53	532130840	BRAKE LEVER		1	
54	532178515	WASHER		1	
55	532133840	LEVER		1	
56	532165723	SPACER		1	
67	532106932	KNOB		1	
68	532144200	BELT		1	
69	876020312	SPLIT PIN		1	
86	532125074	RUNNER L/H		1	
87	532128772	SUPPORT		1	
88	819111216	WASHER		1	
89	819131612	WASHER		1	
92	873800600	NUT		1	
96	873930600	NUT		1	
97	874930620	BOLT		1	
98	819132016	WASHER		1	
99	810040600	WASHER		1	
100	532135651	NUT		1	
101	532132803	COVER		1	
107	532133502	SPACER		1	
108	532133503	LEVER		1	
109	874760640	BOLT		1	
110	532142587	UPSTOP DECK FRONT 38"		1	
113	817060512	SCREW		1	
122	532131289	BRAKE LEVER		1	
123	532169971	ROD		1	
129	819131312	WASHER		1	
130	874780616	BOLT		1	
131	872140608	BOLT		1	
146	532165891	BOLT		1	
148	532169022	SPRING		1	
149	532165898	SPRING		1	
150	819091216	WASHER		1	
151	532169670	BRACKET		1	
152	532172758	CABLE		1	
153	532169674	WASHER		1	
154	532169675	PIN		1	
155	532169671	SPRING		1	
156	532169672	SPACER		1	
157	532169669	CONTROL		1	
158	817720408	SCREW		1	
--	532130794	MANDREL		1	

REPAIR PARTS

TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76
ELECTRICAL




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532163465	BATTERY		1	
2	874760412	BOLT		1	
8	532176689	BATTERY BOX		1	
21	532175688	HARNESS		1	
22	532004152	BULB		1	
24	532124780	CABLE		1	
25	532146147	CABLE		1	
26	532175158	FUSE		1	
27	873510400	NUT		1	
28	532124773	CABLE		1	
29	532160784	SWITCH		1	
30	532175566	SWITCH		1	
33	532140401	KEY		1	
41	871110408	BOLT		1	
42	532131563	COVER		1	
43	532178861	SOLENOID		1	
48	532140844	ADAPTER		1	
52	532141940	WIRE		1	
81	532109748	RELAY		1	
90	532180449	COVER		1	
40	532179723	HARNESS		1	

GPL®

REPAIR PARTS

TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76
MOWER LIFT




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532159460	WIRE		1	
2	532159471	LEVER		1	
3	532105767	PIN RETAINING SCREW		1	
4	812000002	RETAINER RING		1	
5	819211621	WASHER		1	
6	532120183	BEARING		1	
7	532109413	GRIP		1	
8	532124526	KNOB		1	
11	532139865	LINK		1	
12	532139866	LINK		1	
13	532124670	RETAINER RING		1	
15	532173288	LINK		1	
16	873350800	NUT		1	
17	532175689	BRACKET		1	
18	873800800	NUT		1	
19	532139868	LEVER		1	
20	532163552	CLIP		1	
31	532169865	BEARING		1	
32	873540600	NUT		1	




REPAIR PARTS

TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76
CHASSIS AND ENCLOSURES




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532174619	FRAME		1	
2	532176554	PLATE		1	
3	817060612	SCREW		1	
5	532155272	DAMPER		1	
10	872140608	BOLT		1	
11	532174996	DASHBOARD		1	
13	532181719	DASHBOARD		1	
14	817490608	SCREW		1	
17	532185211	HOOD		1	
18	532184921	BUMPER		1	
26	873800600	NUT		1	
30	532180507	FENDER		1	
31	532139976	BRACKET		1	
37	817490508	SCREW		1	
38	532175710	BRACKET		1	
39	532174714	BRACKET PIVOT LASER LT		1	
58	532150127	AIR CONDUCTOR		1	
60	872140606	BOLT		1	
64	532154798	PANEL		1	
74	873680600	NUT		1	
142	532175702	PLATE		1	
143	532154966	BRACKET		1	
144	532175582	BRACKET		1	
145	532156524	SHAFT		1	
166	532171875	SCREW		1	
206	532170165	BOLT		1	
207	817670508	SCREW		1	
208	817670608	SCREW		1	
209	817000612	SCREW		1	
212	532183548	INSERT		1	
258	532185214	LENS		1	
259	532185213	LENS		1	
260	532185429	COVER		1	
261	532185433	INSERT GRILLE		1	
--	532005479	PLUG		1	



REPAIR PARTS


TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76
STEERING ASSEMBLY



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532175904	STEERING WHEEL		1	
2	532175131	AXLE		1	
3	532169840	SPINDLE		1	
4	532169839	SPINDLE		1	
5	532124931	WASHER		1	
6	532121748	WASHER		1	
7	819272016	WASHER		1	
8	812000029	RETAINER RING		1	
9	532124937	BEARING COL. STRG.		1	
10	532175121	ROD		1	
11	810040600	WASHER		1	
12	873940800	NUT		1	
13	532136518	PIPE		1	
15	532145212	NUT		1	
17	532180641	SHAFT		1	
26	532126847	BUSHING		1	
28	819131416	WASHER		1	
29	817060612	SCREW		1	
30	876020412	SPLIT PIN		1	
32	532130465	ROD		1	
36	532155099	BUSHING		1	
37	532152927	SCREW		1	
38	532175905	INSERT CAP STRG WH		1	
39	819183812	WASHER		1	
40	532124701	NUT		1	
41	532100711	ADAPTER		1	
42	532169633	SLEEVE		1	
43	532121749	WASHER		1	
44	532180640	SHAFT		1	
46	532121232	HUB CAP		1	
47	532183226	FITTING		1	
51	873540400	NUT		1	
54	871130420	BOLT		1	
65	532160367	SPACER		1	
67	872140618	BOLT		1	
68	532169827	SHAFT		1	
71	532175146	STEERING GEAR		1	
82	532169835	BRACKET		1	
85	532133835	XMAS TREE FASTNER		1	
88	532175118	BOLT		1	
91	532175553	SPRING		1	

REPAIR PARTS

TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76
DRIVE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
2	532146682	SPRING		1	
3	532123666	PULLEY		1	
4	812000028	CLIP		1	
5	532121520	BRACKET		1	
6	817060512	SCREW		1	
8	532165866	ROD		1	
10	876020416	SPLIT PIN		1	
11	532105701	WASHER		1	
13	874550412	BOLT		1	
14	810040400	WASHER		1	
16	873800500	LOCK NUT		1	
18	874780616	BOLT		1	
19	873800600	NUT		1	
21	532106933	KNOB		1	
22	532130804	ROD		1	
24	873350600	NUT		1	
25	532106888	SPRING		1	
26	819131316	WASHER		1	
27	876020412	SPLIT PIN		1	
28	532175765	SHAFT		1	
29	532071673	COVER		1	
30	532174973	BRACKET		1	
32	874760512	BOLT		1	
34	532175578	SHAFT		1	
35	532120183	BEARING		1	
36	819211616	WASHER		1	
37	532124963	PIN RETAINING SCREW		1	
38	532179114	PULLEY		1	
39	874760648	BOLT		1	
41	532175556	BELT GUIDE		1	
47	532127783	PULLEY		1	
48	532154407	GUIDE		1	
49	532123205	BELT GUIDE		1	
50	872110612	BOLT		1	
51	873680600	NUT		1	
52	873680500	NUT		1	
53	532105710	LINK		1	
55	532105709	SPRING		1	
56	817060620	SCREW		1	
57	532130801	V-BELT		1	
59	532169691	BELT GUIDE		1	
61	817120614	SCREW		1	
62	532124872	PEDAL RUBBER		1	
63	532175410	PULLEY		1	
64	871170764	BOLT		1	
65	810040700	WASHER		1	
66	532154778	TENSIONER		1	
70	532134683	BELT GUIDE		1	
74	532137057	SPACER		1	
75	532121749	WASHER		1	
76	812000001	RETAINER RING		1	
77	532123583	KEY		1	
78	532121748	WASHER		1	
79	532125096	WOODRUFF KEY		1	
80	532131486	ROD		1	
81	532165594	SHAFT		1	
82	532165711	SPRING		1	
83	819171216	WASHER		1	
84	532166228	LINK		1	
85	532150360	NUT		1	
89	532166556	SHIFT CONSOL		1	
90	532124346	NUT		1	
96	532124788	RETAINER RING		1	
112	819091210	WASHER		1	
113	532127285	BRACKET		1	
116	872140608	BOLT		1	
120	873900600	NUT		1	
145	874490540	BOLT		1	
150	532175456	SPACER		1	
151	819133210	WASHER		1	
156	532166002	WASHER		1	
158	532165589	BRACKET		1	
159	532183900	LEVER		1	
161	872140406	BOLT		1	
162	873680400	NUT		1	
163	874780416	BOLT		1	
164	819091010	WASHER		1	
165	532165623	BRACKET		1	

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
166	532166880	SCREW		1	
168	532165492	BOLT		1	
169	532165580	RETAINER		1	
170	532178394	KEEPER		1	
197	532169613	SLEEVE		1	
198	532169593	WASHER		1	
202	872110614	BOLT		1	
212	532145212	NUT		1	



REPAIR PARTS

TRACTOR - - MODEL NO. LT1538 (LT1538B), PRODUCT NO. 954 56 97-76
DECALS



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532156369	DECALC.OPERATEUR		1	
5	532180941	DECAL		1	
8	532170563	DECALC."DANGER"		1	
9	532176822	DECAL		1	
10	532157140	DECAL		1	
14	532136832	DECAL		1	
20	532145005	DECAL		1	
--	532138311	DECAL		1	
--	532171285	PLATE		1	
--	532171284	PLATE		1	

GPL®