

LT 16A, J816H42J, 954130048, 2001-02




The logo for CPL, consisting of the letters 'CPL' in a stylized, bold, sans-serif font. A registered trademark symbol (®) is located to the upper right of the 'L'.

SPARE PARTS LIST

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48
CHASSIS AND ENCLOSURES




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532174619	FRAME		1	
2	532176554	PLATE		1	
3	817060612	SCREW		1	
9	532177150	DASH		1	
10	872140608	BOLT		1	
11	532167203	PLATE		1	
13	532167202	PLATE		1	
14	817490608	SCREW		1	
17	532177147	HOOD		1	
20	532162026	PLATE		1	
25	819131312	WASHER		1	
26	873800600	NUT		1	
28	532177148	GRILL		1	
29	532160568	LENS		1	
30	532172157	GUARD		1	
31	532139976	BRACKET		1	
37	817490508	SCREW		1	
38	532169834	BRACKET		1	
50	532161572	BAFFLE		1	
54	532161464	SCREW		1	
59	532110436	GROMMET		1	
60	872140606	BOLT		1	
64	532162025	DASH		1	
74	873680600	NUT		1	
142	532165867	PLATE		1	
143	532154966	BRACKET		1	
144	532154207	HOLDER		1	
145	532156524	SHAFT		1	
154	532161897	BRACKET		1	
155	532161900	BRACKET		1	
156	532163805	PIN RETAINING SCREW		1	
157	532163806	PIN RETAINING SCREW		1	
158	532162037	BRACKET		1	
160	532162967	NUT		1	
161	532164655	ABSORBER		1	
166	532164863	SCREW		1	
206	532170165	BOLT		1	
209	817000612	SCREW		1	

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48


DECALS



REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48

DRIVE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
8	532165866	ROD		1	
9	532145028	CLUTCH		1	
10	876020416	SPLIT PIN		1	
14	810040400	WASHER		1	
15	874490544	SCREW		1	
16	873800500	LOCK NUT		1	
19	873800600	NUT		1	
20	532150280	SCREW		1	
21	532130564	HANDLE		1	
22	532169498	ROD		1	
23	532171258	BRACKET		1	
24	873350600	NUT		1	
25	532106888	SPRING		1	
26	819131316	WASHER		1	
27	876020412	SPLIT PIN		1	
28	532175765	SHAFT		1	
29	532071673	COVER		1	
30	532169592	BRACKET		1	
32	874760512	BOLT		1	
33	872140506	BOLT		1	
34	532175578	SHAFT		1	
35	532120183	BEARING		1	
36	819211616	WASHER		1	
37	532124963	PIN RETAINING SCREW		1	
38	532165936	PULLEY		1	
39	874760648	BOLT		1	
40	532175461	SPACER		1	
41	532175556	BELT GUIDE		1	
42	819131312	WASHER		1	
47	532127783	PULLEY		1	
48	532154407	GUIDE		1	
49	532123205	BELT GUIDE		1	
50	874760624	BOLT		1	
51	873680600	NUT		1	
52	873680500	NUT		1	
53	532105710	LINK		1	
55	532105709	SPRING		1	
56	817060616	SCREW		1	
57	532140294	BELT		1	
59	532169691	BELT GUIDE		1	
61	817060612	SCREW		1	
62	532124872	PEDAL RUBBER		1	
63	532175414	PULLEY		1	
65	810040700	WASHER		1	
66	532154778	TENSIONER		1	
71	532169183	ROD		1	
73	532169182	BRACKET		1	
74	532137057	SPACER		1	
75	532121749	WASHER		1	
76	812000001	RETAINER RING		1	
77	532123583	KEY		1	
78	532121748	WASHER		1	
81	532165596	SHAFT		1	
82	532165711	SPRING		1	
83	819171216	WASHER		1	
84	532169594	LINK		1	
89	532166602	BRACKET		1	
90	532124346	NUT		1	
95	532170201	CONTROL		1	
96	532124788	RETAINER RING		1	
120	873900600	NUT		1	
144	819111016	WASHER		1	
150	532175456	SPACER		1	
151	819133210	WASHER		1	
156	532166002	WASHER		1	
158	532165589	BRACKET		1	
159	532165494	LEVER		1	
161	872140406	BOLT		1	
162	873680400	NUT		1	
163	874780416	BOLT		1	
164	819091010	WASHER		1	
165	532165623	BRACKET		1	
166	532166880	SCREW		1	
168	532165492	BOLT		1	
169	532165580	RETAINER		1	
197	532169613	SLEEVE		1	
198	532169593	WASHER		1	
199	532169612	SCREW		1	

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
200	872140508	BOLT		1	
202	872110612	BOLT		1	



REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48
ELECTRICAL




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532144925	BATTERY		1	
2	874760412	BOLT		1	
8	532124886	BATTERIE TRAY		1	
10	532145211	BOLT		1	
11	532150109	HOLDER		1	
12	532145769	NUT		1	
16	532153664	SWITCH		1	
21	532166184	HARNESS		1	
22	532004152	BULB		1	
24	532008860	CABLE		1	
25	532146148	CABLE		1	
26	532175158	FUSE		1	
27	873510400	NUT		1	
28	532145491	CABLE		1	
29	532160784	SWITCH		1	
30	532175566	SWITCH		1	
33	532140401	KEY		1	
40	532170233	CABLE ASSY		1	
41	817720408	SCREW		1	
42	532131563	COVER		1	
43	532175141	SOLENOID		1	
48	532140844	ADAPTER		1	
50	532174651	SWITCH		1	
55	817490508	SCREW		1	
52	532141940	WIRE		1	
79	532163996	HOLDER		1	
80	532146685	CABLE ASSY		1	
81	532109748	RELAY		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48
ENGINE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532173315	THROTTLE CONTROL		1	
4	532137352	MUFFLER		1	
13	532165291	GASKET		1	
14	532148456	TUBE		1	
16	811050600	WASHER		1	
23	532169837	HEAT SHIELD		1	
29	532137180	SPARK ARRESTER KIT		1	
31	532157103	TANK		1	
32	532140527	FUEL CAP		1	
33	532123487	HOSE CLAMP		1	
34	532106082	SPACER		1	
37	532142158	FULE LINE		1	
38	532148315	PLUG		1	
39	532109227	PAD		1	
45	817000612	SCREW		1	
62	810040500	WASHER		1	
66	532127951	MOVEMENT LIMITER		1	
72	871070512	BOLT		1	
78	817060620	SCREW		1	
81	873510400	NUT		1	
102	532164863	SCREW		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48


MOWER DECK



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532165892	HOUSING ASM MOWER 42"		1	
2	872140506	BOLT		1	
3	532138017	BRACKE		1	
4	532165460	BRACKET		1	
5	532124670	RETAINER RING		1	
6	532130832	LEVER		1	
8	532850857	BOLT		1	
9	810030600	WASHER		1	
10	532140296	WASHER		1	
11	532138498	BLADE		1	
13	532137645	SHAFT		1	
14	532128774	BEARING HOUSING		1	
15	532110485	BEARING		1	
16	532174493	STRIPPER, MANDREL BLACK		1	
18	872140505	BOLT		1	
19	532132827	SPEC. BOLT		1	
20	532159770	RAIL		1	
21	873680500	NUT		1	
22	532134753	PLATE		1	
23	532131267	BRACKET		1	
24	532105304	HUB CAP		1	
25	532123713	SPRING		1	
26	532110452	NUT		1	
27	532171859	SHIELD DEFL ECTOR		1	
28	819111016	WASHER		1	
29	532131491	SHAFT		1	
30	532157722	SCREW		1	
31	532129963	WASHER		1	
32	532153535	PULLEY		1	
33	532137266	NUT		1	
34	872110614	BOLT		1	
36	532131494	PULLEY		1	
37	819131316	WASHER		1	
40	873680600	NUT		1	
44	532140088	GUARD		1	
45	532124788	RETAINER RING		1	
46	532137729	SCREW		1	
54	532133943	WASHER		1	
55	532155046	LEVER		1	
56	532165723	SPACER		1	
59	532141043	GUARD		1	
61	532174882	SPRING		1	
68	532174883	BELT		1	
90	874760616	BOLT		1	
91	532132274	BRACKET		1	
92	873800600	NUT		1	
93	819171416	WASHER		1	
94	532132264	ROLLER		1	
95	532132273	BRACKET		1	
111	532155197	BRACKET		1	
112	532155198	BRACKET		1	
113	817060514	BOLT		1	
114	873510500	NUT		1	
115	872110504	BOLT		1	
116	532124842	BOLT		1	
117	532165746	WHEEL		1	
118	873930600	NUT		1	
119	819121414	WASHER		1	
121	532143723	BRACKET		1	
129	819131312	WASHER		1	
130	874780616	BOLT		1	
131	872140608	BOLT		1	
143	532157109	BRACKET		1	
144	532158634	BELT GUIDE		1	
145	532165888	PULLEY		1	
146	532171977	SHAFT		1	
148	532169022	SPRING		1	
149	532165898	SPRING		1	
150	819091216	WASHER		1	
159	872140614	BOLT		1	
--	532176207	HOUSING		1	
--	532130794	MANDREL		1	

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48
MOWER LIFT




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532159461	WIRE		1	
2	532159476	SHAFT		1	
3	532138284	PIN RETAINING SCREW		1	
4	812000002	RETAINER RING		1	
5	819211621	WASHER		1	
6	532120183	BEARING		1	
7	532125631	HANDLE		1	
8	532122365	PLUG		1	
11	532139865	LINK		1	
12	532139866	LINK		1	
13	532124670	RETAINER RING		1	
15	532173288	LINK		1	
16	873350800	NUT		1	
17	532130171	BRACKET		1	
18	873800800	NUT		1	
19	532139868	LEVER		1	
20	532163552	CLIP		1	
23	532110807	NUT		1	
24	819131016	WASHER		1	
25	532164024	SPRING		1	
26	532169484	PIN		1	
27	532164543	ROD		1	
28	873350600	NUT		1	
29	532138057	KNOB		1	
30	532150233	TRUNNION		1	
31	532169865	BEARING		1	
32	873540600	NUT		1	
36	532155097	INDICATOR		1	
37	532123935	PLUG		1	
38	817060516	SCREW		1	
40	819112410	WASHER		1	
41	532155098	LEVER		1	
49	532145212	NUT		1	
50	532110452	NUT		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48
SEAT ASSEMBLY




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532140118	SEAT		1	
2	532140551	BRACKET		1	
3	871110616	SCREW		1	
4	819131610	WASHER		1	
5	532145006	CLIP		1	
6	873800600	NUT		1	
7	532124181	SPRING		1	
8	817000616	SCREW		1	
9	819131614	WASHER		1	
10	532174894	PAN		1	
11	532166369	WING NUT		1	
12	532121246	BRACKET		1	
13	532121248	BUSHING		1	
14	872050412	BOLT		1	
15	532121249	SPACER		1	
16	532123740	SPRING		1	
17	532123976	LOCKNUT		1	
18	532124238	HUB CAP		1	
21	532171852	BOLT		1	
22	873800500	LOCK NUT		1	
24	819171912	WASHER		1	
25	532127018	BOLT		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48

STEERING ASSEMBLY




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532172092	STEERING WHEEL		1	
2	532172393	SHAFT		1	
3	532169840	SPINDLE		1	
4	532169839	SPINDLE		1	
5	532124931	WASHER		1	
6	532121748	WASHER		1	
8	812000029	RETAINER RING		1	
10	532175121	ROD		1	
11	810040600	WASHER		1	
12	873940800	NUT		1	
13	532136518	PIPE		1	
15	532145212	NUT		1	
17	532177883	SHAFT		1	
29	817060612	SCREW		1	
32	532171888	ROD		1	
33	819111216	WASHER		1	
34	810040500	WASHER		1	
35	873540500	NUT		1	
36	532155105	BUSHING		1	
37	532152927	SCREW		1	
38	532172093	COVER		1	
40	532124701	NUT		1	
41	532159945	ADAPTER		1	
42	532177149	BOOT		1	
43	532121749	WASHER		1	
46	532121232	HUB CAP		1	
65	532160367	SPACER		1	
67	872140618	BOLT		1	
68	532169827	SHAFT		1	
71	532175146	STEERING GEAR		1	
72	819182411	WASHER		1	
73	532160135	SPACER		1	
82	532169835	BRACKET		1	
87	532173966	WASHER		1	
88	532175118	BOLT		1	
91	532175553	SPRING		1	

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (J816H42J), PRODUCT NO. 954 13 00-48

WHEELS & TIRES



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532059192	CAP VALVE		1	
2	532065139	NIPPLE		1	
3	532106222	TIRE		1	
4	532059904	HOSE		1	
5	532138336	RIM		1	
6	532124957	FITTING		1	
7	532124959	BEARING		1	
8	532138337	RIM SPROCKET		1	
9	532122082	TIRE		1	
10	532124926	HOSE		1	
11	532175039	HUB CAP		1	
--	532144334	SEALING FOAM		1	
	PART NO.		REMARK		KIT

