

LT 16A, JLT16H42A, 954130061, 2002-06




The logo for CPL, consisting of the letters 'CPL' in a stylized, bold, sans-serif font. A registered trademark symbol (®) is located to the upper right of the 'L'.

SPARE PARTS LIST

REPAIR PARTS


TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61
CHASSIS AND ENCLOSURES



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532174619	FRAME		1	
2	532176554	PLATE		1	
3	817060612	SCREW		1	
5	532155272	DAMPER		1	
9	532172151	PANEL		1	
10	872140608	BOLT		1	
11	532174996	DASHBOARD		1	
12	532145660	CLIP		1	
13	532172106	DASH		1	
14	817490608	SCREW		1	
17	532150760	HOOD		1	
18	532164655	ABSORBER		1	
20	532180679	PLATE		1	
23	532124028	BUSHING		1	
26	873800600	NUT		1	
28	532179351	GRILLE		1	
29	532179014	LENS		1	
30	532181205	FENDER		1	
31	532139976	BRACKET		1	
37	817490508	SCREW		1	
38	532175710	BRACKET		1	
51	873800400	NUT		1	
52	819091416	WASHER		1	
53	532145201	BRACKET		1	
54	532161464	SCREW		1	
55	532145202	BRACKET		1	
57	874780412	BOLT		1	
60	872140606	BOLT		1	
64	532154798	PANEL		1	
74	873680600	NUT		1	
142	532175702	PLATE		1	
143	532154966	BRACKET		1	
144	532175582	BRACKET		1	
145	532156524	SHAFT		1	
206	532170165	BOLT		1	
207	817670508	SCREW		1	
208	817670608	SCREW		1	
212	532165919	INSERT		1	
219	817000512	SCREW		1	
--	532005479	PLUG		1	

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61
DECALS




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532180432	DECAL		1	
2	532152262	DECAL		1	
3	532170600	DECAL		1	
4	532170601	DECAL		1	
5	532180434	DECALC.VOLUTE MOTEUR		1	
7	532170565	DECAL		1	
8	532182166	DECAL		1	
9	532141761	DECAL		1	
10	532145498	DECAL		1	
11	532162927	DECAL		1	
12	532179128	DECAL		1	
13	532159736	DECAL		1	
14	532160396	DECAL		1	
15	532159737	DECAL		1	
16	532140837	DECAL		1	
20	532145005	DECAL		1	
--	532171284	PLATE		1	
--	532171285	PLATE		1	
--	532138311	DECAL		1	
--	532169210	DECAL		1	
--	532162598	DECAL		1	
--	532180040	OPERATORS MANUAL		1	
--	532180041	OPERATORS MANUAL		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61
DRIVE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
8	532165866	ROD		1	
10	876020416	SPLIT PIN		1	
14	810040400	WASHER		1	
15	874490544	SCREW		1	
16	873800500	LOCK NUT		1	
19	873800600	NUT		1	
21	532130564	HANDLE		1	
22	532169498	ROD		1	
24	873350600	NUT		1	
25	532106888	SPRING		1	
26	819131316	WASHER		1	
27	876020412	SPLIT PIN		1	
28	532175765	SHAFT		1	
29	532071673	COVER		1	
30	532169592	BRACKET		1	
32	874760512	BOLT		1	
34	532175578	SHAFT		1	
35	532120183	BEARING		1	
36	819211616	WASHER		1	
37	532124963	PIN RETAINING SCREW		1	
38	532179114	PULLEY		1	
39	874760648	BOLT		1	
41	532175556	BELT GUIDE		1	
47	532127783	PULLEY		1	
48	532154407	GUIDE		1	
49	532123205	BELT GUIDE		1	
50	872110612	BOLT		1	
51	873680600	NUT		1	
52	873680500	NUT		1	
53	532105710	LINK		1	
55	532105709	SPRING		1	
56	817060620	SCREW		1	
57	532140294	BELT		1	
59	532169691	BELT GUIDE		1	
61	817120614	SCREW		1	
62	532124872	PEDAL RUBBER		1	
63	532180219	PULLEY		1	
64	871170764	BOLT		1	
65	810040700	WASHER		1	
66	532154778	TENSIONER		1	
70	532180218	BELT GUIDE		1	
71	532169183	ROD		1	
73	532169182	BRACKET		1	
74	532137057	SPACER		1	
75	532121749	WASHER		1	
76	812000001	RETAINER RING		1	
77	532123583	KEY		1	
78	532121748	WASHER		1	
81	532165596	SHAFT		1	
82	532165711	SPRING		1	
83	819171216	WASHER		1	
84	532169594	LINK		1	
89	532166602	BRACKET		1	
90	532124346	NUT		1	
95	532170201	CONTROL		1	
96	532124788	RETAINER RING		1	
116	872140608	BOLT		1	
120	873900600	NUT		1	
150	532175456	SPACER		1	
151	819133210	WASHER		1	
156	532166002	WASHER		1	
158	532165589	BRACKET		1	
159	532165494	LEVER		1	
161	872140406	BOLT		1	
162	873680400	NUT		1	
163	874780416	BOLT		1	
164	819091010	WASHER		1	
165	532165623	BRACKET		1	
166	532166880	SCREW		1	
168	532165492	BOLT		1	
169	532165580	RETAINER		1	
197	532169613	SLEEVE		1	
198	532169593	WASHER		1	
199	532169612	SCREW		1	
200	872140508	BOLT		1	
202	872110614	BOLT		1	
212	532145212	NUT		1	
250	817060612	SCREW		1	

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
263	817000612	SCREW		1	
268	532182402	PROTECTOR		1	



REPAIR PARTS

**TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61
ELECTRICAL**




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532163465	BATTERY		1	
2	874760412	BOLT		1	
8	532176689	BATTERY BOX		1	
16	532176138	MICRO SWITCH		1	
21	532175688	HARNESS		1	
22	532004152	BULB		1	
24	532124780	CABLE		1	
25	532146147	CABLE		1	
26	532175158	FUSE		1	
27	873510400	NUT		1	
28	532124773	CABLE		1	
29	532121305	SWITCH		1	
30	532175566	SWITCH		1	
33	532140401	KEY		1	
40	532179720	HARNESS		1	
41	871110408	BOLT		1	
42	532131563	COVER		1	
43	532178861	SOLENOID		1	
48	532140844	ADAPTER		1	
52	532141940	WIRE		1	
89	532180449	COVER		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61
ENGINE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532170551	THROTTLE CONTROL		1	
2	817720408	SCREW		1	
4	532137352	MUFFLER		1	
13	532165291	GASKET		1	
14	532148456	TUBE		1	
16	811050600	WASHER		1	
23	532169837	HEAT SHIELD		1	
25	532180945	CHOKE CONTROL		1	
26	873920600	NUT		1	
29	532137180	SPARK ARRESTER KIT		1	
31	532180645	FUEL TANK		1	
32	532140527	FUEL CAP		1	
33	532123487	HOSE CLAMP		1	
37	532137040	HOSE		1	
38	532148315	PLUG		1	
40	532124028	BUSHING		1	
41	532139277	NIPPLE		1	
44	817670412	SCREW		1	
45	817000612	SCREW		1	
46	819091416	WASHER		1	
62	810040500	WASHER		1	
72	871070512	BOLT		1	
78	817060620	SCREW		1	
81	873510400	NUT		1	
112	532124952	BUSHING		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61
MOWER DECK




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532165892	HOUSING ASM MOWER 42"		1	
2	872140506	BOLT		1	
3	532138017	BRACKE		1	
4	532165460	BRACKET		1	
5	532124670	RETAINER RING		1	
6	532178024	LEVER		1	
8	532850857	BOLT		1	
9	810030600	WASHER		1	
10	532140296	WASHER		1	
11	532138498	BLADE		1	
13	532137645	SHAFT		1	
14	532128774	BEARING HOUSING		1	
15	532110485	BEARING		1	
16	532174493	STRIPPER, MANDREL BLACK		1	
18	872140505	BOLT		1	
19	532132827	SPEC. BOLT		1	
20	532159770	RAIL		1	
21	873680500	NUT		1	
23	532177563	BRACKET		1	
24	532105304	HUB CAP		1	
25	532123713	SPRING		1	
26	532110452	NUT		1	
27	532171859	SHIELD DEFL ECTOR		1	
28	819111016	WASHER		1	
29	532131491	SHAFT		1	
30	532173984	SCREW		1	
31	532129963	WASHER		1	
32	532153535	PULLEY		1	
33	532178342	NUT		1	
34	872110614	BOLT		1	
36	532131494	PULLEY		1	
37	819131316	WASHER		1	
40	873680600	NUT		1	
44	532140088	GUARD		1	
45	532124788	RETAINER RING		1	
46	532137729	SCREW		1	
48	532133944	WASHER		1	
49	532174284	ROLLER		1	
50	532131340	BOLT		1	
51	532069180	NUT		1	
52	532139888	BOLT		1	
53	532131845	BRAKE		1	
54	532133943	WASHER		1	
55	532155046	LEVER		1	
56	532165723	SPACER		1	
59	532141043	GUARD		1	
67	532106932	KNOB		1	
68	532180215	V-BELTMOWER		1	
91	532180532	BRACKET		1	
92	873800600	NUT		1	
94	532132264	ROLLER		1	
95	532180533	BRACKET		1	
111	532179292	BRACKET		1	
112	532179293	BRACKET		1	
113	817060508	SCREW		1	
114	873510500	NUT		1	
115	872110505	BOLT		1	
116	532124842	BOLT		1	
117	532165746	WHEEL		1	
118	873930600	NUT		1	
119	819121414	WASHER		1	
129	819131312	WASHER		1	
130	874780616	BOLT		1	
131	872140608	BOLT		1	
132	817060612	SCREW		1	
142	532165890	BRACKET		1	
143	532157109	BRACKET		1	
144	532158634	BELT GUIDE		1	
145	532165888	PULLEY		1	
146	532171977	SHAFT		1	
147	532179748	SPRING		1	
148	532169022	SPRING		1	
149	532165898	SPRING		1	
150	819091216	WASHER		1	
151	532169670	BRACKET		1	
152	532181555	CABLE		1	
153	532169674	WASHER		1	
154	532169675	PIN		1	

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
155	532169671	SPRING		1	
156	532169672	SPACER		1	
157	532169669	CONTROL		1	
158	817720408	SCREW		1	
159	872140614	BOLT		1	
160	817060612	SCREW		1	
182	532179126	PIN RETAINING SCREW		1	
183	532163552	CLIP		1	
--	532181385	CUTTER DECK		1	
--	532130794	MANDREL		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61
MOWER LIFT




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532159460	WIRE		1	
2	532159471	LEVER		1	
3	532105767	PIN RETAINING SCREW		1	
4	812000002	RETAINER RING		1	
5	819211621	WASHER		1	
6	532120183	BEARING		1	
7	532125631	HANDLE		1	
8	532122365	PLUG		1	
11	532139865	LINK		1	
12	532139866	LINK		1	
13	532124670	RETAINER RING		1	
15	532173288	LINK		1	
16	873350800	NUT		1	
17	532175689	BRACKET		1	
18	873800800	NUT		1	
19	532139868	LEVER		1	
20	532163552	CLIP		1	
23	532110807	NUT		1	
24	819131016	WASHER		1	
25	532124874	SPRING		1	
26	532169484	PIN		1	
27	532126971	LEVER		1	
28	873350600	NUT		1	
29	532138057	KNOB		1	
30	532150233	TRUNNION		1	
31	532169865	BEARING		1	
32	873540600	NUT		1	
36	532155097	INDICATOR		1	
37	532123935	PLUG		1	
38	817060516	SCREW		1	
40	819112410	WASHER		1	
41	532155098	LEVER		1	
49	532145212	NUT		1	
50	532110452	NUT		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61
SEAT ASSEMBLY




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532140117	SEAT		1	
2	532140551	BRACKET		1	
3	871110616	SCREW		1	
4	819131610	WASHER		1	
5	532145006	CLIP		1	
6	873800600	NUT		1	
7	532124181	SPRING		1	
8	817000616	SCREW		1	
9	819131614	WASHER		1	
10	532182493	BRACKET		1	
11	532166369	WING NUT		1	
12	532121246	BRACKET		1	
13	532121248	BUSHING		1	
14	872050412	BOLT		1	
15	532134300	SPACER		1	
16	532121250	SPRING		1	
17	532123976	LOCKNUT		1	
18	532124238	HUB CAP		1	
21	532171852	BOLT		1	
22	873800500	LOCK NUT		1	
24	819171912	WASHER		1	
25	532127018	BOLT		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61
STEERING ASSEMBLY




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532172092	STEERING WHEEL		1	
2	532175131	AXLE		1	
3	532169840	SPINDLE		1	
4	532169839	SPINDLE		1	
5	532124931	WASHER		1	
6	532121748	WASHER		1	
7	819272016	WASHER		1	
8	812000029	RETAINER RING		1	
9	532124937	BEARING COL. STRG.		1	
10	532175121	ROD		1	
11	810040600	WASHER		1	
13	532136518	PIPE		1	
15	532145212	NUT		1	
17	532177876	SHAFT		1	
26	532126847	BUSHING		1	
28	819131416	WASHER		1	
29	817060612	SCREW		1	
30	876020412	SPLIT PIN		1	
32	532130465	ROD		1	
36	532155099	BUSHING		1	
37	532152927	SCREW		1	
38	532172093	COVER		1	
39	819132411	WASHER		1	
40	532124701	NUT		1	
41	532159945	ADAPTER		1	
42	532169633	SLEEVE		1	
43	532121749	WASHER		1	
44	532153720	STEERING PINION		1	
46	532121232	HUB CAP		1	
47	532183226	FITTING		1	
51	873800500	LOCK NUT		1	
54	874780520	BOLT		1	
63	874780616	BOLT		1	
65	532160367	SPACER		1	
67	872140618	BOLT		1	
68	532169827	SHAFT		1	
71	532175146	STEERING GEAR		1	
82	532169835	BRACKET		1	
85	532133835	XMAS TREE FASTNER		1	
88	532175118	BOLT		1	
91	532175553	SPRING		1	

REPAIR PARTS

TRACTOR - MODEL NO. LT16A (JLT16H42A), PRODUCT NO. 954 13 00-61

WHEELS & TIRES



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532059192	CAP VALVE		1	
2	532065139	NIPPLE		1	
3	532106222	TIRE		1	
4	532059904	HOSE		1	
5	532138336	RIM		1	
6	532124957	FITTING		1	
7	532124959	BEARING		1	
8	532138337	RIM SPROCKET		1	
9	532122082	TIRE		1	
10	532124926	HOSE		1	
11	532175039	HUB CAP		1	
--	532144334	SEALING FOAM		1	

