

LT 19A, JLT19H48C, 954130078, 2002-09




The logo for CPL, consisting of the letters 'CPL' in a stylized, bold, sans-serif font. A registered trademark symbol (®) is located to the upper right of the 'L'.

SPARE PARTS LIST

REPAIR PARTS


TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78
MOWER DECK



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532180358	HOUSING		1	
3	532138017	BRACKE		1	
5	532124670	RETAINER RING		1	
6	532178024	LEVER		1	
8	532174365	BOLT		1	
11	532180054	BLADE		1	
13	532174360	SHAFT		1	
14	532174358	MANDREL		1	
15	532110485	BEARING		1	
16	532174493	STRIPPER, MANDREL, BLACK		1	
17	872110610	BOLT		1	
18	872140505	BOLT		1	
19	532132827	SPEC. BOLT		1	
20	532174378	BAFFLE		1	
21	873680500	NUT		1	
24	532105304	HUB CAP		1	
25	532178102	SPRING		1	
26	532110452	NUT		1	
27	532181707	SHIELD		1	
28	819111016	WASHER		1	
29	532131491	SHAFT		1	
30	532173984	SCREW		1	
31	532129963	WASHER		1	
32	532177865	PULLEY		1	
33	532178342	NUT		1	
36	819131316	WASHER		1	
37	532177968	PULLEY		1	
39	532174375	PULLEY		1	
42	532165723	SPACER		1	
43	532174373	LEVER		1	
45	532180806	COVER		1	
46	532137729	SCREW		1	
47	532180808	V-BELT		1	
48	532174368	V-BELT		1	
49	873680600	NUT		1	
50	872110612	BOLT		1	
52	532175820	PULLEY		1	
54	874780616	BOLT		1	
55	872140608	BOLT		1	
56	532155986	BAR		1	
57	532156941	PIN, RETAINING SCREW		1	
72	819131312	WASHER		1	
90	874760516	BOLT		1	
91	532180534	BRACKET		1	
92	873800600	NUT		1	
93	819171416	WASHER		1	
94	532176066	ROLLER		1	
95	532180535	BRACKET		1	
97	532133943	WASHER		1	
98	532179479	SPRING		1	
99	532184058	PULLEY		1	
100	872110616	BOLT		1	
108	872110404	BOLT		1	
109	873680400	NUT		1	
110	532175016	LEVER		1	
112	532174387	LINK		1	
113	872110508	BOLT		1	
114	532174384	LEVER		1	
115	532174609	LEVER		1	
116	532137644	SCREW		1	
117	532174873	WHEEL		1	
118	873930600	NUT		1	
119	819121414	WASHER		1	
121	532174371	SPRING		1	
122	532174606	BUSHING		1	
126	532174372	LEVER		1	
130	817000616	SCREW		1	
132	817060612	SCREW		1	
180	873800500	LOCK NUT		1	
182	532179127	ROD ROLLER NOSE		1	
183	532163552	CLIP		1	
184	532173979	BELT GUIDE		1	
--	532181579	HOUSING		1	
--	532174356	MANDREL		1	

REPAIR PARTS


TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78
MOWER LIFT



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532159461	WIRE		1	
2	532159476	SHAFT		1	
3	532138284	PIN RETAINING SCREW		1	
4	812000002	RETAINER RING		1	
5	819211621	WASHER		1	
6	532120183	BEARING		1	
7	532125631	HANDLE		1	
8	532122365	PLUG		1	
11	532175370	LINK		1	
12	532175371	LINK		1	
13	532124670	RETAINER RING		1	
15	532175562	BRACKET		1	
16	873350800	NUT		1	
17	532175689	BRACKET		1	
18	873800800	NUT		1	
20	532163552	CLIP		1	
23	532110807	NUT		1	
24	819131016	WASHER		1	
25	532164024	SPRING		1	
26	532169484	PIN		1	
27	532164543	ROD		1	
28	873350600	NUT		1	
29	532138057	KNOB		1	
30	532150233	TRUNNION		1	
31	532176205	TRUNION		1	
32	532175994	NUT		1	
36	532155097	INDICATOR		1	
37	532123935	PLUG		1	
38	817060516	SCREW		1	
40	819112410	WASHER		1	
41	532155098	LEVER		1	
49	532145212	NUT		1	
50	532110452	NUT		1	
51	819171416	WASHER		1	
52	532175378	LEVER		1	
53	532175802	LEVER		1	
54	532175560	PIN RETAINING SCREW		1	

REPAIR PARTS

TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78
SEAT ASSEMBLY




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532140118	SEAT		1	
2	532140551	BRACKET		1	
3	871110616	SCREW		1	
4	819131610	WASHER		1	
5	532145006	CLIP		1	
6	873800600	NUT		1	
7	532124181	SPRING		1	
8	817000616	SCREW		1	
9	819131614	WASHER		1	
10	532182493	BRACKET		1	
11	532166369	WING NUT		1	
12	532121246	BRACKET		1	
13	532121248	BUSHING		1	
14	872050412	BOLT		1	
15	532121249	SPACER		1	
16	532123740	SPRING		1	
17	532123976	LOCKNUT		1	
18	532124238	HUB CAP		1	
21	532171852	BOLT		1	
22	873800500	LOCK NUT		1	
24	819171912	WASHER		1	
25	532127018	BOLT		1	

GPL®

REPAIR PARTS


TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78
STEERING ASSEMBLY



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532172092	STEERING WHEEL		1	
2	532172393	SHAFT		1	
3	532169840	SPINDLE		1	
4	532169839	SPINDLE		1	
5	532124931	WASHER		1	
6	532121748	WASHER		1	
8	812000029	RETAINER RING		1	
10	532175121	ROD		1	
11	810040600	WASHER		1	
12	873940800	NUT		1	
13	532136518	PIPE		1	
15	532145212	NUT		1	
17	532177883	SHAFT		1	
29	817060612	SCREW		1	
32	532170162	ROD		1	
33	819111216	WASHER		1	
34	810040500	WASHER		1	
35	873540500	NUT		1	
36	532155105	BUSHING		1	
37	532152927	SCREW		1	
38	532172093	COVER		1	
40	532124701	NUT		1	
41	532159945	ADAPTER		1	
42	532177149	BOOT		1	
43	532121749	WASHER		1	
46	532121232	HUB CAP		1	
65	532160367	SPACER		1	
67	872140618	BOLT		1	
68	532169827	SHAFT		1	
71	532175146	STEERING GEAR		1	
72	819182411	WASHER		1	
73	532181449	EXTENSION		1	
82	532169835	BRACKET		1	
87	532173966	WASHER		1	
88	532175118	BOLT		1	
91	532175553	SPRING		1	

REPAIR PARTS


TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78
CHASSIS AND ENCLOSURES



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532174619	FRAME		1	
2	532176554	PLATE		1	
3	817060612	SCREW		1	
9	532177144	DASHBOARD		1	
10	872140608	BOLT		1	
11	532167203	PLATE		1	
13	532178298	PANEL		1	
14	817490608	SCREW		1	
17	532181351	HOOD		1	
20	532162026	PLATE		1	
26	873800600	NUT		1	
28	532181352	GRILE		1	
29	532179761	LENS		1	
30	532181353	FENDER		1	
31	532139976	BRACKET		1	
37	817490508	SCREW		1	
38	532175710	BRACKET		1	
54	532161464	SCREW		1	
58	532175351	DUCT		1	
59	532177579	BUSHING		1	
60	872140606	BOLT		1	
64	532174997	DASH		1	
74	873680600	NUT		1	
142	532175702	PLATE		1	
143	532154966	BRACKET		1	
144	532175582	BRACKET		1	
145	532156524	SHAFT		1	
154	532161897	BRACKET		1	
155	532161900	BRACKET		1	
156	532163805	PIN RETAINING SCREW		1	
157	532163806	PIN RETAINING SCREW		1	
158	532162037	BRACKET		1	
159	532181355	CUPHOLDER		1	
161	532164655	ABSORBER		1	
166	532171875	SCREW		1	
206	532170165	BOLT		1	
209	817000612	SCREW		1	

REPAIR PARTS

TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78
DECALS




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532181566	DECALC.VOLUTE MOTEUR		1	
2	532170565	DECAL		1	
3	532179639	DECAL		1	
4	532179640	DECAL		1	
5	532145005	DECAL		1	
6	532180433	DECAL		1	
7	532141761	DECAL		1	
8	532145498	DECAL		1	
9	532162927	DECAL		1	
10	532182166	DECAL		1	
11	532176909	DECAL		1	
12	532140837	DECAL		1	
13	532145437	DECAL		1	
14	532159736	DECAL		1	
15	532175291	DECAL		1	
16	532178302	DECAL		1	
17	532159737	DECAL		1	
-	532162598	DECAL		1	
-	532138311	DECAL		1	
-	532169210	DECAL		1	
-	532181447	PLATE		1	
-	532181448	PLATE		1	
-	532180056	OPERATORS MANUAL		1	
-	532180057	OPERATORS MANUAL		1	

GPL®

REPAIR PARTS

**TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78
DRIVE**




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
6	817060512	SCREW		1	
9	532174367	CLUTCH		1	
15	874490544	SCREW		1	
16	873800500	LOCK NUT		1	
17	532126197	WASHER		1	
19	873800600	NUT		1	
20	532173937	BOLT		1	
21	532181454	KNOB		1	
22	532175896	ROD		1	
24	873350600	NUT		1	
25	532106888	SPRING		1	
26	819131316	WASHER		1	
27	876020412	SPLIT PIN		1	
28	532175765	SHAFT		1	
29	532071673	COVER		1	
30	532169592	BRACKET		1	
32	874760512	BOLT		1	
33	872140506	BOLT		1	
34	532175578	SHAFT		1	
35	532120183	BEARING		1	
36	819211616	WASHER		1	
37	532124963	PIN RETAINING SCREW		1	
38	532179114	PULLEY		1	
39	874760648	BOLT		1	
41	532175556	BELT GUIDE		1	
47	532127783	PULLEY		1	
48	532154407	GUIDE		1	
49	532123205	BELT GUIDE		1	
50	872110612	BOLT		1	
51	873680600	NUT		1	
52	873680500	NUT		1	
53	532105710	LINK		1	
55	532105709	SPRING		1	
56	817060620	SCREW		1	
57	532140294	BELT		1	
59	532169691	BELT GUIDE		1	
61	817120614	SCREW		1	
62	532124872	PEDAL RUBBER		1	
63	532175417	PULLEY		1	
65	810040700	WASHER		1	
66	532154778	TENSIONER		1	
74	532137057	SPACER		1	
75	532121749	WASHER		1	
76	812000001	RETAINER RING		1	
77	532123583	KEY		1	
78	532121748	WASHER		1	
89	532181453	CONSOLE		1	
90	532124346	NUT		1	
95	532180825	ROD		1	
96	532124788	RETAINER RING		1	
116	872140608	BOLT		1	
120	873900600	NUT		1	
150	532175456	SPACER		1	
151	819133210	WASHER		1	
202	872110614	BOLT		1	
212	532145212	NUT		1	
214	532174735	LINK		1	
215	532175646	COVER		1	
217	532179433	PEDAL		1	
218	532174713	LINK		1	
219	532174839	BRACKET		1	
220	532174711	BRACKET		1	
221	872140606	BOLT		1	
222	873680700	NUT		1	
223	532174840	WASHER		1	
224	532174736	PEDAL		1	
225	532174712	LINK		1	
226	532174902	BOLT		1	
227	532174710	CAM		1	
228	532179032	BOLT		1	
229	532176451	WASHER		1	
231	532174573	STRAP		1	
232	532175570	ACTIVATER		1	
233	532174856	PAWL		1	
234	532174858	LEVER		1	
235	532174857	PAWL		1	
236	532128903	BOLT		1	
237	532170165	BOLT		1	

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
238	532175807	LEVER		1	
239	817490508	SCREW		1	
240	532175610	SPRING		1	
241	873930400	NUT		1	
242	874780412	BOLT		1	
243	532178289	BRACKET		1	
244	532166880	SCREW		1	
250	817060612	SCREW		1	
253	532179422	WASHER		1	
254	532178062	CLIP		1	



REPAIR PARTS

TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78
ELECTRICAL




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532144927	BATTERY		1	
2	874760412	BOLT		1	
8	532124886	BATTERIE TRAY		1	
10	532145211	BOLT		1	
11	532150109	HOLDER		1	
12	532145769	NUT		1	
16	532176138	MICRO SWITCH		1	
21	532175688	HARNESS		1	
22	532004152	BULB		1	
24	532008860	CABLE		1	
25	532146148	CABLE		1	
26	532175158	FUSE		1	
27	873510400	NUT		1	
28	532145491	CABLE		1	
29	532160784	SWITCH		1	
30	532175566	SWITCH		1	
33	532140401	KEY		1	
40	532179735	HARNESS		1	
41	817720408	SCREW		1	
42	532131563	COVER		1	
43	532178861	SOLENOID		1	
48	532140844	ADAPTER		1	
50	532174651	SWITCH		1	
52	532141940	WIRE		1	
55	817490508	SCREW		1	
79	532175242	HOLDER		1	
81	532109748	RELAY		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78
ENGINE




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532178385	THROTTLE TRIGGER		1	
4	532149723	MUFFLER		1	
5	532159955	TUBE		1	
6	532160589	TUBE		1	
8	532171877	BOLT		1	
10	532162797	SHIELD		1	
13	532165391	GASKET		1	
14	532148456	TUBE		1	
16	811050600	WASHER		1	
17	817490624	SCREW		1	
23	532169837	HEAT SHIELD		1	
25	532178639	CHOKE CONTROL		1	
26	873920600	NUT		1	
29	532137180	SPARK ARRESTER KIT		1	
31	532157103	TANK		1	
32	532140527	FUEL CAP		1	
33	532123487	HOSE CLAMP		1	
34	532106082	SPACER		1	
37	532142158	FULE LINE		1	
38	532181654	PLUG		1	
39	532109227	PAD		1	
45	817000612	SCREW		1	
62	810040500	WASHER		1	
72	871070512	BOLT		1	
81	873510400	NUT		1	
102	532171875	SCREW		1	

GPL®

REPAIR PARTS

TRACTOR - MODEL NUMBER LT19A (JLT19H48C), PRODUCT NO. 954 13 00-78

WHEELS & TIRES



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	532059192	CAP VALVE		1	
2	532065139	NIPPLE		1	
3	532106222	TIRE		1	
4	532059904	HOSE		1	
5	532138336	RIM		1	
6	532124957	FITTING		1	
7	532124959	BEARING		1	
8	532138337	RIM SPROCKET		1	
9	532122082	TIRE		1	
10	532124926	HOSE		1	
11	532175039	HUB CAP		1	
--	532144334	SEALING FOAM		1	

