

# LT19538

**Spare parts**

**Ersatzteile**

**Pièces détachées**


**Reserve onderdelen**

**Repuestos**

**Reservdelar**




TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70  
DECALS **27**



| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 1       | 532 40 03-89 | Decal, Operators            |
| 2       | 532 42 91-96 | Decal, Hood                 |
| 3       | 532 19 68-41 | Decal, Warning Eng. Symbols |
| 4       | 532 43 39-87 | Decal, Hood Panel           |
| 5       | 532 15 97-36 | Decal, Chassis Hot Muffler  |
| 6       | 532 12 44-33 | Decal, 80 DBA               |
| 7       | 532 18 21-66 | Decal, Cutfinger CE         |
| 8       | 532 16 88-69 | Decal, Tick Mark            |
| 9       | 532 14 50-05 | Decal, Battery Dnge/Poi     |

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 10      | 532 14 08-37 | Decal, Saddle Brake Parking   |
| 11      | 532 19 63-57 | Decal, Warning                |
| 12      | 532 19 43-02 | Decal, Mower V-Belt Schematic |
| 13      | 532 15 97-37 | Decal, Brake/Clutch Symbol    |
| 14      | 532 43 70-94 | Decal, Replacement            |
| --      | 532 41 08-05 | Pad, Footrest, LH             |
| --      | 532 41 10-56 | Pad, Footrest, RH             |
| --      | 532 16 25-98 | Decal, Drawbar Load Limit     |
| --      | 532 43 44-61 | Manual Oper. English          |

## WHEELS AND TIRES




| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                    |
| 2       | 532 06 51-39 | Stem Valve                        |
| 3       | 532 13 83-36 | Rim Asm 6" Front                  |
| 4       | 532 05 99-04 | Tube Front                        |
| 5       | 532 10 62-22 | Tire F T 15 x 6 0 - 6             |
| 6       | 532 12 49-57 | Fitting Grease (Front Wheel Only) |
| 7       | 532 12 49-59 | Bearing Flange (Front Wheel Only) |
| 8       | 532 17 50-39 | Cap Axle Blk 1 50 x 1 00          |
| 9       | 532 42 05-31 | Tire R 18 x 9.5-8 Turf Saver LT   |
| 10      | 532 12 49-26 | Tube Rear                         |
| 11      | 532 13 83-37 | Rim Asm 8" Rear                   |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. Tube)       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70  
SCHEMATIC 38



SCH11

NOTE  
YOUR TRACTOR IS  
EQUIPPED WITH A SPECIAL  
ALTERNATOR SYSTEM.  
THE LIGHTS ARE NOT  
CONNECTED TO THE  
BATTERY, BUT HAVE THEIR  
OWN ELECTRICAL SOURCE.  
BECAUSE OF THIS, THE  
BRIGHTNESS OF THE LIGHTS  
WILL CHANGE WITH ENGINE  
SPEED. AT IDLE THE LIGHTS  
WILL DIM. AS THE ENGINE IS  
SPEEDED UP, THE LIGHTS  
WILL BECOME THEIR  
BRIGHTEST.




IGNITION SWITCH

| POSITION     | CIRCUIT "MAKE" |
|--------------|----------------|
| OFF          | M+G+A1         |
| RUN/OVERRIDE | B+A1           |
| RUN          | B+A1 L+A2      |
| START        | B + S + A1     |



CHASSIS HARNESS  
CONNECTOR  
(MATING SIDE)



DASH HARNESS  
CONNECTOR  
(MATING SIDE)

WIRING INSULATED CLIPS  
NOTE: IF WIRING INSULATED  
CLIPS WERE REMOVED FOR  
SERVICING OF UNIT, THEY  
SHOULD BE RE-INSTALLED TO  
PROPERLY SECURE YOUR  
WIRING.


NON-REMOVABLE  
CONNECTIONS

REMOVABLE  
CONNECTIONS



TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70  
ELECTRICAL **32**

T02S

With 12V Outlet Option



With Service Minder Option



**TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70**  
**ELECTRICAL 32**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                     |
|------------|--------------|---------------------------------|
| 1          | 532 16 34-65 | Battery                         |
| 2          | 874 76 04-12 | Bolt Hex Head 1/4-20 x 3/4      |
| 8          | 532 19 32-28 | Box Battery                     |
| 16         | 532 17 61-38 | Switch Interlock Push-In        |
| 21         | 532 40 02-52 | Harness Socket Light w/4152J    |
| 22         | 532 00 41-52 | Bulb Light                      |
| 25         | 532 41 28-94 | Cable Starter                   |
| 26         | 532 17 51-58 | Fuse                            |
| 27         | 873 51 04-00 | Nut Keps Hex 1/4-20 unc         |
| 28         | 532 19 88-85 | Cable,Ground                    |
| 29         | 532 40 15-45 | Switch, Seat                    |
| 30         | 532 19 33-50 | Switch, Ign                     |
| 33         | 532 41 19-33 | Key, Ignition                   |
| 34         | 532 11 07-12 | Switch Light/Reset              |
| 40         | 532 40 10-98 | Harness Ign. Dash               |
| 41         | 817 72 04-08 | Screw Thd Cut 1/4-20 x 1/2      |
| 42         | 532 13 15-63 | Cover, Terminal                 |
| 43         | 532 19 25-07 | Solenoid                        |
| 46         | 532 40 17-63 | Gauge Hourmeter                 |
| 55         | 817 06 05-12 | Screw Thdrol 5/16-18 x 3/4 TYTT |
| 71         | 532 40 04-49 | Harness Chassis                 |
| 79         | 532 17 52-42 | Socket Asm                      |
| 87         | 532 19 78-02 | Switch Interlock Clutch Cable   |
| 90         | 532 40 07-25 | Cover Terminal                  |
| 92         | 532 19 66-15 | Harness Pigtail Reverse Switch  |
| 93         | 532 19 25-40 | Screw Plastite 10-14 x 2.0      |
| 94         | 532 19 18-34 | Module Reverse ROS              |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm


## CHASSIS AND ENCLOSURES 39



**TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70**  
**CHASSIS AND ENCLOSURES 39**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                     |
|------------|--------------|---------------------------------|
| 3          | 532 40 50-12 | Logo                            |
| 5          | 532 40 75-92 | Dash                            |
| 14         | 532 41 10-73 | Hood                            |
| 15         | 532 41 10-79 | Lens LH                         |
| 18         | 532 42 69-63 | Grille                          |
| 25         | 532 41 10-78 | Lens RH                         |
| 34         | 532 19 61-25 | Plate Engine                    |
| 36         | 817 06 05-12 | Screw 5/16-18 x 3/4             |
| 37         | 532 41 63-07 | Fender                          |
| 52         | 873 68 05-00 | Nut Crown Lock 5/16             |
| 58         | 532 41 22-80 | Drawbar, Upper                  |
| 68         | 817 49 05-08 | Screw THDROL 5/16-18 x 1/2      |
| 130        | 532 41 63-58 | Screw 10 x .750 BOSThread       |
| 137        | 532 40 75-90 | Bumper Dash                     |
| 150        | 532 40 66-62 | Air Duct                        |
| 151        | 532 40 78-07 | Bracket Pivot                   |
| 152        | 532 19 95-35 | Shield Browning                 |
| 159        | 817 00 06-12 | Screw 3/8-7/16 x 3/4            |
| 162        | 532 14 24-32 | Screw                           |
| 175        | 532 19 94-72 | Crossmember                     |
| 176        | 532 40 07-76 | Screw 10-24 x 5/8               |
| 177        | 532 19 52-28 | Bushing Steering                |
| 180        | 532 41 50-63 | Chassis                         |
| 182        | 532 40 71-76 | Dash Lower                      |
| 183        | 874 52 05-20 | Bolt 5/16-18 x 1-1/4            |
| 189        | 817 00 05-12 | Screw 5/16-18 x 3/4             |
| 191        | 532 41 65-00 | Insert Reflective RH            |
| 194        | 873 90 05-00 | Nut Lock Hex Flange 5/16-18     |
| 199        | 532 41 34-85 | Plate Deck Lift                 |
| 202        | 532 41 10-75 | Vent Side Hood RH               |
| 203        | 532 41 10-74 | Vent Side Hood LH               |
| 204        | 532 41 11-16 | Vent Top Hood                   |
| 205        | 532 41 10-76 | Skirt Side RH                   |
| 206        | 532 41 10-77 | Skirt Side LH                   |
| 213        | 874 76 05-12 | Bolt 5/16-18 x 3/4              |
| 214        | 532 19 91-45 | Clip Retainer                   |
| 217        | 532 40 91-67 | Rod Pivot Hood                  |
| 218        | 532 19 63-95 | X-Piece Hood Stop               |
| 228        | 532 19 51-61 | Stud Fastener                   |
| 234        | 532 40 47-42 | Bumper Hood                     |
| 235        | 532 40 61-29 | Spacer Fender                   |
| 236        | 873 93 05-00 | Nut Lock 5/16-18 unc            |
| 238        | 532 41 11-19 | Trim                            |
| 239        | 532 40 48-83 | Clip Tinnerman                  |
| 282        | 532 41 41-10 | Clip Retainer Console           |
| 283        | 532 41 63-16 | Console Deck Lift               |
| 284        | 532 41 63-14 | Console Shift                   |
| 285        | 532 41 63-15 | Console Insert RH               |
| 286        | 532 41 63-17 | Console Insert LH               |
| 287        | 817 60 04-06 | Screw Hex Washhead 1/4-20 x 3/8 |
| 297        | 532 40 66-65 | Insert Reflective LH            |
| - - -      | 532 43 18-83 | Kit Bumper                      |


**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



**TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70**  
**DRIVE 40**

| KEY NO. | PART NO.     | DESCRIPTION                    | KEY NO. | PART NO.     | DESCRIPTION                      |
|---------|--------------|--------------------------------|---------|--------------|----------------------------------|
| 1       | -----        | Transaxle, Peerless 206-565    | 165     | 532 19 62-12 | Bushing Shaft Brake Hand Control |
| 2       | 532 12 35-83 | Key Square                     | 166     | 532 42 91-64 | Nut Push .625                    |
| 15      | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga.  | 167     | 532 40 52-57 | Latch Brake Parking              |
| 17      | 532 19 72-97 | Spring, Brake                  | 172     | 532 19 76-57 | Strap Torque LH                  |
| 22      | 532 19 76-60 | Rod Shift                      | 174     | 532 19 72-89 | Nut Push                         |
| 23      | 532 12 12-74 | Knob Duckhead 1/2-13           | 175     | 532 19 78-58 | Shaft Asm. Shift                 |
| 26      | 532 19 74-55 | Spring Brake Return            | 176     | 532 19 62-14 | Arm Clevis Rod Shift             |
| 29      | 532 19 72-67 | Rod, Brake                     | 178     | 532 19 74-56 | Spring Shift                     |
| 33      | 812 00 00-01 | Ring E                         | 183     | 532 13 70-57 | Spacer Axle                      |
| 35      | 532 40 10-31 | Rod, Brake, Park               | 184     | 532 40 97-47 | Knob                             |
| 37      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.  | 185     | 872 11 06-22 | Bolt                             |
| 42      | 532 12 48-72 | Cover, Foot Pedal              | 186     | 532 19 43-21 | Spacer Retainer                  |
| 49      | 872 11 06-14 | Bolt                           | 187     | 819 13 32-10 | Washer                           |
| 50      | 532 19 43-27 | Pulley Idler Flat              | 188     | 532 19 43-23 | Link Clutch Ground Drive         |
| 51      | 873 90 06-00 | Lock Nut 3/8-16                | 189     | 532 19 43-17 | Bellcrank Ground Drive           |
| 52      | 532 19 43-26 | Idler V-Groove                 | 190     | 532 19 43-18 | Keeper Bellcrank Ground Drive    |
| 56      | 532 19 43-46 | V-Belt, Drive                  | 192     | 532 15 03-60 | Nut Lock Center 1/4-28 Fnthd     |
| 61      | 532 12 36-66 | Pulley transaxle               | 193     | 817 06 05-12 | Screw 5/16-18 x 3/4              |
| 64      | 532 19 62-00 | Shaft Asm. Pedal Brake Control | 195     | 532 19 73-32 | Bracket Brake Rod                |
| 73      | 874 49 05-44 | Belt 5/16-18 Gr. 5             | 202     | 532 19 78-59 | Link Transaxle                   |
| 116     | 873 90 05-00 | Nut Lock Hex Flange 5/16-18    | 203     | 819 11 11-16 | Washer 11/32 x 11/16 x 16 Ga.    |
| 125     | 817 00 05-12 | Screw 5/16-18 x 3/4            | 205     | 532 12 17-48 | Washer 25/32 x 1-5/8 16 Ga.      |
| 134     | 532 19 78-57 | Asm Shift                      | 221     | 532 40 31-87 | Retainer Spring Clip Handle      |
| 139     | 874 55 04-12 | Bolt 1/4-28 unf Gr. 8 w/Patch  | 232     | 874 78 07-16 | Bolt Fin Hex 7/16-14 x 1 Gr 5    |
| 140     | 810 04 04-00 | Washer Lock Hvy Helical 1/4    | 233     | 532 40 52-96 | Washer Serrated                  |
| 141     | 819 09 12-10 | Washer 9/32 x 3/4 x 10 Ga.     |         |              |                                  |
| 155     | 812 00 00-28 | Ring Retainer                  |         |              |                                  |
| 157     | 532 10 57-01 | Washer Plate Shift             |         |              |                                  |
| 158     | 532 19 43-52 | Belt Keeper                    |         |              |                                  |
| 159     | 876 02 04-12 | Pin Cotter 1/8 x 3/4           |         |              |                                  |
| 160     | 532 16 94-84 | Retainer Clip                  |         |              |                                  |
| 161     | 532 10 57-09 | Spring, Return, Clutch         |         |              |                                  |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



**OPTIONAL EQUIPMENT**

**Spark Arrester**

engine-tex\_BS\_28

**TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70  
ENGINE [24]**


| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                         |
|------------|--------------|-------------------------------------|
| 1          | - - - - -    | Engine B&S Model No. 31Q677-1493-B1 |
| 2          | 532 13 73-52 | Muffler                             |
| 9          | 532 19 43-19 | Keeper Belt Engine                  |
| 12         | 532 40 19-85 | Pulley Engine                       |
| 15         | 532 40 75-45 | Tank Fuel 1.5                       |
| 18         | 532 43 02-20 | Cap Asm                             |
| 20         | 532 18 38-97 | Control Throttle                    |
| 21         | 532 41 63-58 | Screw #10 x 0.075                   |
| 28         | 532 13 70-40 | Fuel Line                           |
| 29         | 532 13 71-80 | Spark Arrester Kit                  |
| 37         | 532 12 34-87 | Clamp Hose                          |
| 42         | 810 04 07-00 | Washer Split                        |
| 45         | 873 51 04-00 | Nut Keps Hex 1/4-20 unc             |
| 69         | 532 16 52-91 | Gasket                              |
| 79         | 532 19 23-34 | Screw 5/16-18 x .75                 |
| 84         | 817 06 06-20 | Screw 3/8-16 x 1-1/4                |
| 85         | 532 17 39-37 | Bolt Hex 7/16-20 x 4 Gr. 5          |
| 90         | 817 00 06-16 | Screw 3/8-16 x 1                    |
| 96         | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.          |
| 97         | 817 67 04-12 | Screw 1/4-20 x 3/4                  |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

### Engine Power Rating Information

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J1940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-05). Torque values are derived at 3060 RPM; horsepower values are derived at 3600 RPM. Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net power). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70  
STEERING ASSEMBLY **41**




steering-tex\_special\_33\_w118\_r2

**TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70**  
**STEERING ASSEMBLY 41**

| KEY NO. | PART NO.     | DESCRIPTION                         |
|---------|--------------|-------------------------------------|
| 1       | 532 41 64-80 | Wheel, Steering                     |
| 2       | 532 41 35-91 | Axle Asm., Front                    |
| 4       | 532 40 30-87 | Spindle Asm., LH                    |
| 5       | 532 40 30-88 | Spindle Asm., RH                    |
| 6       | 532 12 49-31 | Washer .75 x 1.230, Thrust          |
| 7       | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.       |
| 8       | 812 00 00-29 | Ring, clip #T5304-75                |
| 9       | 532 12 12-32 | Cap, Spindle                        |
| 13      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.       |
| 14      | 810 04 06-00 | Washer, Lock Hvy Hlcl Spr 3/8       |
| 15      | 873 54 06-00 | Nut, Crown Lock 3/8-24 unf          |
| 16      | 532 42 93-73 | Shaft Steering                      |
| 19      | 532 19 47-29 | Plate Steering                      |
| 20      | 532 41 11-39 | Boot, Steering                      |
| 21      | 532 18 67-37 | Adapter, Wheel Steering             |
| 22      | 532 42 05-37 | Steering Support Lower              |
| 26      | 532 41 59-87 | Insert, Wheel Steering              |
| 28      | 817 00 06-12 | Screw 3/8-16 x 3/4                  |
| 33      | 810 04 05-00 | Washer Lock 5/16                    |
| 35      | 532 19 47-32 | Gear, Sector Plate                  |
| 45      | 819 11 38-12 | Washer 11/32 x 3/8 x 12 Ga.         |
| 53      | 532 18 89-67 | Washer Hardened .793 x 1.637 x .060 |
| 57      | 532 40 74-65 | Bracket Upstop                      |
| 58      | 532 19 47-47 | Bolt Shoulder Sector Pivot CFM      |
| 59      | 532 19 47-48 | Washer Thrust Sector Steering       |
| 60      | 873 97 10-00 | Nut Flange Lock 5/8-11              |
| 61      | 532 19 47-40 | Draglink, LH                        |
| 62      | 532 19 47-41 | Draglink, RH                        |
| 63      | 817 00 05-12 | Screw 5/16-18 x 3/4                 |
| 64      | 532 19 98-49 | Retainer Clip Spring Steering       |
| 66      | 871 02 07-48 | Bolt Hex Fghd 7/16-14 x 3 Serr      |
| 67      | 532 19 47-37 | Bushing PM Front Axle               |
| 68      | 873 90 07-00 | Nut Lock Flange 7/16-14 Gr. 5       |
| 69      | 532 19 91-62 | Washer 1.5 x .505 x .118            |
| 70      | 532 19 61-97 | Bracket Deck Susp. Front            |
| 71      | 532 19 07-52 | Shaft Extension Steering            |
| 72      | 532 42 89-82 | Bolt Fin Hex 5/16-18 x 4 w/Patch    |
| 118     | 532 40 60-13 | Bushing                             |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70  
MOWER DECK **44**




38-8\_Tex-LT\_1\_r4

**TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70**  
**MOWER DECK 44**

| KEY NO. | PART NO.     | DESCRIPTION                        | KEY NO. | PART NO.     | DESCRIPTION                                                                                                                   |
|---------|--------------|------------------------------------|---------|--------------|-------------------------------------------------------------------------------------------------------------------------------|
| 1       | 532 43 45-67 | Mower Housing                      | 59      | 532 14 10-43 | Guard, Tuv Idler                                                                                                              |
| 6       | 532 19 51-86 | Arm Suspension                     | 60      | 532 19 94-71 | Arm Brake Mower                                                                                                               |
| 7       | 532 41 63-58 | Screw #10 x 0.750 BOS Thread       | 63      | 532 19 94-70 | Arm Brake Mower                                                                                                               |
| 8       | 532 19 30-03 | Bolt/Washer Asm 7/16-20 unf        | 64      | 532 19 97-90 | Link Brake                                                                                                                    |
| 11      | 532 13 84-97 | Blade                              | 67      | 532 40 30-12 | Handle Clutch Cable                                                                                                           |
| 13      | 532 19 28-72 | Shaft Assembly Mandrel             | 68      | 532 40 83-81 | V-Belt                                                                                                                        |
| 14      | 532 18 72-81 | Housing Mandrel                    | 69      | 872 14 05-05 | Bolt                                                                                                                          |
| 15      | 532 11 04-85 | Bearing, Ball, Mandrel             | 70      | 532 40 12-46 | Clutch Asm Manual                                                                                                             |
| 19      | 532 19 65-39 | Bolt, Shoulder                     | 115     | 872 11 05-05 | Bolt 5/16-18 x 5/8                                                                                                            |
| 21      | 873 68 05-00 | Nut, Crownlock 5/16-18 unc         | 122     | 532 19 72-58 | Keeper Belt Engine LH                                                                                                         |
| 23      | 532 19 25-57 | Bracket, Deflector                 | 123     | 532 19 72-59 | Keeper Belt Engine RH                                                                                                         |
| 24      | 532 10 53-04 | Cap, Sleeve                        | 144     | 532 19 34-14 | Keeper Belt                                                                                                                   |
| 25      | 532 19 70-26 | Spring, Torsion, Deflector         | 145     | 532 19 31-97 | Pulley Idler                                                                                                                  |
| 26      | 532 11 04-52 | Nut, Push                          | 147     | 532 40 18-72 | Spring Return                                                                                                                 |
| 27      | 532 19 39-68 | Shield, Deflector                  | 152     | 532 43 51-11 | Manual Clutch Cable                                                                                                           |
| 29      | 532 13 14-91 | Rod, Hinge                         | 188     | 532 19 51-61 | Stud Fastener                                                                                                                 |
| 30      | 532 17 39-84 | Screw Thdrol Rolling Wsh Hd        | 189     | 873 90 05-00 | Nut Lock Hex Flange                                                                                                           |
| 31      | 532 18 76-90 | Washer, Spacer                     | 195     | 817 00 06-12 | Screw 3/8-16 x 3/4                                                                                                            |
| 32      | 532 19 97-89 | Pulley, Mandrel                    | 199     | 532 40 00-95 | Baffle Vortex                                                                                                                 |
| 33      | 532 40 02-34 | Nut, Toplock, Flanged              | 209     | 819 13 32-10 | Washer 13/32 x 2 x 10                                                                                                         |
| 34      | 872 11 06-12 | Bolt Carr Sh. 3/8-16 x 1-1/2 Gr. 5 | 241     | 532 15 29-27 | Screw                                                                                                                         |
| 37      | 819 13 13-16 | Washer                             | 242     | 532 41 55-98 | Port Washout                                                                                                                  |
| 38      | 532 19 95-41 | Keeper Belt LH Mandrel             | --      | 532 19 28-70 | Mandrel Assembly (Includes housing, shaft assembly, and bearing only - pulley/nut/washer and blade bolt/washers not included) |
| 40      | 873 90 06-00 | Nut, Lock Flg. 3/8-16 unc          | --      | 532 43 44-67 | Replacement Mower, Complete                                                                                                   |
| 42      | 532 19 84-10 | Spring Torsion Brake               |         |              |                                                                                                                               |
| 43      | 532 19 72-56 | Spring Torsion Retainer            |         |              |                                                                                                                               |
| 46      | 532 13 77-29 | Screw 1/4-20 x 5/8                 |         |              |                                                                                                                               |
| 55      | 532 19 72-49 | Arm, Idler                         |         |              |                                                                                                                               |
| 56      | 532 19 90-92 | Spacer, Retainer                   |         |              |                                                                                                                               |
| 57      | 817 00 06-16 | Screw 3/8-16 x 1                   |         |              |                                                                                                                               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70**  
**MOWER LIFT 45**




| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 2       | 532 42 20-27 | Shaft Asm., Lift             |
| 3       | 532 19 52-31 | Lever Asm., Lift RH          |
| 7       | 532 41 15-55 | Grip, Lever                  |
| 10      | 532 19 63-14 | Spring Torsion               |
| 87      | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock |
| 88      | 532 41 07-10 | Spring Lift Assist           |
| 89      | 819 19 19-12 | Washer Clear Zinc            |
| 90      | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock |
| 91      | 532 19 51-81 | Link Lift Susp Mower Rear    |

| KEY NO. | PART NO.     | DESCRIPTION                      |
|---------|--------------|----------------------------------|
| 97      | 817 00 06-12 | Screw 3/8-16 x .75 Smgml Tap/R.Z |
| 98      | 532 19 52-70 | Link Lift Susp. Front Mower      |
| 100     | 873 93 06-00 | Nut Centerlock 3/8-16            |
| 101     | 532 40 70-03 | Link Asm. Lift                   |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LT19538 (96041017001), PRODUCT NO. 960 41 01-70**  
**SEAT ASSEMBLY 42**



seat-tex\_6.5SL\_1\_r1

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 1       | 532 42 40-67 | Seat                          |
| 2       | 532 18 01-66 | Bracket Pivot Fender          |
| 3       | 532 14 06-75 | Strap, Asm Fender             |
| 6       | 873 80 06-00 | Nut, Lock w/Ins. 3/8-16 unc   |
| 7       | 532 12 41-81 | Spring, Seat Cprsn            |
| 8       | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems |
| 10      | 532 19 69-77 | Pan, Seat                     |
| 21      | 532 17 18-52 | Bolt, Shoulder 5/16-18        |

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 37      | 873 80 05-00 | Nut, Lock 5/16-18 unc         |
| 40      | 532 19 76-61 | Handle Slide                  |
| 41      | 532 19 82-00 | Spring Latch                  |
| 43      | 874 76 06-12 | Bolt 3/8-16 unc x 3/4         |
| 44      | 819 13 38-12 | Washer 13/32 x 2-3/8 x 12 Ga. |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

