

# LT2216CM

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar




# ILLUSTRATED PARTS LIST

**MFG. ID NO. 96061019400**

**CUSTOMER CATALOG NO. LT2216CM**


**PRODUCT NO. 960 61 01-94**



408672

# REPAIR PARTS


TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
DECALS



| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 1       | 532 40 03-89 | Decal Warning Sym. CE         |
| 2       | 532 19 68-41 | Decal Warning Eng. Sym.       |
| 3       | 532 18 95-53 | Decal Hood                    |
| 4       | 532 40 86-72 | Decal Replacement             |
| 5       | 532 18 57-73 | Decal Wheel Steering          |
| 6       | 532 18 04-32 | Decal 100 DBA                 |
| 7       | 532 40 85-33 | Decal Side Panel              |
| 9       | 532 18 39-30 | Decal Fender Logo             |
| 10      | 532 14 50-05 | Decal Bat Dan/Poi P/L Sym Wpn |
| 11      | 532 18 21-66 | Decal Mower Cut Finger Symbol |

| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 12      | 532 15 97-37 | Decal Brake/Clutch Symbol Lt |
| 13      | 532 18 39-31 | Decal Bagger                 |
| 14      | 532 15 97-36 | Decal Chassis Hot Muffler    |
| 15      | 532 40 91-50 | Decal Engine HP              |
| 16      | 532 19 68-42 | Decal Warning Cutfinger      |
| 17      | 532 14 08-37 | Decal Saddle Brake Parking   |
| 21      | 532 16 62-86 | Decal Hex Belt Sch 92 CRD    |
| --      | 532 13 83-11 | Decal Lift Handle            |
| --      | 532 18 10-90 | Pad Footrest RH              |
| --      | 532 18 10-91 | Pad Footrest LH              |
| --      | 532 40 83-03 | Manual Operator's (Euro)     |


## WHEELS & TIRES



| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                  |
| 2       | 532 06 51-39 | Stem Valve                      |
| 3       | 532 10 62-22 | Tire F Ts 15 x 6 0 - 6 Service  |
| 4       | 532 05 99-04 | Tube Inner Front #35060         |
| 5       | 532 13 83-36 | Rim Asm 6" front Silver Service |
| 6       | 532 12 49-57 | Fitting Grease                  |
| 7       | 532 12 49-59 | Bearing Flange                  |
| 8       | 532 13 83-37 | Rim Asm 8"rear Silver Service   |
| 9       | 532 10 62-68 | Tire R Ts 18 x 8.5-8 Service    |
| 10      | 532 12 49-26 | Tube Rear 9 5 x 8 Service       |
| 11      | 532 17 50-39 | Cap Axle Blk 1 50 x 1 00        |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. tube)     |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm


TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
SCHEMATIC



03050

# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
ELECTRICAL



# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
ELECTRICAL

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                       |
|------------|--------------|-----------------------------------|
| 1          | 532 14 49-27 | Battery                           |
| 2          | 874 76 04-12 | Bolt Hex Hd 1/4-20 unc x 3/4      |
| 16         | 532 17 61-38 | Switch Interlock                  |
| 21         | 532 18 37-59 | Light Harness                     |
| 22         | 532 00 41-52 | Bulb                              |
| 24         | 532 12 47-80 | Cable Starter 6 Ga. 11" Red       |
| 25         | 532 16 59-87 | Cable Battery Crd 56" Red         |
| 26         | 532 17 51-58 | Fuse                              |
| 27         | 873 51 04-00 | Nut Keps Hex 1/4-20 unc           |
| 28         | 532 12 77-25 | Cable Ground 6 Ga. 18" Black      |
| 29         | 532 19 27-49 | Switch Seat                       |
| 30         | 532 19 33-50 | Switch Ignition                   |
| 33         | 532 14 04-01 | Key Ign Molded                    |
| 34         | 532 11 07-12 | Switch Light                      |
| 40         | 532 19 74-36 | Harness Ign                       |
| 41         | 871 11 04-08 | Bolt Flk Fin Hex 1/4-20 unc x 1/2 |
| 42         | 532 13 15-63 | Cover Terminal Red                |
| 43         | 532 19 25-07 | Solenoid                          |
| 48         | 532 14 08-44 | Adapter Ammeter Rectangular       |
| 58         | 532 16 94-19 | Buzzer Crd                        |
| 59         | 532 18 03-79 | Switch FBI CRD                    |
| 66         | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2 Ty-Tt   |
| 81         | 532 10 97-48 | Relay Asm                         |
| 92         | 532 19 66-15 | Harness Pigtail                   |
| 93         | 532 19 25-40 | Screw Plastite 10-14 x 2.0        |
| 94         | 532 19 18-34 | Module Reverse                    |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

**TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
CHASSIS AND ENCLOSURES**



# REPAIR PARTS


## TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94 CHASSIS AND ENCLOSURES

| KEY NO. | PART NO.     | DESCRIPTION                                           | KEY NO. | PART NO.     | DESCRIPTION                            |
|---------|--------------|-------------------------------------------------------|---------|--------------|----------------------------------------|
| 1       | 532 17 46-20 | Chassis                                               | 163     | 532 18 03-83 | Bracket Exten Chassis Rh CRD           |
| 2       | 532 18 03-84 | Drawbar                                               | 164     | 532 16 56-05 | Support Battery CRD                    |
| 3       | 817 06 06-12 | Screw 3/8-16 x 3/4                                    | 165     | 532 18 13-56 | Cover Battery                          |
| 5       | 532 15 52-72 | Bumper Hood/Dash                                      | 170     | 532 19 94-88 | Backplate Asm CRD                      |
| 6       | 532 18 44-19 | Saddle                                                | 171     | 872 14 06-20 | Bolt Rdhd Sqnk<br>3/8-16 x 2-1/2 Gr. 5 |
| 8       | 532 12 64-71 | Clip Insulator 13/32 Mtg. Hole                        | 172     | 819 13 20-16 | Washer 13/32 x 1-1/4 x 16 Ga.          |
| 9       | 532 19 35-18 | Dash                                                  | 173     | 873 51 06-00 | Nut, Keps Hex 3/8-16 unc               |
| 10      | 872 14 06-08 | Bolt, Carriage 3/8-16 x 3/4                           | 175     | 532 18 82-03 | Guard Trap                             |
| 11      | 532 17 49-96 | Panel, Dash, L.H.                                     | 179     | 532 18 82-02 | Rod Pivot FBI CRD                      |
| 13      | 532 17 52-55 | Panel, Asm. Dash R.H.                                 | 184     | 532 17 46-62 | Bracket Actuator Bagger CRD            |
| 15      | 874 18 05-12 | Screw, Machine, Truss Head<br>5/16-18 unc x 3/4       | 185     | 532 18 11-01 | Knob Rod Brake Parking                 |
| 16      | 873 51 05-00 | Nut                                                   | 186     | 532 16 07-93 | Latch Asm Mulch/Bagger                 |
| 17      | 532 19 47-57 | Hood                                                  | 187     | 532 12 50-04 | Nut Weld                               |
| 18      | 532 18 49-21 | Bumper Hood                                           | 188     | 819 06 12-16 | Washer #10                             |
| 24      | 874 78 06-16 | Bolt                                                  | 189     | 810 07 10-00 | Washer Lock #10                        |
| 25      | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga.                         | 190     | 871 08 10-10 | Screw Pan Hd Phillip 10-24 x 5/8       |
| 26      | 873 80 06-00 | Nut                                                   | 198     | 532 16 89-37 | Nut, Push                              |
| 28      | 532 19 29-15 | Grille /Lens Asm (Key #'s 258,<br>259, 261, 263, 264) | 205     | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2              |
| 30      | 532 19 25-33 | Fender                                                | 207     | 817 67 05-08 | Screw 5/16-18 x 1/2                    |
| 31      | 532 16 51-56 | Bracket, Fender Support                               | 208     | 817 67 06-08 | Screw Thdrol 3/8-16 x 1/2              |
| 33      | 532 17 97-16 | Footrest, L.H.                                        | 209     | 817 00 06-12 | Screw Hex Wsh Thdrol 3/8-16            |
| 34      | 532 17 97-17 | Footrest, R.H.                                        | 256     | 532 18 13-61 | Cover Fender                           |
| 35      | 872 11 06-06 | Bolt                                                  | 258     | 532 18 97-55 | Lens Grille RH                         |
| 37      | 817 49 05-08 | Screw Thdrol 5/16-18 x 1/2 TYT                        | 259     | 532 18 97-54 | Lens Grille LH                         |
| 38      | 532 18 17-48 | Bracket Asm Pivot Mower Rear                          | 261     | 532 18 97-53 | Insert Grille                          |
| 39      | 532 40 78-07 | Bracket Pivot                                         | 263     | 532 18 38-33 | Bezel Grille RH                        |
| 58      | 532 18 43-22 | Duct Air                                              | 264     | 532 18 38-32 | Bezel Grille LH                        |
| 69      | 532 14 24-32 | Screw Hex 1/4-1/2 unc                                 | 265     | 532 18 57-04 | Seal RH Side Bagger                    |
| 89      | 532 19 73-66 | Console                                               | 266     | 532 18 57-03 | Seal LH Side Bagger                    |
| 145     | 532 15 65-24 | Rod Pivot Chassis/Hood                                | 278     | 532 19 16-11 | Screw 10 x 3/4 Single Lead Hex         |
| 162     | 532 18 03-82 | Bracket Exten Chassis Lh CRD                          |         |              |                                        |

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
DRIVE



drive-fender\_CRD\_D6800

# REPAIR PARTS


**TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
DRIVE**

| KEY NO. | PART NO.     | DESCRIPTION                                                             | KEY NO. | PART NO.     | DESCRIPTION                          |
|---------|--------------|-------------------------------------------------------------------------|---------|--------------|--------------------------------------|
| 1       | -----        | Transaxle DANA 6800-3<br>(Order parts from transaxle manu-<br>facturer) | 80      | 532 14 50-90 | Arm Shift PMST 20" Tires             |
| 2       | 532 14 66-82 | Spring Brake Return                                                     | 82      | 532 16 57-11 | Spring, Torsion                      |
| 3       | 532 16 59-99 | Pulley Transaxle                                                        | 83      | 819 17 12-16 | Washer 17/32 x 3/4 x 16 Ga.          |
| 4       | 812 00 00-28 | Ring Retainer #5100-62                                                  | 84      | 532 40 73-80 | Link Transaxle                       |
| 5       | 532 12 15-20 | Strap torque 30 degrees                                                 | 96      | 532 12 47-88 | Spring, Retainer 1"                  |
| 6       | 817 06 05-12 | Screw 5/16-18 x 3/4                                                     | 112     | 819 09 12-10 | Washer 9/32 x 3/4 x 10 Ga.           |
| 8       | 532 19 27-06 | Rod Shift                                                               | 120     | 873 90 06-00 | Nut Lock Flg. 3/8-16 unc             |
| 9       | 532 40 85-79 | Clutch Noram                                                            | 150     | 532 16 58-50 | Bushing, Bellcrank Grnd Dr           |
| 10      | 876 02 04-16 | Pin, Cotter 1/8 x 1                                                     | 151     | 819 13 32-10 | Washer 13/32 x 2 x 10 Ga.            |
| 11      | 532 10 57-01 | Washer Plate Shf .3888 sq hole                                          | 156     | 532 16 60-02 | Washer Srrd 5/16 ID x 1.125          |
| 13      | 874 55 04-12 | Bolt 1/4-28 Unf Gr. 8 w/patch                                           | 158     | 532 16 55-89 | Bracket Shift Mount                  |
| 14      | 810 04 04-00 | Washer, Lock Hvy Helical                                                | 159     | 532 18 39-00 | Hub Shift                            |
| 15      | 874 49 05-44 | Bolt Hex Flghd 5/16-18 Gr. 5                                            | 161     | 872 14 04-06 | Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5     |
| 16      | 873 80 05-00 | Nut, Lock Hex w/Ins 5/16-18 unc                                         | 162     | 873 68 04-00 | Nut Crownlock 1/4-20 unc             |
| 18      | 874 78 06-16 | Bolt Hex 3/8-16 unc x 1 Gr. 5                                           | 163     | 874 78 04-16 | Bolt Hex Fin 1/4-20 unc x 1 Gr 5     |
| 19      | 873 80 06-00 | Nut, Lock Hex w/Wsh 3/8-16 unc                                          | 165     | 532 16 56-23 | Bracket Pivot Lever                  |
| 21      | 532 12 12-74 | Knob Duckhead                                                           | 166     | 817 49 05-10 | Screw 5/16-18 x 5/8                  |
| 22      | 532 17 56-07 | Rod, Brake CRD                                                          | 167     | 532 16 55-88 | Bracket Support Shift CRD            |
| 24      | 873 35 06-00 | Nut                                                                     | 168     | 532 16 54-92 | Bolt Shoulder 5/16-18 x .561         |
| 25      | 532 10 68-88 | Spring, Rod, Brake                                                      | 171     | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2 Ty-Tt      |
| 26      | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga.                                           | 172     | 532 40 76-05 | Shaft Asm Shift                      |
| 27      | 876 02 04-12 | Pin, Cotter 1/8 x 3/4                                                   | 177     | 532 16 59-32 | Keeper Flat Idler 3.06" CRD          |
| 28      | 532 17 57-65 | Rod, Parking Brake                                                      | 181     | 532 18 02-11 | Bracket Idler Ground Drive CRD       |
| 29      | 532 07 16-73 | Cap Brake Parking                                                       | 182     | 532 18 26-82 | Keeper Belt 2.5" Od V-Idler CRD      |
| 30      | 532 17 49-73 | Bracket, Mfg. Transaxle                                                 | 183     | 532 19 95-32 | Pulley V-Idler                       |
| 34      | 532 17 55-78 | Shaft, Asm Pedal Foot                                                   | 187     | 817 58 05-20 | Screw 5/16-18 x 1.25                 |
| 35      | 532 12 01-83 | Bearing, Nylon                                                          | 203     | 871 17 07-80 | Bolt Hex 7/16-20 x 5                 |
| 36      | 819 21 16-16 | Washer 21/32 x 1 x 16 Ga.                                               | 207     | 532 16 98-45 | Washer Nylon Rear                    |
| 37      | 532 12 49-63 | Pin, Roll 3/16 x 1"                                                     | 214     | 532 17 56-09 | Shaft Asm Blade                      |
| 38      | 532 16 59-36 | Pulley, Flat                                                            | 215     | 532 19 95-80 | Rod Brake Secondary                  |
| 39      | 874 76 06-44 | Bolt Fin Hex 3/8-16 unc x 2-3/4                                         | 253     | 532 17 50-28 | Bracket Cable Chassis                |
| 40      | 532 12 49-65 | Spacer, Split 395 x 59 Bzp                                              | 254     | 817 00 06-16 | Screw 3/8-16 x 1                     |
| 42      | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga.                                           | 255     | 532 17 56-08 | Brace Shaft Brake Mtg.               |
| 43      | 819 11 10-12 | Washer 11/32 x 5/8 x 12 Ga.                                             | 258     | 532 17 80-62 | Clip Retainer                        |
| 47      | 532 12 77-83 | Pulley, Idler, V Groove Plasitc                                         | 261     | 532 13 14-94 | Pulley Idler                         |
| 48      | 532 15 44-07 | Bellcrank Clutch Grnd Drv                                               | 262     | 872 11 06-22 | Bolt RDHD 3/8-16 unc x 2-3/4<br>Gr.5 |
| 49      | 532 12 32-05 | Retainer, Belt Style Spring                                             | 263     | 817 00 06-12 | Screw 3/8-16 x 3/4                   |
| 50      | 872 11 06-12 | Bolt 3/8-16 unc x 1-1/2                                                 | 264     | 532 19 76-08 | Bracket Clutch Mtg.                  |
| 51      | 873 68 06-00 | Nut, Crownlock 3/8-16 unc                                               | 265     | 532 40 46-07 | Spacer Idler Chassis                 |
| 53      | 532 19 96-52 | Link, Clutch 7.66                                                       | 266     | 532 18 20-61 | Shield Idler Mower                   |
| 55      | 532 10 57-09 | Spring, Return, Clutch                                                  | 268     | 532 18 24-02 | Guard Muffler                        |
| 56      | 817 06 06-20 | Screw 3/8-16 x 1-1/4                                                    | 275     | 819 13 16-14 | Washer 13/32 x 1 x 14 Ga.            |
| 57      | 532 40 50-75 | V-Belt                                                                  | 292     | 532 40 02-71 | Spacer Noram                         |
| 62      | 532 12 48-72 | Cover, Pedal                                                            | 293     | 872 14 06-28 | Bolt RDHD SQNK 3/8-16 x 3-1/2        |
| 65      | 810 04 07-00 | Washer                                                                  | 294     | 532 19 70-33 | Nut Jam 3/8-16                       |
| 66      | 532 15 47-78 | Keeper, Belt Engine F-Proof                                             | 295     | 532 17 91-14 | Pulley Idler                         |
| 75      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.                                           |         |              |                                      |
| 76      | 812 00 00-01 | Ring, E                                                                 |         |              |                                      |
| 77      | 532 12 35-83 | Key, Square                                                             |         |              |                                      |
| 78      | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.                                           |         |              |                                      |
| 79      | 532 12 50-96 | Key Woodruff                                                            |         |              |                                      |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
STEERING ASSEMBLY



steering\_pl.lt\_60\_r1

# REPAIR PARTS


TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
STEERING ASSEMBLY

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                         |
|------------|--------------|-------------------------------------|
| 1          | 532 19 46-37 | Steering Wheel                      |
| 2          | 532 18 47-06 | Front Axle Assembly                 |
| 3          | 532 16 98-40 | Spindle Assembly, L.H.              |
| 4          | 532 16 98-39 | Spindle Assembly, R.H.              |
| 5          | 532 12 49-31 | Washer Thrust .75 X 1.230           |
| 6          | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.       |
| 8          | 812 00 00-29 | Ring, Klip                          |
| 10         | 532 17 51-21 | Link, Drag                          |
| 11         | 810 04 06-00 | Washer, Lock                        |
| 13         | 532 13 65-18 | Spacer Axle                         |
| 15         | 532 14 52-12 | Nut Hex Flange Lock                 |
| 17         | 532 19 07-53 | Shaft Assembly, Steering            |
| 29         | 817 00 06-12 | Screw 3/8-16 x 3/4                  |
| 32         | 532 17 01-62 | Rod, Tie                            |
| 33         | 819 11 12-16 | Washer 11/32 x 3/4 x 16 Ga.         |
| 34         | 810 04 05-00 | Washer Lock Hvy Hlcl Spr 5/16       |
| 35         | 873 54 05-00 | Crownlock Nut 5/16-24 unf           |
| 36         | 532 15 50-99 | Bushing, Steering                   |
| 37         | 532 15 29-27 | Screw TT #10-32 x 5 x 3/8 Flange    |
| 38         | 532 19 46-03 | Cap Wheel Steering                  |
| 39         | 819 11 38-12 | Washer 11/32 ID x 2 3/8 OD x 12 Ga. |
| 40         | 873 54 06-00 | Nut Crownlock 3/8-24 unf            |
| 41         | 532 18 67-37 | Adaptor, Steering Wheel             |
| 42         | 532 16 96-33 | Boot, Steering                      |
| 43         | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.       |
| 44         | 532 19 07-52 | Extension Steering                  |
| 46         | 532 12 12-32 | Cap, Spindle                        |
| 65         | 532 16 03-67 | Spacer Axle                         |
| 67         | 872 11 06-18 | Bolt Rdhd Sq 3/8-16 x 2-1/4         |
| 68         | 532 16 98-27 | Brace Axle                          |
| 71         | 532 17 51-46 | Steering Asm.                       |
| 82         | 532 19 99-78 | Bracket Susp. Chassis Front         |
| 87         | 532 17 39-66 | Washer Flat .781 x 1-1/2 x .14      |
| 88         | 532 17 51-18 | Bolt Shoulder 7/16-20 unc           |
| 91         | 532 17 55-53 | Clip Steering                       |
| 95         | 532 18 89-67 | Washer                              |
| 97         | 874 78 05-64 | Bolt 5/16-18 unc x 4" L Gr. 5       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
SEAT ASSEMBLY



seat\_lt.knob\_7(CRD)

# REPAIR PARTS


TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
SEAT ASSEMBLY

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                     |
|------------|--------------|---------------------------------|
| 1          | 532 19 78-95 | Seat                            |
| 2          | 532 14 05-51 | Bracket Pnt Pivot Fender        |
| 3          | 871 11 06-16 | Bolt Fin Hex 3/8-16 x 1         |
| 4          | 819 13 16-10 | Washer Flat 13/32 x 1 x 10 Ga.  |
| 5          | 532 14 50-06 | Clip Push In Hinged             |
| 6          | 873 80 06-00 | Nut Lock Hex W/Ins 3/8-16       |
| 7          | 532 12 41-81 | Spring Seat Cprsn 2 250 Blk Zi  |
| 8          | 817 00 06-16 | Screw 3/8-16 x 1.5              |
| 9          | 819 13 16-14 | Washer 13/32 x 1 x 14 Ga        |
| 10         | 532 19 55-30 | Pan Pnt Seat                    |
| 11         | 532 16 63-69 | Knob Seat Adj. Wingnut          |
| 12         | 532 17 46 48 | Bracket Pnt Mounting Switch     |
| 13         | 532 12 12-48 | Bushing Snap Blk Nyl 50 Id      |
| 14         | 872 05 04-12 | Bolt Rdhd Sht Nk 1/4-20 x 1-1/2 |
| 15         | 532 13 43-00 | Spacer Split                    |
| 16         | 532 12 12-50 | Spring Cprsn                    |
| 17         | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr. 5 Zinc |
| 21         | 532 17 18-52 | Bolt Shoulder 5/16-18 unc-2A    |
| 22         | 873 80 05-00 | Nut Hex Lock w/Ins 5/16-18      |
| 24         | 819 17 19-12 | Washer 17/32 x 1-3/16 x 12 Ga.  |
| 25         | 532 12 70-18 | Bolt shoulder 5/16-18 x .62     |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
ENGINE



# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
ENGINE

| KEY NO. | PART NO.            | DESCRIPTION                                                          |
|---------|---------------------|----------------------------------------------------------------------|
| 1       | 532 17 05-51        | Control Throttle/Choke                                               |
| 2       | 817 72 04-08        | Screw Hex Thd Cut 1/4-20 x 1/2                                       |
| 3       | -----               | Engine Briggs Model 31E677<br>(Order parts from engine manufacturer) |
| 4       | 532 13 73-52        | Muffler                                                              |
| 8       | 532 17 18-77        | Bolt 5/16 -18 UNC x 3/4                                              |
| 13      | 532 16 52-91        | Gasket Muffler                                                       |
| 14      | 532 14 84-56        | Tube Drain Oil Easy                                                  |
| 23      | 532 16 98-37        | Shield Brn/Dbr Guard                                                 |
| 25      | 532 19 06-95        | Control Choke                                                        |
| 29      | 532 13 71-80        | Kit Spark Arrestor                                                   |
| 31      | <b>532 40 75-52</b> | Tank Fuel 2.00                                                       |
| 32      | 532 19 77-25        | Cap Asm Fuel                                                         |
| 33      | 532 12 34-87        | Clamp Hose Blk                                                       |
| 37      | 532 13 70-40        | Line Fuel                                                            |
| 38      | 532 18 16-54        | Plug Drain Oil Easy                                                  |
| 44      | 817 67 04-12        | Screw Hexwsh thdrol 1/4-20 x 3/4                                     |
| 45      | 817 00 06-12        | Screw Hexwsh Thdr 3/8-16 x 3/4                                       |
| 46      | 819 09 14-16        | Washer 9/32 x 7/8 x 16 Ga.                                           |
| 72      | 532 19 23-34        | Screw 5/16-18 x .75                                                  |
| 78      | 817 06 06-20        | Screw 3/8-16 x 1-1/4                                                 |
| 81      | 873 51-04-00        | Nut Keps Hex 1/4-20 UNC                                              |
| 119     | 532 19 97-68        | Guard Engine LH                                                      |
| 120     | 532 19 97-67        | Guard Engine RH                                                      |
| 121     | 532 19 66-88        | Clips Threaded                                                       |
| 122     | 532 13 77-29        | Screw THD Roll 1/4-2 x 5/8                                           |
| 123     | 817 67 05-08        | Screw Thread 5/16-18 x 1/2                                           |
| 124     | 532 41 05-24        | Shield, Side LH                                                      |
| 125     | 532 41 05-25        | Shield, Side RH                                                      |
| 126     | <b>817 00 05-12</b> | Screw 5/16-18 x 3/4                                                  |


**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

## Engine Power Rating Information

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J11940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-5). Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net horsepower). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
MOWER



# REPAIR PARTS


TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
MOWER

| KEY NO. | PART NO.            | DESCRIPTION                         | KEY NO. | PART NO.            | DESCRIPTION                                                                                                                                |
|---------|---------------------|-------------------------------------|---------|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| 1       | 532 40 01-08        | Housing Asm. Mower 92 CRD           | 45      | 532 17 55-39        | Cover Mandrel Rh 92 CRD                                                                                                                    |
| 2       | 872 14 05-06        | Bolt Rdhd Sqnk 5/16-18 unc x 3/4    | 46      | 532 13 77-29        | Screw Thd Roll 1/4-20 x 5/8                                                                                                                |
| 3       | 532 16 55-69        | Bracket Asm. S-Bar Chass 92 CRD     | 55      | 532 19 94-98        | Arm Idler 92 CRD                                                                                                                           |
| 4       | 532 16 55-58        | Bracket Bar Sway Deck 92 CRD        | 56      | 532 16 57-23        | Spacer Retainer Mower                                                                                                                      |
| 5       | 532 12 46-70        | Retainer Spring                     | 61      | 532 19 94-86        | Spring Tension Belt                                                                                                                        |
| 6       | 532 16 55-57        | Bar Sway 92 CRD                     | 67      | 532 10 69-32        | Knob Rd 3/8-16 Plstc Thds Blk                                                                                                              |
| 8       | 532 18 17-12        | Bolt 3/8-24 x 1.25 Gr. 8 Patched    | 68      | 532 40 20-08        | Hex-Belt 92 Mower                                                                                                                          |
| 9       | 810 03 06-00        | Washer Lock Hvy 3/8 Unplated        | 69      | 532 16 54-82        | Shaft Asm W/Lwr Brg                                                                                                                        |
| 11      | 532 18 63-85        | Blade 3-1 Lh 92 CRD                 | 84      | 532 15 60-85        | Keeper Belt Idler                                                                                                                          |
| 13      | 532 13 76-45        | Shaft Asm. W/Lower Bearing          | 116     | 532 19 34-06        | Bolt Shoulder                                                                                                                              |
| 14      | 532 12 87-74        | Housing Mandrel Vented (Machd)      | 117     | 532 17 48-73        | Wheel Gage                                                                                                                                 |
| 15      | 532 11 04-85        | Bearing Ball Mandrel                | 119     | 819 13 20-12        | Washer 13/32 x 1-1/4 x 12 GA.                                                                                                              |
| 16      | 532 18 63-86        | Blade 3-1 Rh 92 CRD                 | 124     | 872 11 06-12        | Bolt Carr Sh 3/8-16 x 1-1/2 Gr. 5                                                                                                          |
| 17      | 872 14 06-10        | Bolt Carriage 3/8-16 x 1-1/4        | 130     | 872 11 05-06        | Bolt Rdhdsqnk 5/16-18 unc x 3/4                                                                                                            |
| 18      | 872 11 06-06        | Bolt Rdhd Sqnk 3/8-16 x 3/4         | 131     | 532 16 56-61        | Chute Bagger CRD 92cm                                                                                                                      |
| 19      | 532 13 28-27        | Bolt Shoulder 5/16-18 Thd Form      | 152     | 532 17 60-74        | Cable Clutch CRD                                                                                                                           |
| 20      | 532 18 17-13        | Bolt 3/8-24 x 1.25 Gr. 8 Ptch Lhthd | 158     | 817 72 04-08        | Screw Hex Thd Cut 1/4-20 x 1/2                                                                                                             |
| 21      | 873 68 05-00        | Nut Crown Lock 5/16-18              | 161     | <b>532 18 63-87</b> | Blade Cross LH                                                                                                                             |
| 22      | 532 19 95-90        | Bracket Idler Sprt 92 CRD           | 162     | <b>532 18 05-24</b> | Adapter Blade Cross                                                                                                                        |
| 23      | 532 16 54-46        | Bracket Idler Sprt                  | 163     | <b>532 18 63-88</b> | Blade Cross RH                                                                                                                             |
| 24      | 532 16 52-42        | Bracket Suspension LF 92 CRD        | 185     | 532 18 82-34        | Head Asm. Cable Clutch                                                                                                                     |
| 25      | 532 16 52-44        | Bracket Suspension RF 92 CRD        | ---     | 532 18 18-57        | Mandrel Assembly (Includes hous-<br>ing, shaft assembly, and bear-<br>ing only - pulley/nut/washer and<br>blade bolt/washers not included) |
| 26      | 532 40 01-10        | Brace Susp Frt CRD                  | ---     | 532 18 18-58        | Mandrel Asm CRD Lh Threads SVC                                                                                                             |
| 27      | 532 16 55-68        | Bracket Asm. Susp RR 92 CRD         | ---     | <b>532 40 13-73</b> | Replacement Mower, Complete<br>(Std. Deck - Order separately<br>gauge wheel components Key<br>nos. 116-119)                                |
| 28      | 532 16 55-67        | Bracket Asm. Susp LR 92 CRD         |         |                     |                                                                                                                                            |
| 30      | 532 17 39-84        | Screw Thd Rolling                   |         |                     |                                                                                                                                            |
| 31      | 532 18 76-90        | Washer Spacer Mower Vented          |         |                     |                                                                                                                                            |
| 32      | <b>532 17 57-07</b> | Mandrel Pulleys                     |         |                     |                                                                                                                                            |
| 33      | 532 40 02-34        | Nut Flg Top Lock                    |         |                     |                                                                                                                                            |
| 34      | 532 40 01-07        | Bracket Gauge Wheel Lf 92 CRD       |         |                     |                                                                                                                                            |
| 35      | 532 40 01-06        | Bracket Gauge Wheel Rf 92 CRD       |         |                     |                                                                                                                                            |
| 36      | 532 14 67-63        | Pulley Idler V-Groove Dim 4.25      |         |                     |                                                                                                                                            |
| 40      | 873 68 06-00        | Nut Crownlock 3/8-16 unc            |         |                     |                                                                                                                                            |
| 41      | 873 90 06-00        | Nut Lock Flg. 3/8-16 unc            |         |                     |                                                                                                                                            |
| 44      | 532 17 55-38        | Cover Mandrel Lh 92 CRD             |         |                     |                                                                                                                                            |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
MOWER LIFT



lift-rh.1piece\_9


| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 1       | 532 19 84-17 | Wire Asm Inner Spring W/Plunger |
| 2       | 532 19 80-70 | Shaft Asm. Lift                 |
| 3       | 532 18 88-22 | Pin Groove                      |
| 4       | 812 00 00-02 | E Ring #5133-62                 |
| 5       | 819 21 16-21 | Washer 21/32 x 1 x 21 Ga.       |
| 6       | 532 12 01-83 | Bearing Nylon                   |
| 7       | 532 12 56-31 | Grip Handle Fluted              |
| 8       | 532 12 45-26 | Button Plunger Black            |
| 11      | 532 16 58-29 | Link Asm Lift L.H.              |
| 12      | 532 16 58-31 | Link Asm Lift R.H.              |
| 13      | 532 12 46-70 | Retainer Spring                 |
| 15      | 532 17 32-88 | Link Front                      |
| 16      | 873 35 08-00 | Nut Jam Hex 1/2-13 unc          |
| 17      | 532 17 56-89 | Trunnion Blk Zinc               |
| 18      | 873 80 08-00 | Nut Lock w/wsh 1/2-13 unc       |
| 19      | 532 13 98-68 | Arm Suspension Mower            |
| 20      | 532 19 42-09 | Pin Cotter 7/16 Bowtie Lock     |
| 23      | 532 11 08-07 | Nut Special                     |

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 24      | 819 13 10-16 | Washer 13/32 x 5/8 x 16 Ga.   |
| 25      | 532 12 48-74 | Spring 2-1/8"                 |
| 26      | 532 16 94-84 | Retainer Clip                 |
| 27      | 532 12 69-71 | Rod Adj Lift Zinc 7.49 Wrk Lg |
| 28      | 873 35 06-00 | Nut Hex Jam 3/8-16 Unc        |
| 29      | 532 13 80-57 | Knob Inf 3/8-16 Unc Blk w/sym |
| 30      | 532 15 02-33 | Trunnion Infin Height         |
| 31      | 532 16 98-65 | Bearing, Pvt. Lift.           |
| 32      | 873 54 06-00 | Nut Crownlock 3/8-24          |
| 36      | 532 15 50-97 | Pointer Height Indicator      |
| 37      | 532 12 39-35 | Plug Hole Blk 1.485/1.515 Dia |
| 38      | 817 06 05-16 | Screw 5/16-18 x 1             |
| 40      | 819 11 24-10 | Washer 11/32 x 1-1/2 x 10 Ga. |
| 41      | 532 12 39-34 | Scale Ind Height Blk          |
| 49      | 532 14 52-12 | Nut hex Flange Lock           |
| 50      | 532 11 04-52 | Nut Push Phos & Oil           |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. LT2216CM (96061019400), PRODUCT NO. 960 61 01-94  
BAGGER



| KEY NO. | PART NO.     | DESCRIPTION                          | KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|--------------------------------------|---------|--------------|-----------------------------------|
| 1       | 532 16 52-49 | Tube Handle Bagger CRD               | 31      | 532 16 94-84 | Retainer Clip                     |
| 3       | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr. 5 Zinc      | 32      | 532 12 68-75 | Rivet Rd Hd Drilled 3/8 Dia.      |
| 4       | 532 16 99-16 | Handle Bagger w/Lvrs Blk CRD         | 33      | 532 16 55-71 | Plug Mulcher                      |
| 5       | 874 98 10-24 | Screw Pan Head #10-24 x 1.50         | 34      | 532 16 55-70 | Handle Mulcher                    |
| 6       | 874 98 10-32 | Screw Pan Hd                         | 35      | 532 16 55-72 | Pin Mulcher                       |
| 7       | 873 40 10-00 | Nut Wiz Lock Hex Serr/Hd 10-24       | 36      | 819 13 20-12 | Washer 13/32 x 1-1/4 x 12 Ga.     |
| 8       | 532 18 13-54 | Cover Bagger                         | 37      | 532 17 54-01 | Plug Support Bagger CRD           |
| 9       | 872 14 04-18 | Bolt Carr. 1/4-20 x 2.25d x Gr.5     | 38      | 872 01 05-20 | Bolt 5/16-18 x 2-1/2              |
| 10      | 532 18 12-82 | Tube Support Bagger CRD              | 39      | 532 18 09-85 | Seal                              |
| 11      | 532 16 57-19 | Bracket Support Upper Bag CRD        | 41      | 532 16 96-83 | Bracket Pnt Adj Pvt Bagger CRD    |
| 12      | 532 18 88-48 | Bracket Pivot Lh                     | 43      | 532 17 40-83 | Plug Tubing End                   |
| 13      | 874 76 06-12 | Bolt Fin Hex 3/8-16 UNC x 3/4        | 46      | 872 11 05-10 | Bolt Carr. 5/16-18 x 1-1/4 Gr. 5  |
| 14      | 874 52 06-36 | Bolt Fin Hex 3/8-16 x 2-1/4 Gr.5     | 47      | 532 19 37-04 | Tube Upper Bagger                 |
| 15      | 532 12 46-70 | Retainer Spring                      | 49      | 532 19 33-05 | Bar Spreader                      |
| 16      | 873 90 06-00 | Nut Lock Flange 3/8-16 unc           | 50      | 873 80 05-00 | Nut Lock Hex W/Ins. 5/16-18 unc   |
| 17      | 872 14 05-06 | Bolt Rdhd Sht Sqnk 5/16-18 unc x 3/4 | 51      | 532 19 99-03 | Latch Spring Bagger               |
| 19      | 873 90 05-00 | Nut Lock Hex Flange 5/16-18          | 53      | 873 51 04-00 | Nut Keps Hex 1/4-20 Unc           |
| 20      | 532 18 88-47 | Bracket Pivot Rh                     | 54      | 872 14 04-06 | Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr. 5 |
| 21      | 532 40 61 80 | Bag Asm CRD                          |         |              |                                   |
| 22      | 532 16 57-81 | Bracket Side Bagger CRD              |         |              |                                   |
| 24      | 532 16 57-83 | Tube Pivot Bagger CRD                |         |              |                                   |
| 25      | 532 19 37-05 | Tube Front Bagger                    |         |              |                                   |
| 28      | 532 16 57-87 | Grip Handle                          |         |              |                                   |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm