


# ILLUSTRATED PARTS LIST

**MFG. ID NO. 96041032101**

**CUSTOMER CATALOG NO. LT2320 A2**


**PRODUCT NO. 960 41 03-21**



**47**

581601801

**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
DECALS 27**




**KEY PART  
NO. NO.**

KEY PART NO.	NO.	DESCRIPTION
1	587 67 54-01	Decal, Fender
2	587 73 15-01	Decal, STRWHL
3	582 83 15-01	Decal, Panel SD
4	581 57 97-01	Decal, Eng.
5	581 59 40-01	Decal, Eng.
6	581 60 18-01	Decal, Replacement
7	584 90 46-01	Decal, Deflect. Warning
9	532 14 50-05	Decal, Battery Dnge/Poi
10	581 57 92-01	Decal, Defl.
11	581 57 96-01	Decal, Warning
12	581 58 00-01	Decal, V-Belt Sch
15	581 72 40-01	Decal, Brake/Clutch

**KEY PART  
NO. NO.**

KEY PART NO.	NO.	DESCRIPTION
16	581 57 98-01	Decal, Chassis Warning
17	581 57 81-01	Decal, Read Owner's Manual
18	581 57 80-01	Decal, Parking Brake
--	581 72 46-01	Decal, Drawbar
--	581 72 48-01	Decal, Bypass
--	532 41 19-03	Pad, Footrest, LH
--	532 41 22-79	Pad, Footrest, RH
--	585 53 02-40	Manual, Operators (Euro)
--	585 53 02-50	Manual, Operators (Scan)
--	585 53 02-20	Manual, Operators (E-Bloc)
--	585 53 02-30	Manual, Operators (Baltic)

**WHEELS AND TIRES**




**KEY PART  
NO. NO.**

KEY PART NO.	NO.	DESCRIPTION
1	532 05 91-92	Cap Valve Tire
2	532 06 51-39	Stem Valve
3	532 13 83-36	Rim Front Service
4	532 05 99-04	Tube Front (Service Item Only)
5	532 10 62-22	Tire TM Front 15 x 6-6
6	532 12 49-57	Fitting Grease (Front Wheel Only)
7	532 12 49-59	Bearing Flange (Front Wheel Only)
8	532 17 50-39	Cap Axle Blk 1 50 x 1 00
9	532 12 20-82	Tire TM Rear 20 x 10-8
10	532 12 49-26	Tube Rear (Service Item Only)
11	532 13 83-37	Rim Asm 8" rear Service
--	532 14 43-34	Sealant, Tire (10 oz. Tube)


**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21 SCHEMATIC **38**

SCH13



**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
ELECTRICAL 32**




**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
ELECTRICAL 32**

<b>KEY NO.</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>
1	532 16 34-65	Battery
2	874 76 04-12	Bolt Hex Head 1/4-20 x 3/4
8	587 20 51-01	Box Battery
16	532 17 61-38	Switch Interlock Push-In
21	532 40 02-52	Harness Socket Light w/4152J
22	532 00 41-52	Bulb Light
24	585 55 56-01	Cable Battery
25	585 55 55-01	Cable Starter
26	532 17 51-58	Fuse
27	873 51 04-00	Nut Keps Hex 1/4-20 unc
28	532 41 65-88	Cable, Ground
29	532 40 15-45	Switch, Seat
30	532 19 33-50	Switch, Ign
33	532 41 19-35	Key\Chain
34	532 11 07-12	Switch Light / Reset
40	501 13 32-01	Harness Ign. Dash
41	817 72 04-08	Screw Thd Cut 1/4-20 x 1/2
42	532 13 15-63	Cover, Terminal
43	532 19 25-07	Solenoid
46	586 16 18-01	Gauge Servicere minder Hrmtr
50	582 10 76-01	Switch PTO
55	817 06 05-12	Screw Thdrol 5/16-18 x 3/4 TYTT
71	532 19 42-76	Harness Ign. Chassis
79	532 17 52-42	Socket Asm Bulb Twistlock
81	532 40 96-15	Relay Harness
90	532 43 53-95	Cover Terminal
99	817 67 04-12	Screw Hexwsh Thdrol 1/4-20 x 3/4
100	819 09 14-16	Washer 9/32 x 7/8 x 16 Ga.
102	532 40 44-54	Harness Pigtail
105	532 40 75-68	Switch Reverse TT Pedal Control

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
CHASSIS AND ENCLOSURES **39**




**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
CHASSIS AND ENCLOSURES 39**

KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION		
5	532 42 82-71	Dash	195	532 40 41-37	Plug Hole
8	532 12 64-71	Clip, Insulator	196	532 41 18-78	Console Asm Decklift
14	532 44 38-24	Hood	197	589 20 46-02	Shield Drawbar
18	532 42 73-33	Grille/Lens Asm.	198	532 44 15-52	Indicator
34	580 91 08-01	Plate Engine	199	532 19 63-77	Plate Deck Lift
36	817 06 05-12	Screw 5/16-18 x 3/4	202	532 44 54-26	Vent Side Hood RH
37	532 44 38-16	Fender	203	532 44 55-83	Vent Side Hood LH
52	873 68 05-00	Nut Lock 5/16-18	207	532 19 89-63	Bezel RH
58	532 41 22-81	Drawbar Upper	208	532 19 89-64	Bezel LH
68	817 49 05-08	Screw Thdrol 5/16-18 x 1/2	213	874 76 05-12	Bolt 5/16-18 x 3/4
125	581 68 48-01	Clip Fuel Line	217	532 40 91-67	Rod Pivot
130	532 41 63-58	Screw 10 x .750 BOS Thread	218	532 19 63-95	X-Piece Hood Stop
146	581 85 79-01	Bolt	222	532 13 77-29	Screw 1/4-20 x 5/8
150	584 86 29-01	Air Duct	225	532 44 38-25	Bumper Grille
151	532 44 54-94	Bracket Pivot Hood	226	532 42 47-16	Logo Predator
152	532 19 95-35	Shield Browning	228	532 19 51-61	Stud Fastner
153	532 42 47-17	Lens Bar	235	532 40 61-29	Spacer Fender
159	817 00 06-12	Screw 3/8-16 x 3/4	236	873 93 05-00	Nut Lock 5/16-18 unc
161	532 41 18-79	Window, Fuel	237	532 40 37-04	Plug Mount Cargo
162	532 14 24-32	Screw Hex Wsh 1/4 x 1/2 unc	303	587 49 34-02	Shield Chassis LH
165	532 19 68-26	Support Tank Rear	304	587 86 51-02	Shield Chassis RH
175	532 19 63-04	Crossmember	306	873 90 06-00	Nut Lock 3/8-16 unc
176	532 40 07-76	Screw 10-24 x 5/8	307	587 52 03-01	Shield Upper RH
177	532 19 52-28	Bushing Steering	308	532 17 18-77	Bolt 5/16-18 unc 3/4
180	532 41 50-64	Chassis	321	587 52 02-01	Shield Upper LH
181	532 40 47-96	Bushing	--	532 40 09-44	Kit Bumper
182	532 40 68-59	Dash Lower			
183	874 52 05-20	Bolt 5/16-18 x 1-1/4 Full Thd.			
184	587 55 41-01	Plug Demo			
189	817 00 05-12	Screw 5/16-18 x 3/4			
194	873 90 05-00	Nut Lock Hex Flange 5/16-18			

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
 DRIVE **40**




drive\_tex\_K46\_pedal\_157\_r1



**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
DRIVE 40**


KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1	----- Transaxle, TUFFTORQ K46BT (426120) (Order parts from transaxle manufacturer.)	171	872 11 06-16 Bolt
2	532 12 35-83 Key	183	532 13 70-57 Spacer Axle
15	819 13 13-16 Washer 13/32 x 13/16 x 16 Ga.	184	587 65 37-01 Handle Parking Brake
17	532 41 36-78 Spring, Brake	185	872 11 06-22 Bolt Rdhd Sqnk 3/8-16 x 2-3/4 Gr. 5
26	532 19 96-79 Spring Return Cruise	186	532 19 43-21 Spacer Retainer
29	532 40 38-06 Rod, Brake	187	819 13 32-10 Washer
33	812 00 00-01 Ring E	188	582 21 70-01 Link Clutch Ground Drive, Long
35	583 86 45-01 Rod, Brake, Park	189	532 19 43-17 Bellcrank Ground Drive
37	532 18 89-67 Washer Hardened	190	532 19 43-18 Keeper Bellcrank Ground Drive
42	532 12 48-72 Cover, Foot Pedal	196	817 00 06-16 Screw 3/8-16 x 1
49	872 11 06-14 Bolt	197	585 65 86-01 Link Clutch Anti-Rotation
50	532 19 43-27 Pulley Idler Flat	205	532 12 17-48 Washer
51	873 90 06-00 Lock Nut 3/8-16	206	532 44 85-96 Bracket Mount Latch Cruise
52	532 19 43-26 Idler V-Groove	207	587 03 14-01 Latch Control Cruise
56	532 13 09-69 V-Belt, Drive	208	532 19 78-69 Gear Sector Control Cruise
64	532 19 78-65 Shaft Asm. Pedal Brake Control	209	532 19 95-92 Rod Control Cruise
73	874 49 05-40 Bolt Hex Flghd 5/16-18 Gr. 5	210	532 19 78-60 Rocker Asm. Pedal Control
74	532 14 24-32 Screw Hex 1/4 x 1/2 unc	211	532 12 01-83 Bearing Nylon
92	874 76 05-20 Bolt Fin Hex 5/16-18 unc x 1.25	213	532 40 31-19 Knob Control Cruise
99	532 41 57-42 Rod Spring Bypass	214	532 42 12-63 Pedal Forward
116	873 90 05-00 Nut Lock Hex Flange 5/16-18	215	532 40 17-23 Pedal Reverse
125	817 00 05-12 Screw 5/16-18 x 3/4	216	532 19 61-31 Bracket Pulley Idler
143	817 49 05-08 Screw 5/16-18 x 1/2	221	532 40 31-87 Retainer Spring Clip Handle
153	532 12 47-88 Retainer Spring	222	879 21 20-10 Washer 21/32 x 1-1/4 x 10 Ga.
159	876 02 04-12 Pin Cotter 1/8 x 3/4	224	532 41 22-98 Console Asm
160	532 16 94-84 Retainer Clip	225	532 40 33-19 Keeper Belt Trans.
161	532 10 57-09 Spring, Return, Clutch	227	817 49 05-12 Screw Thdrol 5/16-18 x 3/4
163	532 44 82-75 Rod Pedal Control	325	585 66 85-01 Bracket Torque Strap LH
166	532 42 91-64 Nut Push	326	585 67 08-01 Bracket Torque Strap RH
167	532 40 52-57 Latch Brake Parking	336	587 25 96-01 Bolt 5/16-18 x 1-3/4 Flg. Hx.
170	532 19 43-22 Keeper Belt Centerspan		

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



**SPARK ARRESTER KIT**

engine-tex\_bs-2cyl\_155



**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
ENGINE 24**


KEY NO.	PART NO.	DESCRIPTION
1	-----	Engine Briggs Model No. 40N777-0007-B1 (501257801)(Order parts from engine manufacturer.)
2	532 14 97-23	Muffler
9	501 83 26-01	Keeper Belt Engine
11	587 24 16-01	Clutch Electric
12	532 40 50-97	Pulley Engine
15	532 19 34-99	Tank Fuel
18	584 24 87-01	Cap Asm
20	532 42 35-02	Control Throttle
21	532 41 63-58	Screw #10 x 0.750 BOS Thread
28	532 13 70-40	Fuel Line
29	532 13 71-80	Spark Arrester Kit
37	532 12 34-87	Clamp Hose
41	532 12 61-97	Washer 1-1/2 OD x 15/32 ID x .250
42	810 04 07-00	Washer Lock 7/16
45	873 51 04-00	Nut Keps Hex 1/4-20 unc
62	532 43 40-17	Shield Heat Muffler
69	532 16 53-91	Gasket
70	581 88 11-01	Tube Exhaust LH
71	581 88 10-01	Tube Exhaust RH
79	532 18 39-06	Screw Socket Head 5/16-18 x 1
81	532 14 84-56	Tube Drain Oil Easy
82	532 42 82-87	Valve Drain Oil Easy
84	817 06 06-20	Screw 3/8-16 x 1-1/4
85	501 60 66-01	Bolt 7/16-20 x 3.75 Gr. 5
90	817 00 06-16	Screw 3/8-16 x 1
91	532 18 74-95	Bushing
102	817 00 05-12	Screw 5/16-18 x 3/4
105	501 26 86-02	Shield Side LH
106	501 26 87-02	Shield Side RH
108	587 17 95-03	Cover Pulley Engine w/SHLD 46"
115	532 43 17-61	Palnut #10
136	532 42 17-56	Screw, #10 0.500, BOS

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**Engine Power Rating Information**

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J1940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-05). Torque values are derived at 3060 RPM; horsepower values are derived at 3600 RPM. Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net power). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
STEERING ASSEMBLY **41**




steering-tex\_STDSRR\_51

**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
STEERING ASSEMBLY **41****

<b>KEY PART NO.</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>
1	532 42 41-46	Wheel, Steering
2	532 41 35-91	Axle Front
4	532 40 30-87	Spindle LH
5	532 40 30-88	Spindle RH
6	532 12 49-31	Washer Thrust 0.75 x 1.23
7	532 12 17-48	Washer 25/32 x 1-5/8 x 16 Ga.
8	812 00 00-29	Ring, Klip #T5304-75
9	532 12 12-32	Cap, Spindle
13	532 12 17-49	Washer 25/32 x 1-1/4 x 16 Ga.
14	810 04 06-00	Washer, Lock 3/8
15	873 54 06-00	Nut, Crown Lock 3/8-24 unf
16	587 01 60-02	Steering Shaft
19	532 19 47-29	Plate Steering
20	532 42 47-40	Boot Steering
21	586 84 02-01	Adapter Wheel Steering
22	585 02 98-02	Bearing
26	532 42 41-47	Insert, Wheel Steering
27	819 21 16-16	Washer
28	817 00 06-12	Screw 3/8-16 x 3/4
35	532 19 47-32	Gear, Sector Plate
45	587 01 64-01	Washer 3/8 ID 2-3/8 OD 12 Ga. PLTD
51	873 90 06-00	Nut Lock Flg 3/8-16 unc
53	532 18 89-67	Washer Hardened .793 x 1.637 x .060
57	532 40 74-65	Bracket Upstop
58	532 19 47-47	Bolt Shoulder Sector Pivot CFM
59	532 19 47-48	Washer Thrust Sector Steering
60	873 97 10-00	Nut Flange Lock 5/8-11
61	532 19 47-40	Draglink, LH
62	532 19 47-41	Draglink, RH
63	817 00 05-12	Screw 5/16-18 x 3/4
64	532 19 98-49	Retainer Clip Spring Steering
66	871 02 07-48	Bolt Hex Fghd 7/16-14 x 3 Serr
67	532 19 47-37	Bushing PM Front Axle
68	873 90 07-00	Nut Lock Flange 7/16-14 Gr. 5
69	532 19 91-62	Washer 1.5 x .505 x .118
70	585 33 88-01	Bracket Deck Susp. Front
75	580 68 37-01	Pinion
76	580 68 36-01	Screw Head Sock
118	532 40 60-13	Bushing Axle
122	532 44 49-62	Cap Gear

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
MOWER DECK 44




46\_tex\_elect\_6\_r4

**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
MOWER DECK 44**

KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1	589 53 53-16	147	532 19 72-51
4	874 76 05-12	188	532 19 51-61
6	532 19 51-86	189	873 90 05-00
11	532 40 53-80	197	819 13 13-12
12	584 30 93-01	198	532 40 31-49
13	587 25 65-01	199	532 40 31-50
14	532 18 72-81	200	532 41 35-24
15	585 32 39-01	206	532 42 30-62
19	532 19 65-39	208	817 67 06-08
21	873 68 05-00	209	588 80 88-01
23	532 19 25-57	210	532 43 10-87
24	532 10 53-04	240	874 52 06-36
25	532 19 70-26	241	532 15 29-27
26	532 11 04-52	242	532 41 55-98
27	532 44 28-95	247	532 43 02-63
29	532 13 14-91	248	532 43 02-62
32	532 19 74-73	253	532 42 73-50
33	532 40 02-34	254	532 43 02-64
34	872 11 06-12	255	532 43 60-87
36	532 19 73-79		
40	873 90 06-00	258	584 95 39-01
46	532 13 77-29	--	587 25 33-01
55	532 19 72-49		
56	532 19 90-92		
57	817 00 06-16		
59	532 14 10-43		
68	532 40 51-43		
69	872 14 05-05	--	532 42 80-12
116	532 19 34-06		
117	532 17 48-73		
119	819 13 20-12		
145	532 19 31-97		

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21**  
**MOWER LIFT 45**



lift-tex\_44

\*Key 91 may be substituted for Key 101


KEY NO.	PART NO.	DESCRIPTION
2	532 42 20-27	Shaft Asm., Lift
3	532 19 52-30	Lever Lift Handle
7	580 96 23-01	Grip, Lever
10	532 19 63-14	Spring Torsion
87	532 19 42-09	Pin Cotter 7/16 Bow Tie Lock
88	532 41 07-10	Spring Lift Assist
89	819 19 19-12	Washer Clear Zinc
90	532 19 42-08	Pin Cotter 5/16 Bow Tie Lock
91	532 19 51-81	Link Lift Susp Mower Rear

KEY NO.	PART NO.	DESCRIPTION
97	817 00 06-12	Screw 3/8-16 x 3/4
98	532 19 52-70	Link Asm. Susp. Front Mower
100	873 93 06-00	Nut Centerlock 3/8-16 unc
101	532 40 70-03	Link Asm Lift Fixed
116	819 15 15-16	Washer 15/32 x 15/16 x 16 Ga.

**NOTE:** All component dimensions given in U.S. inches  
 1 inch = 25.4 mm



**TRACTOR - - MODEL NO. LT2320 A2 (96041032101), PRODUCT NO. 960 41 03-21  
SEAT ASSEMBLY 42**



seat-tex\_6.5SL\_11

KEY PART NO.	NO.	DESCRIPTION
1	532 40 66-25	Seat
2	532 18 01-66	Bracket Pivot Fender
6	873 80 06-00	Nut, Lock W/Ins. 3/8-16 unc
7	587 61 33-01	Spring, Seat Cprsn
8	532 17 18-77	Bolt 5/16-18 unc x 3/4 w/Sems
10	532 19 69-77	Pan, Seat
21	587 90 78-01	Bolt, Shoulder 5/16-18 x 5/8
37	873 80 05-00	Nut, Lock 5/16-18 unc
40	532 19 76-61	Handle Slide Seat

KEY PART NO.	NO.	DESCRIPTION
41	532 19 82-00	Spring Latch Seat
43	874 76 06-12	Bolt Fin Hex 3/8-16 unc x 3/4
44	819 13 38-12	Washer 13/32 x 2-3/8 x 12 Ga.
46	588 09 04-01	Bolt 3/8-16 x1; 1.25 OD

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

GPL<sup>®</sup>