

# LTH1842

**Spare parts**

**Ersatzteile**

**Pièces détachées**


**Reserve onderdelen**

**Repuestos**

**Reservdelar**

**GPL®**


**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**DECALS 27**



| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 2       | 532 14 08-37 | Decal, Brake Parking Sandle   |
| 3       | 532 42 20-12 | Decal, Hood                   |
| 4       | 532 19 68-41 | Decal, Warning Engine Syms    |
| 5       | 532 16 03-96 | Decal, V-Belt Sch.            |
| 6       | 532 15 97-36 | Decal, Chassis Hot Muffler    |
| 7       | 532 18 21-66 | Decal, Mower Cutfinger Symbol |
| 9       | 532 16 88-69 | Decal, Tick Mark              |
| 10      | 532 40 03-89 | Decal, Warning Symbols CE     |
| 11      | 532 14 50-05 | Decal, Bat Dan/Poi P/L Sym    |
| 12      | 532 17 83-02 | Decal, Oper. Cruise Symbols   |

| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 13      | 532 41 01-04 | Decal, Sidepnl               |
| 15      | 532 15 97-37 | Decal, Brake/Clutch Symbol   |
| 17      | 532 19 63-57 | Decal, Cutfinger Warning     |
| 18      | 532 12 44-33 | Decal, 80 DBA                |
| --      | 532 16 25-98 | Decal, Drawbar Load Limit    |
| --      | 532 16 69-60 | Decal, Bypass Lt Hydro       |
| --      | 532 41 08-05 | Pad, Footrest LH             |
| --      | 532 41 08-06 | Pad, Footrest RH             |
| --      | 532 41 03-26 | Manual, Operator's (English) |

**WHEELS & TIRES**




| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                    |
| 2       | 532 06 51-39 | Stem Valve                        |
| 3       | 532 10 62-22 | Tire F Ts 15 x 6 0 - 6 Service    |
| 4       | 532 05 99-04 | Tube Front (Service Item Only)    |
| 5       | 532 13 83-36 | Rim Asm 6" Front Silver Service   |
| 6       | 532 12 49-57 | Fitting Grease (Front Wheel Only) |
| 7       | 532 12 49-59 | Bearing Flange (Front Wheel Only) |
| 8       | 532 13 83-37 | Rim Asm 8" Rear Silver Service    |
| 9       | 532 12 20-82 | Tire R Ts 20 x 10-8 C Service     |
| 10      | 532 12 49-26 | Tube Rear (Service Item Only)     |
| 11      | 532 17 50-39 | Cap Axle Blk 1 50 x 1 00          |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. tube)       |


**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52  
SCHEMATIC 38

SCH12



**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**ELECTRICAL 32**




**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**ELECTRICAL 32**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                         |
|------------|--------------|-------------------------------------|
| 1          | 532 16 34-65 | Battery                             |
| 2          | 874 76 04-12 | Bolt Hex Hd 1/4-20 unc x 3/4        |
| 8          | 532 19 32-28 | Box Battery                         |
| 16         | 532 17 61-38 | Switch Interlock                    |
| 21         | 532 40 02-52 | Harness Asm Light w/4152J           |
| 22         | 532 00 41-52 | Bulb Light #1156                    |
| 25         | 532 41 28-94 | Cable Battery 6 Ga. Red 14.5        |
| 26         | 532 17 51-58 | Fuse 20 AMP                         |
| 27         | 873 51 04-00 | Nut Keps Hex 1/4-20 Unc             |
| 28         | 532 19 88-85 | Cable 18" Rear. BATT.               |
| 29         | 532 40 15-45 | Switch Seat                         |
| 30         | 532 19 33-50 | Switch Ignition                     |
| 33         | 532 41 19-33 | Key/Chain                           |
| 34         | 532 11 07-12 | Switch Light                        |
| 40         | 532 40 11-04 | Harness Ign.                        |
| 41         | 817 72 04-08 | Bolt Hex Hd. Fin 1/4-20 x 1/2 Gr. 5 |
| 42         | 532 13 15-63 | Cover Terminal Red                  |
| 43         | 532 19 25-07 | Solenoid                            |
| 46         | 532 40 17-63 | Hourmeter                           |
| 50         | 532 17 46-51 | Switch PTO                          |
| 55         | 817 06 05-12 | Screw 5/16-18 x 3/4                 |
| 71         | 532 40 04-49 | Harness Ign. Chass. Tex             |
| 79         | 532 17 52-42 | Socket, Asm. Bulb                   |
| 90         | 532 40 07-25 | Cover Terminal Battery              |
| 101        | 532 19 83-17 | Pigtail MATNLK New Harn.            |
| 102        | 532 40 44-54 | Harness Pigtail K46 TEX ROS         |
| 105        | 532 40 75-68 | Switch Reverse TT Pedal Control     |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm.

**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**CHASSIS AND ENCLOSURES 39**



chassis-tex\_lt husq\_8\_r4


**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**CHASSIS AND ENCLOSURES 39**

| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 3       | 532 40 50-12 | Logo                            |
| 5       | 532 40 75-94 | Dash                            |
| 14      | 532 41 10-73 | Hood                            |
| 15      | 532 41 10-79 | Lens LH                         |
| 18      | 532 40 66-67 | Grille/Lens Asm.                |
| 25      | 532 41 10-78 | Lens RH                         |
| 34      | 532 19 61-25 | Plate Engine                    |
| 36      | 817 06 05-12 | Screw 5/16-18 x 3/4             |
| 37      | 532 41 63-07 | Fender                          |
| 52      | 873 68 05-00 | Nut Crown Lock 5/16             |
| 68      | 817 49 05-08 | Screw THDROL 5/16-18 x 1/2      |
| 130     | 532 41 63-58 | Screw #10 x 0.750 BOS Thread    |
| 137     | 532 40 75-90 | Bumper, Dash                    |
| 150     | 532 40 75-37 | Air Duct                        |
| 151     | 532 40 78-07 | Bracket Pivot                   |
| 152     | 532 19 95-35 | Shield Browning                 |
| 159     | 817 00 06-12 | Screw Hex Wsh Thdr 3/8-16 x 3/4 |
| 162     | 532 14 24-32 | Screw                           |
| 175     | 532 19 94-72 | Crossmember                     |
| 176     | 532 40 07-76 | Screw 10-24 x 5/8               |
| 177     | 532 19 52-28 | Bushing Steering                |
| 180     | 532 19 54-57 | Chassis                         |
| 182     | 532 40 71-76 | Dash Lower                      |
| 183     | 874 78 05-20 | Bolt 5/16-18 unc x 1-1/4        |
| 189     | 817 00 05-12 | Screw 5/16-18 x 3/4             |
| 191     | 532 41 65-00 | Insert Reflective RH            |
| 194     | 873 90 05-00 | Nut Lock Hex Flange 5/16-18     |

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 199     | 532 41 34-85 | Plate Deck Lift                |
| 202     | 532 41 10-75 | Vent Side Hood RH              |
| 203     | 532 41 10-74 | Vent Side Hood LH              |
| 204     | 532 41 11-16 | Vent Top Hood                  |
| 205     | 532 41 10-76 | Skirt Side RH                  |
| 206     | 532 41 10-77 | Skirt Side LH                  |
| 213     | 874 76 05-12 | Bolt 5/16-18 x 3/4             |
| 214     | 532 19 91-45 | Clip Retainer                  |
| 217     | 532 40 91-67 | Rod Pivot Hood                 |
| 218     | 532 19 63-95 | X-Piece Hood Stop              |
| 228     | 532 19 51-61 | Stud Fastener                  |
| 234     | 532 40 47-42 | Bumper Hood                    |
| 235     | 532 40 61-29 | Spacer Fender                  |
| 236     | 873 93-05-00 | Nut Lock 5/16-18 unc Center    |
| 238     | 532 41 11-19 | Trim                           |
| 239     | 532 40 48-83 | Clip Tinnerman                 |
| 282     | 532 41 41-10 | Clip Retainer                  |
| 283     | 532 41 63-16 | Console Deck Lift              |
| 284     | 532 41 78-87 | Console Control Pedal          |
| 285     | 532 41 63-15 | Console Insert RH              |
| 286     | 532 41 63-17 | Console Insert LH              |
| 287     | 817 60 04-06 | Screw Hex Washead 1/4-20 x 3/8 |
| 297     | 532 40 66-65 | Insert Reflective LH           |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm


## 40



**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**DRIVE 40**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                                                                                                |
|------------|--------------|------------------------------------------------------------------------------------------------------------|
| 1          | ---          | Transaxle, TUFFTORQ K46 BT                                                                                 |
| 2          | 532 12 35-83 | Key                                                                                                        |
| 15         | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga.                                                                              |
| 17         | 532 41 36-78 | Spring, Brake                                                                                              |
| 29         | 532 40 38-06 | Rod, Brake                                                                                                 |
| 33         | 812 00 00-01 | Ring E                                                                                                     |
| 35         | 532 40 10-31 | Rod, Brake, Park                                                                                           |
| 42         | 532 12 48-72 | Cover, Foot Pedal                                                                                          |
| 49         | 872 11 06-14 | Bolt                                                                                                       |
| 50         | 532 19 43-27 | Pulley Idler Flat                                                                                          |
| 51         | 873 90 06-00 | Lock Nut 3/8-16                                                                                            |
| 52         | 532 19 43-26 | Idler V-Groove 910" Offset                                                                                 |
| 56         | 532 13 09-69 | V-Belt, Drive                                                                                              |
| 64         | 532 19 78-65 | Shaft Asm. Pedal Brake Control                                                                             |
| 73         | 874 49 05-44 | Bolt Hex FlgHd 5/16-18 Gr. 5                                                                               |
| 80         | 532 41 21-70 | Bracket Strap Torque                                                                                       |
| 99         | 532 41 57-42 | Rod Spring Bypass                                                                                          |
| 116        | 873 90 05-00 | Nut Lock Hex Flange 5/16-18                                                                                |
| 125        | 817 00 05-12 | Screw 5/16-18 x 3/4                                                                                        |
| 143        | 817 49 05-08 | Screw 5/16-18 x 1/2                                                                                        |
| 153        | 532 12 47-88 | Retainer Spring                                                                                            |
| 159        | 876 02 04-12 | Pin Cotter 1/8 x 3/4                                                                                       |
| 160        | 532 16 94-84 | Retainer Clip                                                                                              |
| 161        | 532 10 57-09 | Spring, Return, Clutch  |
| 163        | 532 40 10-34 | Rod Pedal Control                                                                                          |
| 166        | 532 19 72-90 | Nut Push                                                                                                   |
| 167        | 532 40 52-57 | Latch Brake Parking                                                                                        |
| 170        | 532 19 43-22 | Keeper Belt Centerspan                                                                                     |
| 171        | 872 11 06-16 | Bolt RDHD SQNK 3/8-16 unc x 2                                                                              |
| 183        | 532 13 70-57 | Spacer Split                                                                                               |
| 184        | 532 40 97-47 | Handle Parking Brake                                                                                       |
| 185        | 872 11 06-22 | Bolt RDHD 3/8-16 unc x 2-3/4 Gr. 5                                                                         |
| 186        | 532 19 43-21 | Spacer Retainer                                                                                            |
| 187        | 819 13 32-10 | Washer                                                                                                     |
| 188        | 532 19 43-23 | Link Clutch Ground Drive                                                                                   |
| 189        | 532 19 43-17 | Bellcrank Ground Drive                                                                                     |
| 190        | 532 19 43-18 | Keeper Bellcrank Ground Drive                                                                              |
| 196        | 817 00 06-16 | Screw 3/8-16 x 1                                                                                           |
| 197        | 532 19 58-04 | Bracket Clutch Anti-Rotation                                                                               |
| 205        | 532 12 17-48 | Washer                                                                                                     |
| 210        | 532 40 09-80 | Rocker Asm. Pedal Control                                                                                  |
| 211        | 532 12 01-83 | Bearing Nylon                                                                                              |
| 214        | 532 40 17-22 | Pedal Forward                                                                                              |
| 215        | 532 40 17-23 | Pedal Reverse                                                                                              |
| 216        | 532 19 61-31 | Bracket Pulley Idler                                                                                       |
| 221        | 532 40 31-87 | Retainer Spring Clip Handle                                                                                |
| 222        | 879 21 20-10 | Washer 21/32 x 1-1/4 x 10 Ga.                                                                              |
| 225        | 532 40 33-19 | Keeper Belt Trans.                                                                                         |
| 226        | 532 40 15-64 | Bracket Mount Torque                                                                                       |
| 230        | 532 18 89-67 | Washer Hardened                                                                                            |

NOTE: All component dimensions given in U.S. inches  
1 inch = 25.4 mm




engine-tex\_Kohl\_10

**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**ENGINE 24**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                           |
|------------|--------------|---------------------------------------|
| 1          | -----        | Engine Kohler Model No.<br>SV540-0025 |
| 2          | 532 18 86-55 | Muffler                               |
| 9          | 532 19 43-20 | Keeper Belt Engine                    |
| 11         | 532 18 05-05 | Clutch, Ogura                         |
| 12         | 532 40 50-97 | Pulley Engine                         |
| 15         | 532 40 75-45 | Tank Fuel 1.5                         |
| 18         | 532 19 77-25 | Cap Asm                               |
| 20         | 532 18 38-97 | Control Throttle                      |
| 21         | 532 41 63-58 | Screw #10 x 0.750 BOS Thread          |
| 28         | 532 13 70-40 | Fuel Line                             |
| 29         | 532 13 71-80 | Spark Arrester Kit                    |
| 37         | 532 12 34-87 | Clamp Hose                            |
| 41         | 532 12 61-97 | Washer 1-1/2 OD. x 15/32              |
| 42         | 810 04 07-00 | Bolt 5/16-18 unc x 3/4 w/Sems         |
| 45         | 873 51 04-00 | Nut Keps Hex 1/4-20 unc               |
| 69         | 532 18 59-09 | Gasket                                |
| 79         | 532 19 23-34 | Screw Socket HD. 5/16-18 x .75        |
| 81         | 532 14 84-56 | Tube Drain Oil Easy                   |
| 82         | 532 18 16-54 | Plug Drain Oil                        |
| 83         | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems         |
| 90         | 817 00 06-16 | Screw 3/8-16 x 1                      |
| 92         | 817 12 06-16 | Screw 3/8-16 x 1                      |
| 94         | 532 18 86-54 | Tube Exhaust                          |
| 95         | 532 17 39-37 | Bolt Hex 7/16-20 x 4 Gr. 5            |
| 96         | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.            |
| 97         | 817 67 04-12 | Screw 1/4-20 x 3/4                    |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**STEERING ASSEMBLY 41**




steering-tex\_HUSQSR\_11

**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**STEERING ASSEMBLY 41**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                     |
|------------|--------------|---------------------------------|
| 1          | 532 41 64-80 | Wheel, Steering                 |
| 2          | 532 41 35-91 | Axle Asm., Front                |
| 4          | 532 40 30-87 | Spindle Asm., LH                |
| 5          | 532 40 30-88 | Spindle Asm., RH                |
| 6          | 532 12 49-31 | Bearing, Race Thrust Harden     |
| 7          | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.   |
| 8          | 812 00 00-29 | Ring, Klip #T5304-75            |
| 9          | 532 12 12-32 | Cap, Spindle                    |
| 13         | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.   |
| 14         | 810 04 06-00 | Washer, Lock Hvy Hlcl Spr 3/8   |
| 15         | 873 54 06-00 | Nut, Crown Lock 3/8-24 unf      |
| 16         | 532 19 60-74 | Shaft Steering                  |
| 19         | 532 19 47-29 | Plate Steering                  |
| 20         | 532 41 11-39 | Boot, Steering                  |
| 21         | 532 18 67-37 | Adapter, Wheel Steering         |
| 22         | 532 19 48-45 | Bushing, Strg. Blk              |
| 26         | 532 41 59-87 | Insert, Wheel Steering          |
| 28         | 817 00 06-12 | Screw 3/8-16 x 3/4              |
| 33         | 810 04 05-00 | Washer Lock 5/16                |
| 35         | 532 19 47-32 | Gear, Sector Plate              |
| 45         | 819 11 38-12 | Washer 11/32 x 3/8 x 12 Ga.     |
| 53         | 532 18 89-67 | Washer Hardened .793x1.637x.060 |
| 57         | 532 40 74-65 | Bracket Upstop                  |
| 58         | 532 19 47-47 | Bolt Shoulder Sector Pivot CFM  |
| 59         | 532 19 47-48 | Washer Thrust Sector Steering   |
| 60         | 873 97 10-00 | Nut Flange Lock 5/8-11          |
| 61         | 532 19 47-40 | Draglink, LH                    |
| 62         | 532 19 47-41 | Draglink, RH                    |
| 63         | 817 00 05-12 | Screw 5/16-18 x 3/4             |
| 64         | 532 19 98-49 | Retainer Clip Spring Steering   |
| 66         | 871 02 07-48 | Bolt Hex Fghd 7/16-14 x 3 Serr  |
| 67         | 532 19 47-37 | Bushing PM Front Axle           |
| 68         | 873 90 07-00 | Nut Lock Flange 7/16-14 Gr. 5   |
| 69         | 532 19 91-62 | Washer 1.5 x .505 x .118        |
| 70         | 532 19 61-97 | Bracket Deck Susp. Front        |
| 71         | 532 19 60-75 | Shaft Extension Steering        |
| 72         | 874 78 05-72 | Bolt 5/16-18 unc x 4.5. Gr. 5   |
| 118        | 532 40 60-13 | Bushing                         |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

## 44




**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**MOWER DECK** **44**

| KEY NO. | PART NO.     | DESCRIPTION                                                                                            |
|---------|--------------|--------------------------------------------------------------------------------------------------------|
| 1       | 532 19 64-95 | Mower Deck Assembly, 42"                                                                               |
| 6       | 532 19 51-86 | Arm Susp. Rear                                                                                         |
| 8       | 532 19 30-03 | Bolt/Washer Asm 7/16-20 unf<br>(The following Blades are available)                                    |
| 11      | 532 13 89-71 | Blade Mower 42" Hi-Lift<br>(for bagging and discharging)                                               |
| 13      | 532 19 28-72 | Shaft Assembly, Mandrel                                                                                |
| 14      | 532 18 72-81 | Housing, Mandrel                                                                                       |
| 15      | 532 11 04-85 | Bearing, Ball, Mandrel                                                                                 |
| 16      | 532 17 44-93 | Stripper, Mandrel Deck                                                                                 |
| 19      | 532 19 65-39 | Bolt, Shoulder                                                                                         |
| 20      | 532 15 97-70 | Baffle, Vortex                                                                                         |
| 21      | 873 68 05-00 | Nut                                                                                                    |
| 23      | 532 19 25-57 | Bracket, Deflector Mower 42"                                                                           |
| 24      | 532 10 53-04 | Cap, Sleeve 80 x 112 Blk Mower                                                                         |
| 25      | 532 19 70-26 | Spring, Torsion, Deflector                                                                             |
| 26      | 532 11 04-52 | Nut, Push Phos & Oil                                                                                   |
| 27      | 532 40 30-04 | Shield, Deflector 42" Blk                                                                              |
| 29      | 532 13 14-91 | Rod, Hinge 42" 6 75 W/G                                                                                |
| 30      | 532 17 39-84 | Screw Thdrol                                                                                           |
| 31      | 532 18 76-90 | Washer, Spacer Mower Vented                                                                            |
| 32      | 532 15 35-35 | Pulley, Mandrel                                                                                        |
| 33      | 532 40 02-34 | Nut, Toplock                                                                                           |
| 34      | 872 11 06-12 | Bolt Carr SH 3/8-16 x 1-1/2 Gr. 5                                                                      |
| 36      | 532 19 73-79 | Pulley Idler Flat                                                                                      |
| 40      | 873 90 06-00 | Nut Lock 3/8-16                                                                                        |
| 55      | 532 19 72-49 | Arm, Idler                                                                                             |
| 56      | 532 19 90-92 | Spacer, Retainer                                                                                       |
| 57      | 817 00 06-16 | Screw 3/8-16 x 1                                                                                       |
| 59      | 532 14 10-43 | Guard TUV Idler                                                                                        |
| 62      | 872 11 06-16 | Bolt Rdhd Sqnk 3/8-16 unc x 2                                                                          |
| 68      | 532 14 49-59 | V-Belt, 42" Mower                                                                                      |
| 69      | 872 14 05-05 | Bolt, Carriage 5/16-18 x 5/8                                                                           |
| 116     | 532 12 48-42 | Bolt, Shoulder                                                                                         |
| 117     | 532 18 86-06 | Wheel, Gauge                                                                                           |
| 119     | 819 12 14-14 | Washer 3/8 x 7/8 x 14                                                                                  |
| 145     | 532 19 31-97 | Pulley, Idler, Flat                                                                                    |
| 188     | 532 19 51-61 | Stud Fastner W/D Anti-Rotation                                                                         |
| 189     | 873 90 05-00 | Nut Lock Hex Flange 5/16-18                                                                            |
| 190     | 532 19 72-51 | Spring Mower Drive                                                                                     |
| 208     | 817 67 06-08 | Screw THDROL 3/8-16 x 1/2                                                                              |
| --      | 532 19 28-70 | Mandrel Assembly (Includes Housing<br>Shaft and Shaft Hardware Only -<br>Pulley Not Included)          |
| --      | 532 19 97-50 | Replacement Mower, Complete<br>(Std. deck Order separately gauge wheel<br>components Key Nos. 116-119) |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52**  
**MOWER LIFT 45**




| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 2       | 532 19 52-23 | Shaft Asm., Lift             |
| 3       | 532 19 52-31 | Lever Asm., Lift RH          |
| 7       | 532 41 15-55 | Grip, Lever                  |
| 10      | 532 19 63-14 | Spring Torsion               |
| 87      | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock |
| 88      | 532 41 07-10 | Spring Lift Assist           |
| 89      | 819 19 19-12 | Washer Clear Zinc            |
| 90      | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock |

| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 91      | 532 19 51-81 | Link Lift Susp Mower Rear       |
| 97      | 817 00 06-12 | Screw Hex WSH THDR 3/8-16 x 3/4 |
| 98      | 532 19 52-70 | Link Lift Susp. Front Mower     |
| 100     | 873 93 06-00 | Nut Centerlock 3/8-16           |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. LTH1842 (96041005201), PRODUCT NO. 960 41 00-52  
SEAT ASSEMBLY **42**



seat-tex\_6.5SL\_1\_r1

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 1       | 532 19 75-18 | Seat                          |
| 2       | 532 18 01-66 | Bracket Pivot Fender          |
| 3       | 532 14 06-75 | Strap, Asm Fender             |
| 6       | 873 80 06-00 | Nut, Lock w/Ins. 3/8-16 unc   |
| 7       | 532 12 41-81 | Spring, Seat Cprsn            |
| 8       | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems |
| 10      | 532 19 69-77 | Pan, Seat                     |
| 21      | 532 17 18-52 | Bolt, Shoulder 5/16-18        |

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 37      | 873 80 05-00 | Nut, Lock 5/16-18 unc         |
| 40      | 532 19 76-61 | Handle Slide                  |
| 41      | 532 19 82-00 | Spring Latch Seat             |
| 43      | 874 76 06-12 | Bolt Fin Hex 3/8-16 unc x 3/4 |
| 44      | 819 13 38-12 | Washer 13/32 x 2-3/8 x 12 Ga. |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

