

# **ILLUSTRATED PARTS LIST**


**MODEL NO. 96041012100**

**CUSTOMER CATALOG NO. M11577**

**PRODUCT NO. 960 41 01-21**




TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
DECALS **27**



| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 1       | 532 40 03-89 | Decal, Operators              |
| 2       | 532 43 11-71 | Decal, Hood Logo RH/LH        |
| 3       | 532 19 68-41 | Decal, Warning Eng. Symbols   |
| 4       | 532 42 59-29 | Decal, Hood Panel             |
| 5       | 532 15 97-36 | Decal, Chassis Hot Muffler    |
| 6       | 532 18 04-32 | Decal, Fender 100 DB/CE       |
| 7       | 532 42 42-36 | Decal, Wheel Steering         |
| 9       | 532 14 50-05 | Decal, Battery Dnge/Poi       |
| 10      | 532 14 08-37 | Decal, Saddle Brake Parking   |
| 11      | 532 42 51-12 | Decal, Warning DFlect/Ctfingr |
| 12      | 532 42 15-43 | Decal, Mower V-Belt Schematic |

| KEY NO. | PART NO.     | DESCRIPTION                |
|---------|--------------|----------------------------|
| 13      | 532 15 97-37 | Decal, Brake/Clutch Symbol |
| 15      | 532 42 56-78 | Decal, Fender              |
| 17      | 532 41 79-25 | Decal, BS Engine           |
| --      | 532 40 95-05 | Pad, Footrest, LH          |
| --      | 532 41 12-73 | Pad, Footrest, RH          |
| --      | 532 42 30-86 | Manual Oper. Euro          |
| --      | 532 42 30-87 | Manual Oper. Scand         |
| --      | 532 42 30-88 | Manual Oper. E-Bloc        |
| --      | 532 42 30-89 | Manual Oper. Baltic        |

## WHEELS AND TIRES




| KEY NO. | PART NO.     | DESCRIPTION                           |
|---------|--------------|---------------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                        |
| 2       | 532 06 51-39 | Stem Valve                            |
| 3       | 532 42 53-61 | Rim Asm 6 x 3.25 Front                |
| 4       | 532 42 16-52 | Tube Front 13x5-6 (Service Item Only) |
| 5       | 532 12 34-10 | Tire F T 13 x 5.0 - 6                 |
| 6       | 532 12 49-57 | Fitting Grease (Front Wheel Only)     |
| 7       | 532 12 49-59 | Bearing Flange (Front Wheel Only)     |
| 8       | 532 17 50-39 | Cap Axle Blk 1 50 x 1 00              |
| 9       | 532 10 62-30 | Tire R 16 x 6.5                       |
| 10      | 532 00 71-54 | Tube Rear (Service Item Only)         |
| 11      | 532 42 53-62 | Rim Asm 8 x 5.375 Rear                |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. Tube)           |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
SCHEMATIC 38




SCH11

NOTE  
YOUR TRACTOR IS  
EQUIPPED WITH A SPECIAL  
ALTERNATOR SYSTEM.  
THE LIGHTS ARE NOT  
CONNECTED TO THE  
BATTERY, BUT HAVE THEIR  
OWN ELECTRICAL SOURCE.  
BECAUSE OF THIS, THE  
BRIGHTNESS OF THE LIGHTS  
WILL CHANGE WITH ENGINE  
SPEED. AT IDLE THE LIGHTS  
WILL DIM. AS THE ENGINE IS  
SPEEDED UP, THE LIGHTS  
WILL BECOME THEIR  
BRIGHTEST.



IGNITION SWITCH

| POSITION     | CIRCUIT    | "MAKE" |
|--------------|------------|--------|
| OFF          | M+G+A1     |        |
| RUN/OVERRIDE | B+A1       |        |
| RUN          | B+A1       | L+A2   |
| START        | B + S + A1 |        |




WIRING INSULATED CLIPS  
NOTE: IF WIRING INSULATED  
CLIPS WERE REMOVED FOR  
SERVICING OF UNIT, THEY  
SHOULD BE RE-INSTALLED TO  
PROPERLY SECURE YOUR  
WIRING.

NON-REMOVABLE  
CONNECTIONS  
REMOVABLE  
CONNECTIONS



TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
ELECTRICAL **32**

T02K

With 12V Outlet Option



With Service Minder Option




**TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
ELECTRICAL 32**

| <b>KEY<br/>NO.</b> | <b>PART<br/>NO.</b> | <b>DESCRIPTION</b>             |
|--------------------|---------------------|--------------------------------|
| 1                  | 532 14 49-24        | Battery                        |
| 2                  | 874 76 04-12        | Bolt Hex Head 1/4-20 x 3/4     |
| 8                  | 532 19 32-28        | Box Battery                    |
| 16                 | 532 17 61-38        | Switch Interlock Push-In       |
| 21                 | 532 18 37-59        | Harness Socket Light w/4152J   |
| 22                 | 532 00 41-52        | Bulb Light                     |
| 25                 | 532 41 28-94        | Cable Starter                  |
| 26                 | 532 17 51-58        | Fuse                           |
| 27                 | 873 51 04-00        | Nut Keps Hex 1/4-20 unc        |
| 28                 | 532 19 88-85        | Cable, Ground                  |
| 29                 | 532 19 27-49        | Switch, Seat                   |
| 30                 | 532 19 33-50        | Switch, Ign                    |
| 33                 | 532 41 19-35        | Key/Chain                      |
| 34                 | 532 11 07-12        | Switch Light/Reset             |
| 40                 | 532 40 10-98        | Harness Ign. Dash              |
| 41                 | 817 72 04-08        | Screw Thd Cut 1/4-20 x 1/2     |
| 42                 | 532 13 15-63        | Cover, Terminal                |
| 43                 | 532 19 25-07        | Solenoid                       |
| 55                 | 817 06 05-12        | Screw Thdrol 5/16-18 x 3/4     |
| 71                 | 532 40 04-49        | Harness Chassis                |
| 79                 | 532 17 52-42        | Socket Asm Bulb Twistlock      |
| 87                 | 532 19 78-02        | Switch Interlock Clutch Cable  |
| 90                 | 532 40 07-25        | Cover, Terminal Battery        |
| 92                 | 532 19 66-15        | Cover, Harness Pigtail Console |
| 93                 | 532 19 25-40        | Screw Plastite 10-14 x 2.0     |
| 94                 | 532 19 18-34        | Module Reverse Console         |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
CHASSIS AND ENCLOSURES **39**




chassis-tex\_elite pro\_9\_r1

**TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
CHASSIS AND ENCLOSURES **39****

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                     |
|------------|--------------|---------------------------------|
| 5          | 532 41 17-64 | Dash                            |
| 14         | 532 18 65-80 | Hood                            |
| 15         | 532 18 97-54 | Lens LH                         |
| 18         | 532 40 82-98 | Grille Asm.                     |
| 25         | 532 18 97-55 | Lens RH                         |
| 34         | 532 19 61-25 | Plate Engine                    |
| 36         | 817 06 05-12 | Screw 5/16-18 x 3/4             |
| 37         | 532 42 09-86 | Fender                          |
| 52         | 873 68 05-00 | Nut Crown Lock 5/16             |
| 58         | 532 41 22-80 | Drawbar, Upper                  |
| 68         | 817 49 05-08 | Screw THDROL 5/16-18 x 1/2      |
| 130        | 532 41 63-58 | Screw #10 x .750 BOS Thread     |
| 137        | 532 18 49-21 | Bumper Hood                     |
| 138        | 532 40 97-30 | Cupholder                       |
| 150        | 532 18 44-61 | Duct Intake Air                 |
| 151        | 532 40 78-07 | Bracket Pivot                   |
| 152        | 532 19 95-35 | Shield Browning                 |
| 159        | 817 00 06-12 | Screw 3/8-7/16 x 3/4            |
| 162        | 532 14 24-32 | Screw                           |
| 175        | 532 19 32-43 | Crossmember                     |
| 176        | 532 40 07-76 | Screw 10-24 x 5/8               |
| 177        | 532 19 52-28 | Bushing Steering                |
| 180        | 532 41 46-85 | Chassis                         |
| 181        | 532 40 47-96 | Bushing Mount Fender Cargo      |
| 182        | 532 19 30-57 | Dash Lower                      |
| 183        | 874 78 05-20 | Bolt 5/16-18 unc x 1-1/4        |
| 186        | 532 18 97-53 | Insert Grille                   |
| 189        | 817 00 05-12 | Screw 5/16-18 x 3/4             |
| 194        | 873 90 05-00 | Nut Lock Hex Flange 5/16-18     |
| 196        | 532 41 45-81 | Console Asm. Deck Lift          |
| 207        | 532 18 38-33 | Bezel RH                        |
| 208        | 532 18 38-32 | Bezel LH                        |
| 213        | 874 76 05-12 | Bolt 5/16-18 x 3/4              |
| 217        | 532 40 91-67 | Rod Pivot Hood                  |
| 218        | 532 19 63-95 | X-Piece Hood Stop               |
| 228        | 532 19 51-61 | Stud Fastener                   |
| 235        | 532 40 61-29 | Spacer Fender                   |
| 236        | 873 93 05-00 | Nut Lock 5/16-18 unc            |
| 287        | 817 60 04-06 | Screw Hex Washhead 1/4-20 x 3/8 |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm




drive-tex\_peerless\_fender\_22\_r1

**TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
DRIVE **40****

| KEY NO. | PART NO.            | DESCRIPTION                                                               |
|---------|---------------------|---------------------------------------------------------------------------|
| 1       | -----               | Transaxle, Peerless 205-569<br>(Order parts from transaxle manufacturer.) |
| 2       | 532 12 35-83        | Key Square                                                                |
| 15      | 819 13 13-16        | Washer 13/32 x 13/16 x 16 Ga.                                             |
| 17      | 532 19 72-97        | Spring, Brake                                                             |
| 22      | 532 19 76-60        | Rod Shift                                                                 |
| 23      | 532 17 16-74        | Knob                                                                      |
| 26      | 532 19 74-55        | Spring Brake RTN                                                          |
| 29      | 532 19 72-67        | Rod, Brake                                                                |
| 33      | 812 00 00-01        | Ring E                                                                    |
| 35      | 532 19 77-22        | Rod, Brake, Park                                                          |
| 37      | 532 12 17-49        | Washer 25/32 x 1-1/4 x 16 Ga.                                             |
| 42      | 532 12 48-72        | Cover, Foot Pedal                                                         |
| 49      | 872 11 06-14        | Bolt                                                                      |
| 50      | 532 19 43-27        | Pulley Idler Flat                                                         |
| 51      | 873 90 06-00        | Lock Nut 3/8-16                                                           |
| 52      | 532 19 43-26        | Idler V-Groove                                                            |
| 56      | <b>532 13 82-55</b> | V-Belt, Drive                                                             |
| 61      | 532 16 59-99        | Pulley Transaxle                                                          |
| 64      | 532 19 62-00        | Shaft Asm. Pedal Brake Control                                            |
| 70      | 532 42 53-66        | Console                                                                   |
| 73      | 874 49 05-44        | Bolt 5/16-18 Gr. 5                                                        |
| 74      | 532 14 24-32        | Screw 1/4 x 1/2                                                           |
| 116     | 873 90 05-00        | Nut Lock Hex Flange 5/16-18                                               |
| 125     | 817 00 05-12        | Screw 5/16-18 x 3/4                                                       |
| 134     | 532 19 78-57        | Arm Shift                                                                 |
| 139     | 874 55 04-12        | Bolt 1/4-20 unf Gr. 8 w/Patch                                             |
| 140     | 810 04 04-00        | Washer Lock Hvy Helical 1/4                                               |
| 141     | 819 09 12-10        | Washer 9/32 x 3/4 x 10 Ga.                                                |
| 155     | 812 00 00-28        | Ring Retainer                                                             |
| 157     | 532 10 57-01        | Washer Plate Shf                                                          |
| 158     | 532 19 43-52        | Keeper T/A                                                                |
| 159     | 876 02 04-12        | Pin Cotter 1/8 x 3/4                                                      |

| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 160     | 532 16 94-84 | Retainer Clip                   |
| 161     | 532 10 57-09 | Spring, Return, Clutch          |
| 165     | 532 19 62-12 | Busing Shaft Brake Hand Control |
| 166     | 532 19 72-90 | Nut Push .625                   |
| 167     | 532 40 52-57 | Latch Brake Parking             |
| 172     | 532 19 76-57 | Strap Torque LH                 |
| 174     | 532 19 72-89 | Nut Push                        |
| 175     | 532 19 78-58 | Shaft Asm Shift                 |
| 176     | 532 19 62-14 | Arm Clevis Rod Shift            |
| 178     | 532 19 74-56 | Spring Shift                    |
| 183     | 532 13 70-57 | Spacer, Axle                    |
| 184     | 532 41 12-89 | Handle Parking Brake            |
| 185     | 872 11 06-22 | Bolt                            |
| 186     | 532 19 43-21 | Spacer Retainer                 |
| 187     | 819 13 32-10 | Washer                          |
| 188     | 532 19 43-23 | Link Clutch Ground Drive        |
| 189     | 532 19 43-17 | Bellcrank Ground Drive          |
| 190     | 532 19 43-18 | Keeper Bellcrank Ground Drive   |
| 192     | 532 15 03-60 | Nut Lock Center 1/4-28          |
| 193     | 817 06 05-12 | Screw 5/16-18 x 3/4             |
| 195     | 532 19 73-32 | Bracket Brake Rod               |
| 202     | 532 19 78-59 | Link Shift                      |
| 203     | 819 11 11-16 | Washer 11/32 x 11/16 x 16 Ga.   |
| 205     | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.   |
| 221     | 532 40 31-87 | Retainer Spring Clip Handle     |
| 232     | 874 78 07-16 | Bolt 7/16-14 x 1 Gr. 5          |
| 233     | 532 40 52-96 | Washer Serrated                 |
| 263     | 81700 06-12  | Screw Hexwsh Thdr 3/8-16 x 3/4  |
| 268     | 532 18 24-02 | Guard Muffler                   |
| 275     | 819 13 16-14 | Washer 13/32 x 1 x 14 Ga.       |
| 287     | 532 42 16-48 | Keeper Pulley Transaxle         |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



**TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
ENGINE 24**


| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                                                             |
|------------|--------------|-------------------------------------------------------------------------|
| 1          | -----        | Engine BS Model No. 217807<br>(Order parts from engine<br>manufacurer.) |
| 2          | 532 17 97-58 | Muffler                                                                 |
| 9          | 532 19 43-19 | Keeper Belt Engine                                                      |
| 12         | 532 14 01-86 | Pulley Engine                                                           |
| 15         | 532 40 75-45 | Tank Fuel 1.5                                                           |
| 18         | 532 19 77-25 | Cap Asm                                                                 |
| 20         | 532 41 17-24 | Control Throttle                                                        |
| 21         | 532 41 63-58 | Screw #10 x 0.750 BOS Thread                                            |
| 28         | 532 13 70-40 | Fuel Line                                                               |
| 29         | 532 13 71-80 | Spark Arrester Kit                                                      |
| 37         | 532 12 34-87 | Clamp Hose                                                              |
| 42         | 810 04 07-00 | Washer Lock Hvy HLCL SPR 7/16                                           |
| 45         | 873 51 04-00 | Nut Keps Hex 1/4-20 unc                                                 |
| 69         | 532 16 52-91 | Gasket                                                                  |
| 79         | 532 19 23-34 | Screw Socket HD 5/16 - 18 x 75                                          |
| 81         | 532 14 84-56 | Tube Drain Oil Easy                                                     |
| 82         | 532 18 16-54 | Plug Drain Oil                                                          |
| 84         | 817 06 06-20 | Screw 3/8-16 x 1-1/4                                                    |
| 85         | 532 17 39-37 | Bolt Hex 7/16-20 x 4 Gr. 5                                              |
| 90         | 817 00 06-16 | Screw 3/8-16 x 1                                                        |
| 96         | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.                                              |
| 97         | 817 67 04-12 | Screw 1/4-20 x 3/4                                                      |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

### Engine Power Rating Information

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J11940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-5). Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net horsepower). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

## STEERING ASSEMBLY 41




steering-tex\_HUSQSR\_3

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 42 45-43 | Wheel, Steering                |
| --      | 532 19 36-51 | Wheel, Steering Prem 2         |
| 2       | 532 41 81-68 | Axle Asm., Front               |
| 4       | 532 41 68-45 | Spindle Asm., LH               |
| 5       | 532 41 68-46 | Spindle Asm., RH               |
| 6       | 532 12 49-31 | Bearing, Race Thrust Hardened  |
| 7       | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.  |
| 8       | 812 00 00-29 | Ring, Klip #T5304-75           |
| 9       | 532 12 12-32 | Cap, Spindle                   |
| 13      | 532 12 17-49 | Washer, 25/32 x 1-1/4 x 16 Ga. |
| 14      | 810 04 06-00 | Washer, Lock Hvy Hlcl Spr 3/8  |
| 15      | 873 54 06-00 | Nut, Crown Lock 3/8-24 unf     |
| 16      | 532 19 60-74 | Shaft Steering                 |
| 19      | 532 19 47-29 | Plate Steering                 |
| 20      | 532 41 12-91 | Boot, Steering                 |
| 21      | 532 18 67-37 | Adapter, Wheel Steering        |
| 22      | 532 19 48-45 | Bushing, Strg. Blk             |
| 26      | 532 42 46-91 | Insert, Wheel Steering         |
| --      | 532 19 36-52 | Insert, Wheel Steering Prem 2  |
| 28      | 817 00 06-12 | Screw 3/8-16 x 3/4             |
| 33      | 810 04 05-00 | Washer Lock 5/16               |
| 35      | 532 19 47-32 | Gear, Sector Plate             |
| 45      | 819 11 38-12 | Washer 11/32 x 3/8 x 12 Ga.    |

| KEY NO. | PART NO.     | DESCRIPTION                         |
|---------|--------------|-------------------------------------|
| 53      | 532 18 89-67 | Washer Hardened .793 x 1.637 x .060 |
| 57      | 532 40 74-65 | Bracket Upstop                      |
| 58      | 532 19 47-47 | Bolt Shoulder Sector Pivot CFM      |
| 59      | 532 19 47-48 | Washer Thrust Sector Steering       |
| 60      | 873 97 10-00 | Nut Flange Lock 5/8-11              |
| 61      | 532 19 47-40 | Draglink, LH                        |
| 62      | 532 19 47-41 | Draglink, RH                        |
| 63      | 817 00 05-12 | Screw 5/16-18 x 3/4                 |
| 64      | 532 19 98-49 | Retainer Clip Spring Steering       |
| 66      | 871 02 07-48 | Bolt Hex Fghd 7/16-14 x 3 Serr      |
| 67      | 532 19 47-37 | Bushing PM Front Axle               |
| 68      | 873 90 07-00 | Nut Lock Flange 7/16-14 Gr. 5       |
| 69      | 532 19 91-62 | Washer 1.5 x .505 x .118            |
| 70      | 532 41 70-65 | Bracket Deck Susp. Front            |
| 71      | 532 19 60-75 | Shaft Extension Steering            |
| 72      | 874 78 05-72 | Bolt 5/16-18 x 4.5 Gr.              |
| 74      | 532 12 49-37 | Bearing                             |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
SEAT ASSEMBLY **42**




seat-tex\_knob\_1

| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 1       | 532 19 75-11 | Seat                            |
| 2       | 532 18 01-66 | Bracket Pivot Fender            |
| 3       | 532 14 06-75 | Strap, Asm Fender               |
| 5       | 532 14 50-06 | Clip Push-In Hinged             |
| 6       | 873 80 06-00 | Nut, Lock w/Ins. 3/8-16 unc     |
| 7       | 532 12 41-81 | Spring, Seat Cprsn              |
| 8       | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems   |
| 10      | 532 19 91-80 | Pan, Seat                       |
| 12      | 532 19 93-70 | Bracket Seat Mounting           |
| 13      | 532 12 12-48 | Bushing Snap                    |
| 14      | 870 05 04-12 | Bolt RDHD Sht NK 1/4-20 x 1-1/2 |

| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 15      | 532 13 43-00 | Spacer Split .28 x .96 Yel Zinc |
| 16      | 532 12 37-40 | Spring                          |
| 17      | 532 12 39-76 | Nut Lock 1/4 LGE FLG Gr. Zinc   |
| 19      | 532 19 93-72 | Knob Seat Adj. 3/18-16" Tex     |
| 21      | 532 17 18-52 | Bolt, Shoulder 5/16-18          |
| 37      | 873 80 05-00 | Nut, Lock 5/16-18 unc           |
| 42      | 532 19 93-71 | Washer Cup Seat Tex LT          |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
MOWER **44**




tex-deck\_SRD\_25\_r1

**TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21  
MOWER 44**

| KEY NO. | PART NO.     | DESCRIPTION                         | KEY NO. | PART NO.     | DESCRIPTION                                                                                                                              |
|---------|--------------|-------------------------------------|---------|--------------|------------------------------------------------------------------------------------------------------------------------------------------|
| 1       | 532 41 92-72 | Deck Weldment 30"Srd                | 30      | 532 19 70-26 | Spring Torsion Dfl 38/42/46 Gr                                                                                                           |
| 2       | 532 19 51-61 | Stud Fastner w/'D'anti-Rotatio      | 31      | 532 11 04-52 | Nut Push Phos & Oil                                                                                                                      |
| 3       | 873 90 05-00 | Nut Lock Hex Flange 5/16 - 18       | 32      | 532 40 18-72 | Spring Return Deck 38/46"                                                                                                                |
| 4       | 532 41 76-45 | Bracket Clutch Cable                | 33      | 532 18 72-81 | Housing Mandrel 4pt Service                                                                                                              |
| 5       | 817 00 05-10 | Bolt 5/16-18                        | 34      | 532 19 28-72 | Shaft Asm Mndrl N/Greaseable38                                                                                                           |
| 6       | 532 41 88-63 | Arm Susp Mower Rear Srd             | 35      | 532 41 92-73 | Blade Mower Hp/Mulch Srd                                                                                                                 |
| 7       | 532 41 63-58 | Screw #10 x 0.750 BOS Thread        | 36      | 532 19 30-03 | Bolt/Washer Asm 7/16 - 20 unf                                                                                                            |
| 8       | 532 42 02-52 | Arm Idler 30"Srd                    | 37      | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga.                                                                                                            |
| 9       | 532 19 90-92 | Spacer Retainer                     | 38      | 532 19 65-39 | Bolt Shoulder                                                                                                                            |
| 10      | 817 00 06-16 | Screw 3/8 - 16 X 1 Smgml Tap/R Blk  | 39      | 532 10 53-04 | Cap Sleeve                                                                                                                               |
| 11      | 532 13 77-29 | Screw Thd Roll 1/4 - 20 X 5/8       | 40      | 532 41 92-70 | Keeper Belt Engine LH                                                                                                                    |
| 12      | 532 19 94-70 | Arm Brake Mower 38" RH Tex          | 41      | 532 41 92-65 | Keeper Belt Engine RH                                                                                                                    |
| 13      | 872 11 06-12 | Bolt Carr Sh 3/8 - 16 X 1 - 1/2 Gr5 | 42      | 817 00 06-12 | ScrewHexwshTHDR3/8-16x3/4BL                                                                                                              |
| 14      | 532 15 60-85 | Keeper Belt Idler                   | 43      | 532 41 68-77 | Pulley Mandrel 6 5 Pd 30"                                                                                                                |
| 15      | 532 14 67-63 | Pulley Ikler V-Groove Dim 4.25      | 67      | 532 40 97-92 | Handle clutch cable                                                                                                                      |
| 16      | 873 90 06-00 | Nut Lock FIG 3/8 - 16 unc           | 70      | 532 19 83-32 | Clutch Asm. Manual                                                                                                                       |
| 17      | 532 40 02-34 | Nut Flange Lock Top                 | 76      | 532 41 55-98 | Port Washout                                                                                                                             |
| 18      | 532 18 76-90 | Washer Spacer Mandrel               | 152     | 532 40 87-14 | Manual Clutch Cable                                                                                                                      |
| 19      | 532 11 04-85 | Bearing Ball Mandrel                | --      | 532 19 28-70 | Mandrel Assembly (Includes Hous-<br>ing, Shaft Assembly, And Bearing<br>Only - Pulley/Nut/Washer And Blade<br>Bolt/Washers Not Included) |
| 20      | 532 17 39-84 | Screw Thd Roll Dod Pt Hex           | --      | 532 42 16-96 | Replacement Mower Complete                                                                                                               |
| 21      | 532 41 69-10 | Keeper Belt Mandrel 30"             |         |              |                                                                                                                                          |
| 22      | 532 19 31-98 | Pulley Idler Flat Unplated          |         |              |                                                                                                                                          |
| 23      | 817 49 06-28 | Screw Thdrol 3/8 - 16 X 1-3/4       |         |              |                                                                                                                                          |
| 24      | 819 13 20-12 | Washer 13/32 X 1 - 1/4 X 12 Ga      |         |              |                                                                                                                                          |
| 25      | 532 42 02-53 | Keeper Belt 30"Srd                  |         |              |                                                                                                                                          |
| 26      | 532 43 03-13 | Cover Mandrel Mwr 30"Black          |         |              |                                                                                                                                          |
| 27      | 532 41 92-71 | V-Belt Drive                        |         |              |                                                                                                                                          |
| 28      | 532 42 47-69 | Shield Asm Deflect Mwr 30s Blk      |         |              |                                                                                                                                          |
| 29      | 532 42 08-95 | Pin Hinge 30                        |         |              |                                                                                                                                          |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. M11577 (96041012100), PRODUCT NO. 960 41 01-21**  
**MOWER LIFT 45**



| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 2       | 532 19 52-23 | Shaft Asm., Lift             |
| 3       | 532 19 52-31 | Lever Asm., Lift RH          |
| 7       | 532 41 17-42 | Grip, Lever                  |
| 10      | 532 19 63-14 | Spring Torsion               |
| 87      | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock |
| 88      | 532 41 07-10 | Spring Lift Assist           |
| 89      | 819 19 19-12 | Washer Clear                 |
| 90      | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock |

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 91      | 532 19 51-81 | Link Lift Susp Mower Rear      |
| 97      | 817 00 06-12 | Screw 3/8-16 x 3/4             |
| 98      | 532 19 52-64 | Link Lift Susp. Front Mower    |
| 100     | 873 93 06-00 | Nut Centerlock 3/8-16          |
| 113     | 819 17 19-12 | Washer 17/32 x 1-3/16 x 12 Ga. |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

