

Rider Pro 18

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar

A




B

*compl 535 44 75-01




C




xxx xx xx-xx = New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

D




E

*compl 544 12 60-01



xxx xx xx-xx = New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

F



New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

xxx xx xx-xx =

535 46 05-01

728 84 43-05 (x2)

506 86 34-01 (x2)

735 31 26-00

(x3) 535 43 28-01

535 42 37-01

735 31 26-00

535 42 36-01

738 21 05-04

735 31 40-10

535 42 19-01

535 42 38-01 (x2)

535 42 32-01

732 21 18-01 (x2)

738 21 05-04

(x3) 725 53 70-01

535 42 35-01

721 43 35-01

CSU compl 535 45 71-02

506 55 46-01

506 53 94-01

506 55 47-01 (x2)

535 42 78-01

735 31 33-00

(x2) 535 42 38-01

535 42 26-01

(x2) 732 21 18-01

732 21 20-51

*506 50 08-02

(x2) 506 52 24-01

731 23 20-51 (x4)

535 42 41-01*

738 22 04-19*

735 31 40-10*

734 11 74-41



(x2) 506 58 91-02

725 25 00-51

735 31 14-20 (x2)


xxx xx xx-xx = New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

H



J


Kawasaki FH531V



xxx xx xx-xx = New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj


K

****compl 535 40 61-01**




xxx xx xx-xx = New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

L K66




xxx xx xx-xx = New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

M



xxx xx xx-xx = New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

N



New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

xxx xx xx-xx =

P

544 21 14-01




535 47 67-01



506 99 96-01



Warning
506 94 48-01



506 58 45-01



506 89 33-01



506 89 35-01



535 43 20-01



506 96 83-01



506 89 34-01



535 44 99-01



535 41 31-01



535 45 01-01



544 24 98-01



535 45 01-01


544 24 98-02

PR 18


xxx xx xx-xx = New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

Q

*compl 506 93 24-01




R



New part,
 Neues teil,
 Nouvelle piece,
 Nueva pieza,
 Ny detalj

xxx xx xx-xx =


S



New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

xxx xx xx-xx =


T1 Combi 103



New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj


xxx xx xx-xx =

T2




Yttre.
Outer.
Exterieur.
Äusser.
Ulko.

****compl 544 06 59-01 (x2)**



Mitten.
Centre.
Centre.
Zentrum.
Keskj.

***compl 544 06 59-02**



***compl 544 11 29-01

544 23 81-03


Combi 103



**New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj**


XXX XX XX-XX

U1 Combi 112




U2

Combi 112
compl 965 07 85-01




Yttre.
Outer.
Exterieur.
Äusser.
Ulko.

**compl 544 06 59-01 (x2)



Mitten.
Centre.
Centre.
Zentrum.
Keski.

*compl 544 06 59-02



***compl 544 11 30-01


544 23 81-05

Combi 112

535 43 74-01



506 78 97-01



506 92 90-01




544 06 59-01

New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

XXX XX XX-XX =

V1


Combi 94XP



**New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj**


V2 Combi 94XP

compl 953 53 67-01




Yttre.
Outer.
Exterieur.
Äusser.
Ulko.

**compl 535 50 35-02 (x2)



Mitten.
Centre.
Centre.
Zentrum.
Keski.

*compl 535 50 35-01



***compl 544 06 57-03

544 23 81-02

Combi 94 XP

535 43 74-01



506 78 97-01




506 92 90-01



New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

XXX XX XX-XX =

W1 Combi 103XP




New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj

xxx xx xx-xx =

W2



X1 Combi 112XP



Combi 112XP
compl 965 07 87-01



**New part,
Neues teil,
Nouvelle piece,
Nueva pieza,
Ny detalj**