


**ILLUSTRATED PARTS LIST**


**MFG. ID NO. 96041038700**  
**CUSTOMER CATALOG NO. TS 348**  
**PRODUCT NO. 960 41 03-87**



**47**

**588739101**

**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**DECALS 27**




**KEYPART  
NO. NO.**

|    |              |                             |
|----|--------------|-----------------------------|
| 1  | 581 72 40-01 | Decal, Brake/Clutch Sym     |
| 2  | 532 41 86-00 | Decal, Fwd Pedal Dealer     |
| 6  | 581 57 97-01 | Decal, Warning Eng. Syms.   |
| 7  | 581 57 80-01 | Decal, Saddle Brake Parking |
| 8  | 587 01 51-01 | Decal, Warn. Reserve Fuel   |
| 9  | 532 14 50-05 | Decal, Battery Dan./Poi.    |
| 10 | 586 80 03-01 | Decal, Oper. Cruise Sym.    |
| 11 | 581 57 81-01 | Decal, Warning Sym.         |
| 12 | 588 73 91-01 | Decal, RPL                  |
| 14 | 588 77 47-01 | Decal, Panel Side           |
| 15 | 581 57 96-01 | Decal, Chassis Hot Muffler  |
| 16 | 581 62 73-01 | Decal, Badge Logo           |

**KEY PART  
NO. NO.**

|    |              |                                        |
|----|--------------|----------------------------------------|
| 17 | 581 72 43-01 | Decal, No Step                         |
| 18 | 581 58 00-02 | Decal, Mower DFLCTR Warning<br>CTFNGR  |
| 20 | 584 90 46-01 | Decal, Deck Lift                       |
| -- | 501 74 90-01 | Decal, Drawbar Locking<br>Differential |
| -- | 581 72 48-01 | Decal, Bypass                          |
| -- | 532 43 98-82 | Pad, Footrest, LH                      |
| -- | 532 43 98-81 | Pad, Footrest, RH                      |
| -- | 581 72 46-01 | Decal, Drawbar Load                    |
| -- | 588 77 53-28 | Manual, Operator's English             |

**WHEELS AND TIRES**




**KEY PART  
NO. NO.**

|    |              |                                    |
|----|--------------|------------------------------------|
| 1  | 532 05 91-92 | Cap, Valve, Tire                   |
| 2  | 532 06 51-39 | Stem, Valve                        |
| 3  | 532 18 18-39 | Rim Assembly, Front                |
| 4  | 532 05 99-04 | Tube, Front (Service Item Only)    |
| 5  | 532 16 10-24 | Tire, Front 16 x 6.5-8             |
| 6  | 532 12 49-57 | Fitting, Grease (Front Wheel Only) |
| 7  | 532 12 49-59 | Bearing, Flange (Front Wheel Only) |
| 8  | 532 17 50-39 | Cap, Axle                          |
| 9  | 532 17 04-56 | Tire, Rear 20 x 10-8               |
| 10 | 532 12 49-26 | Tube, Rear (Service Item Only)     |
| 11 | 532 13 83-37 | Rim Assembly, Rear                 |
| -- | 532 14 43-34 | Sealant, Tire (10 oz. Tube)        |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm


TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87  
SCHEMATIC 38

SCH12



**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**ELECTRICAL 32**

T38S




**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**ELECTRICAL 32**

| <b>KEY PART<br/>NO.</b> | <b>NO.</b>   | <b>DESCRIPTION</b>                  |
|-------------------------|--------------|-------------------------------------|
| 1                       | 532 16 34-65 | Battery                             |
| 2                       | 874 76 04-12 | Bolt Hex Hd. 1/4-20 unc x 3/4       |
| 8                       | 587 20 51-01 | Battery Box                         |
| 16                      | 532 17 61-38 | Switch Interlock                    |
| 21                      | 585 43 64-01 | Harness Light                       |
| 24                      | 585 55 56-01 | Cable Battery                       |
| 25                      | 585 55 55-01 | Cable Starter                       |
| 26                      | 532 17 51-58 | Fuse                                |
| 27                      | 873 51 04 00 | Nut Keps Hex 1/4-20 unc             |
| 28                      | 532 41 65-88 | Cable Ground                        |
| 29                      | 532 40 15-45 | Switch Seat                         |
| 30                      | 532 19 33-50 | Switch Ign.                         |
| 33                      | 532 41 19-35 | Key/Chain                           |
| 34                      | 532 11 07-12 | Switch Light                        |
| 40                      | 501 13 31-01 | Harness Ign. Dash                   |
| 41                      | 817 72 04-08 | Screw 1/4-20 x 1/2                  |
| 42                      | 532 13 15-63 | Cover Terminal                      |
| 43                      | 532 19 25-07 | Solenoid                            |
| 45                      | 587 55 39-03 | Ammeter Guage Round                 |
| 46                      | 587 55 40-03 | Hourmeter Gauge                     |
| 50                      | 582 10 76-01 | Switch PTO                          |
| 55                      | 817 06 05-12 | Screw 5/16-18 x 3/4                 |
| 71                      | 532 19 42-76 | Harness Ign. Chassis                |
| 90                      | 532 43 53-95 | Cover Terminal Battery              |
| 99                      | 817 67 04-12 | Screw Hex Wsh. Thdrol. 1/4-20 x 3/4 |
| 100                     | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.          |
| 102                     | 532 40 44-54 | Harness Pigtail Tex ROS Tufftorq    |
| 105                     | 532 40 75-68 | Switch Reverse                      |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**CHASSIS AND ENCLOSURES 39**



chassis-tex\_GT HUSQ II\_185\_r1


**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**CHASSIS AND ENCLOSURES 39**

| KEY NO. | PART NO.     | DESCRIPTION                      |
|---------|--------------|----------------------------------|
| 2       | 532 41 22-82 | Drawbar Lower                    |
| 3       | 532 44 44-81 | Applique                         |
| 5       | 582 09 11-01 | Dash                             |
| 14      | 532 44 11-77 | Hood                             |
| 15      | 585 42 03-01 | Lens LH                          |
| 18      | 587 52 34-01 | Grille                           |
| 25      | 585 42 02-01 | Lens RH                          |
| 36      | 817 06 05-12 | Screw 5/16-18 x 3/4              |
| 37      | 532 44 12-08 | Fender                           |
| 58      | 532 41 22-81 | Drawbar Upper                    |
| 68      | 817 49 05-08 | Screw 5/16-18 x 1/2              |
| 125     | 581 68 48-01 | Clip Fuel Line                   |
| 130     | 532 41 63-58 | Screw #10 x 0.750 BOS Thread     |
| 137     | 532 40 75-90 | Bumper Dash                      |
| 146     | 581 85 79-01 | Bolt                             |
| 150     | 532 43 97-31 | Air Duct                         |
| 151     | 532 43 66-70 | Bracket Pivot                    |
| 152     | 532 43 98-70 | Shield Browning                  |
| 159     | 817 00 06-12 | Screw Hexwsh THDR 3/8 - 16x3/4   |
| 161     | 532 43 99-29 | Window Fuel                      |
| 162     | 532 14 24-32 | Screw                            |
| 165     | 532 19 43-30 | Support Tank Rear                |
| 175     | 532 19 63-04 | Crossmember                      |
| 176     | 532 40 07-76 | Screw 10-24 x 5/8                |
| 177     | 532 19 52-28 | Bushing Steering                 |
| 180     | 532 44 55-59 | Chassis                          |
| 182     | 532 40 68-59 | Dash Lower                       |
| 183     | 874 52 05-20 | Bolt 5/16-18 x 1-1/4 Full Thread |
| 189     | 817 00 05-12 | Screw 5/16-18 x 3/4              |
| 191     | 586 18 28-01 | Insert RH                        |
| 194     | 873 90 05-00 | Nut Lock Hex Flange 5/16-18      |

| KEY NO. | PART NO.     | DESCRIPTION            |
|---------|--------------|------------------------|
| 195     | 532 40 41-37 | Plug Hole Dash Lower   |
| 196     | 532 43 97-16 | Console Asm. Deck Lift |
| 199     | 532 19 82-59 | Plate Deck Lift        |
| 202     | 532 43 97-28 | Vent Side Hood RH      |
| 203     | 532 43 97-27 | Vent Side Hood LH      |
| 204     | 532 44 44-84 | Vent Top Hood          |
| 205     | 532 43 97-30 | Trim Hood Side RH      |
| 206     | 532 43 97-29 | Trim Hood Side LH      |
| 207     | 585 42 00-02 | Bezel RH               |
| 208     | 585 42 01-02 | Bezel LH               |
| 214     | 532 19 91-45 | Clip Retainer Tinner   |
| 217     | 532 40 91-67 | Rod Pivot              |
| 221     | 532 19 89-09 | Reflector LH           |
| 228     | 532 19 51-61 | Stud Fastner           |
| 233     | 532 19 65-39 | Bolt Shoulder          |
| 235     | 532 40 61-29 | Spacer Fender          |
| 236     | 873 93 05-00 | Nut Lock 5/16-18 unc   |
| 296     | 585 42 05-01 | LED Light LH           |
| 297     | 586 18 29-01 | Insert LH              |
| 299     | 585 42 04-01 | LED Light RH           |
| 306     | 873 90 06-00 | Nut Lock               |
| 335     | 532 44 82-04 | Cover Dash RH          |
| 336     | 532 44 53-09 | Cover Dash LH          |
| 350     | 532 44 51-43 | Clip X-mas Tree        |
| 375     | 586 90 82-01 | Dash Clip-On Bumper    |
| --      | 532 43 18-82 | Kit Guard Brush        |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**DRIVE 40**




drive-tex\_K46\_pedal\_197

**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**DRIVE 40**

| KEY NO. | PART NO.     | DESCRIPTION                                                                       |
|---------|--------------|-----------------------------------------------------------------------------------|
| 1       | — — — — —    | Transaxle, TUFFTORQ K46 CR (501051401) (Order parts from transaxle manufacturer.) |
| 2       | 532 12 35-83 | Key                                                                               |
| 15      | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga.                                                     |
| 17      | 532 41 36-78 | Spring, Brake                                                                     |
| 26      | 532 19 96-79 | Spring Return Cruise                                                              |
| 29      | 532 40 38-06 | Rod, Brake                                                                        |
| 33      | 812 00 00-01 | Ring E                                                                            |
| 35      | 583 86 45-01 | Rod, Brake, Park                                                                  |
| 37      | 532 18 89-67 | Washer Hardened                                                                   |
| 42      | 532 12 48-72 | Cover, Foot Pedal                                                                 |
| 49      | 872 11 06-14 | Bolt                                                                              |
| 50      | 532 19 43-27 | Pulley Idler Flat                                                                 |
| 51      | 873 90 06-00 | Lock Nut 3/8-16                                                                   |
| 52      | 532 19 43-26 | Idler V-Groove                                                                    |
| 56      | 532 13 09-69 | V-Belt, Drive                                                                     |
| 64      | 532 19 78-65 | Shaft Asm. Pedal Brake Control                                                    |
| 69      | 532 42 33-03 | Hairpin Soft Zink .059 x 1.125                                                    |
| 70      | 532 43 96-61 | Console Shift                                                                     |
| 73      | 874 49 05-40 | Bolt Hex Flghd 5/16-18 Gr. 5                                                      |
| 74      | 532 14 24-32 | Screw Hex Wsh. Hi-Lo 1/4 x 1/2 unc                                                |
| 92      | 874 76 05-20 | Bolt Fin Hex 5/16-18 unc x 1.25                                                   |
| 99      | 582 40 45-01 | Rod Spring Bypass                                                                 |
| 116     | 873 90 05-00 | Nut Lock Hex Flange 5/16-18                                                       |
| 125     | 817 00 05-12 | Screw 5/16-18 x 3/4                                                               |
| 153     | 532 12 47-88 | Retainer Spring                                                                   |
| 159     | 876 02 04-12 | Pin Cotter 1/8 x 3/4                                                              |
| 160     | 532 16 94-84 | Retainer Clip                                                                     |
| 161     | 532 10 57-09 | Spring, Return, Clutch                                                            |
| 163     | 532 44 82-75 | Rod Pedal Control                                                                 |
| 166     | 532 42 91-64 | Nut Push                                                                          |
| 167     | 532 40 52-57 | Latch Brake Parking                                                               |
| 170     | 532 41 34-30 | Keeper Belt Centerspan                                                            |
| 183     | 532 13 70-57 | Spacer Split                                                                      |
| 184     | 587 65 37-01 | Handle Parking Brake                                                              |

| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 185     | 872 11 06-22 | Bolt Rdhd Sqnk 3/8-16 x 2-1/2  |
| 186     | 532 19 43-21 | Spacer Retainer                |
| 187     | 819 13 32-10 | Washer                         |
| 188     | 582 21 70-01 | Link Clutch Ground Drive, Long |
| 189     | 532 19 43-17 | Bellcrank Ground Drive         |
| 190     | 532 19 43-18 | Keeper Bellcrank Ground Drive  |
| 196     | 817 00 06-16 | Screw 3/8-16 x 1               |
| 197     | 585 65 86-01 | Link Clutch Anti-Rotation      |
| 205     | 532 12 17-48 | Washer                         |
| 206     | 532 44 85-96 | Bracket Mount Latch Cruise     |
| 207     | 587 03 14-01 | Latch Control Cruise           |
| 208     | 532 19 78-69 | Gear Sector Control Cruise     |
| 209     | 532 19 95-92 | Rod Control Cruise             |
| 210     | 532 19 78-60 | Rocker Asm. Pedal Control      |
| 211     | 532 12 01-83 | Bearing Nylon                  |
| 213     | 532 40 31-19 | Knob Control Cruise            |
| 214     | 532 41 68-63 | Pedal Forward                  |
| 215     | 586 60 65-02 | Pedal Reverse                  |
| 220     | 532 19 89-08 | Reflector RH                   |
| 221     | 532 40 31-87 | Retainer Spring Clip Handle    |
| 222     | 879 21 20-10 | Washer 21/32 x 1-1/4 x 10 Ga.  |
| 225     | 532 40 33-19 | Keeper Belt Trans.             |
| 227     | 817 49 05-12 | Screw Thdrol 5/16-18 x 3/4     |
| 231     | 532 40 72-87 | Idler V-Groove                 |
| 284     | 532 41 76-93 | Nut U-CHNL 1/4-20              |
| 307     | 874 18 04-12 | Screw MACH CR 1/4-20 x 3/4     |
| 325     | 586 43 12-02 | Torque Strap K46 LT LH         |
| 326     | 586 00 11-02 | Bracket TRQ STP 46 20" Tire RH |
| 334     | 585 88 22-02 | Sway Bar Bracket               |
| 336     | 587 25 96-01 | Bolt 5/16-18 x 1-3/4 Flanged   |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



# TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87 ENGINE **24**


| KEY NO. | PART NO.     | DESCRIPTION                                                                                |
|---------|--------------|--------------------------------------------------------------------------------------------|
| 1       | — — — — —    | Engine Briggs Model No. 385777-0007-G1 (588627901) (Order parts from engine manufacturer.) |
| 2       | 589 81 87-01 | Muffler                                                                                    |
| 9       | 501 83 26-02 | Keeper Belt Engine                                                                         |
| 11      | 587 24 16-01 | Clutch Electric                                                                            |
| 12      | 532 40 50-97 | Pulley Engine                                                                              |
| 15      | 532 42 28-04 | Tank Fuel                                                                                  |
| 18      | 584 24 87-02 | Cap                                                                                        |
| 20      | 532 42 43-41 | Control Throttle                                                                           |
| 21      | 532 41 63-58 | Screw #10 x .750 BOS Thread                                                                |
| 22      | 532 18 95-41 | Control Choke                                                                              |
| 28      | 587 04 46-61 | Fuel Line                                                                                  |
| 29      | 532 13 71-80 | Spark Arrester Kit                                                                         |
| 37      | 532 12 34-87 | Clamp Hose                                                                                 |
| 41      | 532 12 61-97 | Washer 1-1/2 OD x 15/32 ID x .250                                                          |
| 42      | 810 04 07-00 | Washer Lock 7/16                                                                           |
| 45      | 873 51 04-00 | Nut Keps Hex 1/4-20 unc                                                                    |
| 62      | 532 43 40-17 | Heat Shield                                                                                |
| 69      | 532 19 24-42 | Gasket                                                                                     |
| 70      | 532 19 15-48 | Tube Exhaust LH                                                                            |
| 71      | 532 19 15-49 | Tube Exhaust RH                                                                            |
| 79      | 532 19 24-43 | Screw Socket HP 5/16-18 x 1                                                                |
| 81      | 532 14 84-56 | Tube Drain Oil                                                                             |
| 82      | 532 42 82-87 | Valve, Oil Drain                                                                           |
| 84      | 817 06 06-20 | Screw 3/8-16 x 1-1/4                                                                       |
| 85      | 501 60 66-01 | Bolt 7/16-20 x 3.75 Gr.                                                                    |
| 90      | 817 00 06-16 | Screw 3/8-16 x 1                                                                           |
| 91      | 532 18 74-95 | Bushing 1.375 OD                                                                           |
| 102     | 817 00 05-12 | Screw 5/16-18 x 3/4                                                                        |
| 116     | 539 13 26-24 | Knob-Shift                                                                                 |
| 117     | 532 42 08-28 | Valve Fuel Reserve                                                                         |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

## Engine Power Rating Information

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J1940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-05). Torque values are derived at 3060 RPM; horsepower values are derived at 3600 RPM. Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net power). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

## STEERING ASSEMBLY 41



steering-tex\_HUSQSR\_68

**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**STEERING ASSEMBLY 41**

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                         |
|------------|--------------|-------------------------------------|
| 1          | 532 43 97-40 | Wheel, Steering                     |
| 2          | 532 41 35-91 | Axle Asm., Front                    |
| 4          | 532 40 30-89 | Spindle Asm., LH                    |
| 5          | 532 40 30-90 | Spindle Asm., RH                    |
| 6          | 532 12 49-31 | Bearing, Race Thrust Harden         |
| 7          | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.       |
| 8          | 812 00 00-29 | Ring, Clip #T5304-75                |
| 9          | 532 12 12-32 | Cap, Spindle                        |
| 13         | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.       |
| 14         | 810 04 06-00 | Washer, Lock Hvy Hlcl Spr 3/8       |
| 15         | 873 54 06-00 | Nut, Crown Lock 3/8-24 unf          |
| 16         | 587 01 60-02 | Steering Shaft                      |
| 19         | 532 19 47-29 | Plate Steering                      |
| 21         | 586 84 02-01 | Adapter Wheel Steering              |
| 22         | 585 02 98-02 | Bearing                             |
| 26         | 532 43 97-43 | Insert, Wheel Steering              |
| 27         | 819 21 16-16 | Washer                              |
| 28         | 817 00 06-12 | Screw 3/8-16 x 3/4                  |
| 35         | 532 19 47-32 | Gear, Sector Plate                  |
| 45         | 587 01 64-01 | Washer 3/8 ID 2-3/8 OD 12 Ga. PLTD  |
| 50         | 873 90 06-00 | Nut Lock Flg 3/8-16 unc             |
| 53         | 532 18 89-67 | Washer Hardened .793 x 1.637 x .060 |
| 54         | 874 76 06-36 | Bolt Hex 3/8-16 unc x 2-1/4         |
| 55         | 532 41 47-36 | Spacer Brace Axle                   |
| 58         | 532 19 47-47 | Bolt Shoulder Sector Pivot CFM      |
| 59         | 532 19 47-48 | Washer Thrust Sector Steering       |
| 60         | 873 97 10-00 | Nut Flange Lock 5/8-11              |
| 61         | 588 79 44-01 | Draglink, LH                        |
| 62         | 588 79 45-01 | Draglink, RH                        |
| 63         | 817 00 05-12 | Screw 5/16-18 x 3/4                 |
| 64         | 532 19 98-49 | Retainer Clip Spring Steering       |
| 65         | 532 19 47-34 | Brace Axle Front                    |
| 66         | 871 02 07-48 | Bolt Hex Fghd 7/16-14 x 3 Serr      |
| 67         | 532 19 47-37 | Bushing PM Front Axle               |
| 68         | 873 90 07-00 | Nut Lock Flange 7/16-14 Gr. 5       |
| 69         | 532 19 91-62 | Washer 1.5 x .505 x .118            |
| 70         | 585 33 88-01 | Bracket Deck Susp. Front            |
| 75         | 580 68 37-01 | Pinion                              |
| 76         | 580 68 36-01 | Screw Head Sock                     |
| 78         | 532 05 70-79 | Washer Thrust                       |
| 118        | 532 40 60-13 | Bushing                             |
| 122        | 532 44 49-62 | Cap Gear                            |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm.

## 44




**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**MOWER DECK** **44**

| KEY NO. | PART NO.     | DESCRIPTION                    | KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|--------------------------------|---------|--------------|-------------------------------|
| 1       | 594 74 20-01 | Deck                           | 39      | 539 20 02-82 | Nut, 3/8-16 Hex Jam Nyloc     |
| 2       | 539 11 21-70 | Housing Assembly               | 40      | 532 17 60-66 | Roller, Nose                  |
| 3       | 532 18 76-90 | Washer-Spacer                  | 41      | 532 17 91-27 | Rod, Roller, Nose, Narrow     |
| 4       | 532 17 43-75 | Pulley, Mandrel                | 43      | 819 12 14-14 | Washer, 3/8 x 7/8 x 14 Ga     |
| 5       | 532 40 02-34 | Nut, Flange Lock Top           | 44      | 575 96 72-05 | Shield, Belt RH               |
| 7       | 539 11 07-32 | Discharge Chute                | 45      | 874 78 05-16 | Bolt Fin Hx 5/16-18 x 1       |
| 8       | 539 11 07-35 | Spring - Torsion               | 46      | 810 03 05-00 | Wash 5/16 Slw                 |
| 9       | 539 11 07-36 | Pin, Clevis 5/16 x 5.19        | 49      | 584 95 39-01 | Bolt Hex                      |
| 10      | 539 11 34-25 | Blade, 16-1/4"                 | 50      | 532 41 55-98 | Washout Port                  |
| 11      | 532 19 30-03 | Bolt, Washer Asm 7/16-20       | 51      | 817 49 04-08 | Bolt, 1/4-20 x 1/2            |
| 12      | 539 11 34-26 | Confinement Plate              | 52      | 874 78 07-40 | Hcs 7/16-14 x 2-1/2 Gr 5      |
| 13      | 872 11 05-05 | Bolt Carr. 5/16-18 x 5/8 Short | 53      | 574 84 56-02 | Belt, Deck                    |
| 14      | 873 80 05-00 | Nut 5/16-18 Hex Nyloc          | 54      | 532 14 10-43 | Guard, Belt                   |
| 15      | 532 19 51-61 | Stud, Fasten w/ Anti- Rotate   | 55      | 539 11 55-74 | Eyebolt 5/16 x 3-1/2          |
| 17      | 532 19 61-04 | Pulley, Idler Spec. Hub        | 56      | 539 99 05-85 | Nut 5/16-18 Hex Whizlock      |
| 18      | 574 82 71-02 | Arm, Idler, Blk                | 57      | 539 10 68-50 | Spring                        |
| 19      | 532 17 79-68 | Pulley, Idler                  | 58      | 532 11 04-85 | Ball Bearing                  |
| 20      | 539 13 27-28 | Pulley, Idler                  | 59      | 575 35 29-01 | Pulley                        |
| 21      | 575 22 45-01 | Idler Bushing                  | 60      | 532 16 94-84 | Clip Retainer                 |
| 22      | 532 13 39-57 | Wheel, Gauge                   | 61      | 532 40 48-51 | Rod Anti Sway                 |
| 23      | 532 19 34-06 | Bolt, Shoulder 3/8 16 x 3-5/8  | 62      | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga. |
| 24      | 521 99 65-01 | Nut 3/8-16 Hex Flg Nyloc       | 63      | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock  |
| 25      | 575 22 47-06 | Shield, Belt LH                | 65      | 580 94 16-04 | Baffle Front RH               |
| 27      | 539 10 47-63 | Retainer 5/16c U Type          | 66      | 584 65 15-04 | Baffle Front LH               |
| 28      | 539 10 82-71 | Hcs 3/8-16 x 3-1/2 Gr 5        | --      | 594 74 20-01 | Mower Deck Complete           |
| 29      | 539 10 65-04 | Heavy Washer                   |         |              |                               |
| 30      | 819 14 16-14 | Washer, 3/8 Flat Std           |         |              |                               |
| 31      | 539 97 69-79 | Nut 3/8-16 Hex Nyloc           |         |              |                               |
| 32      | 539 99 09-23 | Rhsnb 3/8-16 x 1-3/4 Gr 5      |         |              |                               |
| 33      | 539 10 48-64 | Washer, 7/16 Flat              |         |              |                               |
| 34      | 532 17 85-15 | Washer, Flat Hardened          |         |              |                               |
| 35      | 873 90 07-00 | Nut, 7/16-14 Hex               |         |              |                               |
| 36      | 532 19 51-85 | Arm, Susp., Rear               |         |              |                               |
| 37      | 539 11 36-21 | Sb 3/8-16 x 3/8 Skt Hd         |         |              |                               |
| 38      | 819 13 13-16 | Washer, 13/32 x 13/16 x 16 Ga  |         |              |                               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**MOWER LIFT 45**




lift-tex\_24

| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 2       | 532 42 20-27 | Shaft Asm., Lift             |
| 3       | 532 19 52-30 | Lever Asm., Lift RH          |
| 7       | 580 96 23-01 | Grip, Lever                  |
| 10      | 532 19 63-14 | Spring Torsion               |
| 41      | 532 17 59-94 | Nut, Lift Link               |
| 87      | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock |
| 88      | 532 41 07-10 | Spring Lift Assist           |
| 89      | 819 19 19-12 | Washer Clear Zinc            |

| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 91      | 532 40 34-07 | Link Lift Susp Mower Rear   |
| 96      | 532 19 52-63 | Bushing, Spherical          |
| 97      | 817 00 06-12 | Screw 3/8-16 x .75          |
| 98      | 574 82 25-01 | Link Lift Susp. Front Mower |
| 114     | 873 36 07-00 | Nut Jam 7/16-20             |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

**TRACTOR - - MODEL NO. TS 348 (96041038700), PRODUCT NO. 960 41 03-87**  
**SEAT ASSEMBLY 42**



seat-tex\_6.5SL\_10\_r1

| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 1       | 532 44 32-63 | Seat                          |
| 2       | 532 18 01-66 | Bracket Pivot Fender          |
| 6       | 873 80 06-00 | Nut, Lock W/Ins. 3/8-16 unc   |
| 7       | 587 61 33-01 | Spring, Seat Cprsn            |
| 8       | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems |
| 10      | 532 19 69-77 | Pan, Seat                     |
| 21      | 587 90 78-01 | Bolt, Shoulder 5/16-18 x 5/8  |
| 37      | 873 80 05-00 | Nut, Lock 5/16-18 unc         |

| KEY NO. | PART NO.     | DESCRIPTION                      |
|---------|--------------|----------------------------------|
| 40      | 532 43 98-71 | Handle Slide Seat                |
| 41      | 532 19 82-00 | Spring Latch Seat                |
| 43      | 874 76 06-12 | Bolt Fin Hex 3/8-16 unc x 3/4    |
| 44      | 819 13 38-12 | Washer 13/32 x 2-3/8 x 12 Ga.    |
| 46      | 588 09 04-01 | Bolt 3/8-16x1, 1.25 OD Wshr Sems |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

