

YT130

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

GPL®

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

ELECTRICAL

REPAIR PARTS


TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

ELECTRICAL

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

ELECTRICAL



REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

ELECTRICAL


KEY NO.	PART NO.	DESCRIPTION
1	532144925	Battery 12 Volt 25 AMP
2	874760412	Bolt Hex Hd 1/4-20unc X 3/4
8	532156417	Case Battery Mech Hinge
16	532153664	Switch Interlock Push-In
21	532166181	Harness Asm Light W/4152j
22	532004152	Bulb Light #1156
24	532124780	Cable Battery 6 Ga 11" red
25	532146147	Cable Battery 6 Ga 44" red w/16 wire
26	532166180	Fuse 30 AMP Auto Green
27	873510400	Nut Keps Hex 1/4-20 Unc
28	532124773	Cable Ground 6 Ga 12" black
29	532121305	Switch Plunger Nc Gray
30	532163968	Switch Ign
33	532140401	Key Ign Molded Generic
40	532170217	Harness Ign.
41	871110408	Bolt Blk Fin Hex 1/4 - 20 x 1/2
42	532131563	Cover Terminal Red
43	532145673	Solenoid
48	532140844	Adapter Ammeter Rectangular®
52	532141940	Protection Wire Loop
70	532170242	Harness, Eng.

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

CHASSIS AND ENCLOSURES



REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

CHASSIS AND ENCLOSURES


KEY NO.	PART NO.	DESCRIPTION
1	532169830	Chassis Stamping
2	532169061	Drawbar
3	817060612	Screw 3/8-16x3/4
5	532155272	Bumper Hood/Dash
9	532171853	Dash P/L
10	872140608	Bolt Carriage 3/8-16 x 1
11	532155927	Panel Dash Lh
13	532169195	Panel Dash Rh
17	532165378	Hood LT/PL Husqvarna
18	532126938	Bumper Hood
20	532156437	Plate Mtg Battery Fuel Tank Fr
23	532124028	Bushing
25	819131312	Washer 13/32 X 13/16 X 12 Ga
26	873800600	Nut Lock Hex W/Ins 3/8-16 Unc
28	532165379	Grille LT/PL Husqvarna
29	532165380	Lens LT/PL Husqvarna
30	532171854	Fender Footrest STLT Pnt
31	532139976	Bracket Support Fender
37	817490508	Screw Thdrol 6/16-18 x 1/2 TYT
38	532169834	Bracket, Asm. Pivot, Mower Rear
51	873800400	Nut Lock Hex W/Ins 1/4-20
52	819091416	Washer 9/32 x 7/8 x 16 Ga.
53	532150067	Bracket Pnt. Pick off LT/PL Husqvarna
57	874780412	Bolt Hex 1/4-20 x 3/4
58	532150127	Air Duct Engine P/L
60	872140606	Bolt Rdhd Sqnk 3/8-16unc x 3/4
64	532154798	Dash Lower STLT
68	873510400	Nut keps Hex 1/4-20 unc
71	873680400	Nut Crownlock 1/4-20unc
74	873680600	Nut Crownlock 3/8-16 UNC
129	819091016	Washer 9/32 x 5/8 x 16 Ga.
134	532160219	Rod Support Hood LT/PL Husq.
142	532165867	Plate Reinforcement STLT
143	532154966	Bracket Swaybar Chassis
144	532154207	Bracket Pnt Footrest STLT
145	532156524	Rod Pivot Chassis/Hood
206	532170165	Bolt Shoulder 5/16-18 TT
208	817670608	Screw Thdrol 3/8-16 x 1/2
--	532005479	Plug Button

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

DRIVE



REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

DRIVE


KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1 - - - - -	Transaxle (Order Parts From Engine Manufacturer) Peerless 206-545C	59 532169595	Keeper Belt Span Ctr
2 532146682	Spring Return Brake T/a Zinc	61 817060612	Screw 3/8-16x3/4
3 532123666	Pulley Transaxle 18" tires	62 532123533	Cover Pedal Deluxe
4 812000028	Ring Retainer #5100-62	63 532140186	Engine Pulley LT/YT
5 532121520	Strap Torque 30 Degrees	64 871170764	Bolt Hex
6 817060512	Screw Thdrol 5/16-18 X 3/4 TYT	65 810040700	Washer Lock Hvy Hlcl Spr 7/16
8 532165866	Rod Shift Fender Adjust STLT	66 532154778	Keeper Belt Engine Foolproof
10 876020416	Pin Cotter 1/8 X 1 Cad	70 532134683	Guide Belt Mower Drive RH
11 532105701	Washer Plate Shf 388 Sq Hole	72 819132012	Washer 13/32 X 1-1/4 X 12 Ga
13 874550412	Bolt 1/4-28 Unf Gr 8 W/Patch	74 532137057	Spacer Axle
14 810040400	Washer Lock Hvy Helical 1/4	75 532121749	Washer 25/32 X 1 1/4 X 16 Ga
16 873800500	Nut Lock Hx W/Ins 5/16-18 Unc Pl	76 812000001	E-ring #5133-75
18 874780616	Bolt, Fin Hex 3/8-16 UNC x 1 Gr. 5	77 532123583	Key Square 2 0 X 1845/ 1865
19 873800600	Nut Lock 3/8-16 Unc	78 532121748	Washer 25/32 X 1-5/8 X 16 Ga
21 532121274	Knob	79 532125096	Key Woodruff #9 3/16 x 3/4
22 532130804	Rod Brake Blk Zinc 26 840	80 532131486	Arm Shift
24 873350600	Nut Hex Jam 3/8-16 Unc	81 532165594	Shaft Asm Cross Tapered DA/PR 18"
25 532106888	Spring Rod Brake 2 00 Zinc	82 532165711	Spring Torsion T/a
26 819131316	Washer 13/32 X 13/16 X 16 Ga	83 819171216	Washer 17/32 X 3/4 X 16 Ga
27 876020412	Pin Cotter 1/8 X 3/4 Cad	84 532166228	Transaxle Link
28 532145204	Rod Brake Parking LT/YT	85 532150360	Nut Lock Center 1/4 - 28 FNTHD
29 532071673	Cap Brake Parking Black	89 532166561	Console Shift STLT
30 532130807	Bracket Mtg Transaxle	90 532124346	Nut Self-thd Wsh-hd 1/4 Zinc
31 532127275	Keeper Belt LH LT 14 Ga	96 532124788	Retainer Spring 1"
32 874760512	Bolt Hex Hd 5/16-18unc X 3/4	112 819091210	Washer 9/32 x 3/4 x 10 Ga.
34 532155071	Shaft Asm Pedal Foot	113 532127285	Strap Torque LT
35 532120183	Bearing Nylon Blk 629 Id	116 872110610	Bolt Rdhd Sq Neck 3/8-16 x 1.25
36 819211616	Washer 21/32 X 1 X 16 Ga	145 874490540	Bolt Hex Flg Hd 5/16-18 Gr 5
37 532124963	Pin Roll 3/16 X 1"	150 532165850	Bushing Bellcrank
38 532131494	Pulley Idler Flat	151 819133210	Washer 13/32 x 2 x 10 Ga.
39 872110622	Bolt Rdhd 3/8-16unc X 2-3/4 Gr 5	156 532166002	Washer Srrtd 5/16ID x 1.125
40 532124965	Spacer Split 395 X 59 Bzp	158 532165589	Bracket Shift Mount
41 532165838	Keeper Belt Idler Flat	159 532165494	Hub Tapered Flange Shift Lt
42 819131312	Washer 13/32 X 13/16 X 12 Ga	161 872140406	Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5
47 532127783	Pulley Idler V Groove Plastic	162 873680400	Nut Crownlock 1/4-20 Unc
48 532154407	Bellcrank Clutch Grnd Drv Stl	163 874780416	Bolt Hex Fin 1/4-20 Unc x 1 Gr 5
49 532123205	Retainer Belt Style Spring	164 819091010	Washer 5/8 x .281 x 10 Ga
50 874760624	Bolt Hex Hd 3/8-16unc X 1-1/2	165 532165623	Bracket Pivot Lever
51 873680600	Nut Crownlock 3/8-16 Unc	166 532166880	Screw 5/16-18 x 5/8
52 873680500	Nut Crownlock 5/16-18 Unc	168 532165492	Bolt Shoulder 5/16-18 x .561
53 532105710	Link Clutch	169 532165580	Plate Fastening STLT/CRD
55 532105709	Spring Return Clutch 6 75	197 532169613	Nyliner Snap-In 5/8" ID
56 874760620	Bolt Fin Hx 3/8-16 X 1/4	198 532169593	Washer Nyl 7/8 Id x .105" Hyd
57 531006043	V-Belt Ground Drive 95 25	202 872110612	Bolt Carr Sh 3/8-16 x 1-1/2 Gr 5
58 532127274	Keeper Belt RH LT Pnt/zinc 16g		

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

STEERING ASSEMBLY



REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

STEERING ASSEMBLY


KEY NO.	PART NO.	DESCRIPTION
1	532166627	Wheel Steering
2	532154427	Axle Asm STMP Dropped STL
3	532169840	Spindle Asm LH
4	532169839	Spindle Asm RH
5	532124931	Bearing Race Thrust Harden
6	532121748	Washer 25/32 X 1-5/8 X 16 Ga
7	819272016	Washer 27/32 X 1-1/4 X 16 Ga
8	812000029	Ring Klip #t5304-75
9	532124937	Bearing Col Strg Blk
10	532169832	Link Drag
11	810040600	Washer Lock Hvy Hlcl Spr 3/8
13	532136518	Spacer Brg Axle Front
15	532145212	Nut Hex Flange Lock
17	532156546	Shaft Asm Strg
18	532057079	Washer Thrust 515x 750x 033
19	532160395	Support Shaft
22	532165857	Screw Hex
23	532165851	Shaft Asm Pittman
25	532154406	Bracket Steering
26	532126847	Bushing Link Drag Blk LR
27	532136874	Gear Sector
28	819131416	Washer 13/32 X 7/8 X 16 Ga
29	817060612	Screw 3/8-16x3/4
30	876020412	Pin Cotter 1/8 X 3/4 Cad
32	532130465	Rod Tie Wire Form 19 75 Mech
36	532155099	Bushing Strg
37	532152927	Screw
38	532166626	Insert Cap Strg Wh
39	819132411	Washer 13/32 X 1-1/20 x 11 Ga
40	532124701	Lock nut
41	532159945	Adaptor Wheel Strg
42	532169634	Boot Steering Shaft
43	532121749	Washer 25/32 X 1 1/4 X 16 Ga
44	532153720	Extension Steering Shaft LR/LT
46	532121232	Cap Spindle Fr Top Blk
47	532124836	Fitting Grease
51	873800500	Nut Lock Hex w/Ins 5/16-18
54	874780520	Bolt Fin Hex 5/16-18 Unc x 1-1/4
62	532167902	Kit, Steering Assembly Svc
63	874780616	Bolt Fin Hex 3/8-16unc x 1 Gr. 5
65	532160367	Spacer Brace Axle
66	532154404	Bearing Arm Pittman
67	872110618	Bolt, Rdhd Sqnk 3/8-16 x 2-1/4
68	532169827	Axle, Brace
79	819132012	Washer 13/32 x 1-1/4 x 12 Ga
80	874950612	Bolt Hex Nylon 3/8-16 x 3/4
82	532169635	Bracket Susp Chassis Front
85	532133835	Fastener Christmas Tree

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

ENGINE



REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

ENGINE


KEY NO.	PART NO.	DESCRIPTION
1	532141359	Control Th/ch 20.22 LH Flag
2	817720410	Screw Hex Thd Cut 1/4-20x5/8 T
3	-----	Engine B&S Model No. 28R707 (Order Parts From Engine Manufacturer)
4	532137348	Muffler LT B&S 12/12.5/13HP
13	532165291	Gasket Eng 1 313 Id Tin Plated
14	813280324	Nipple Pipe 3/8 Npt X 3"
15	813200300	Elbow Std 90 Degree 3/8-18 Npt
16	811050600	Washer Lock Ext Tooth 3/8
23	532169837	Shield Brn/Dbr Guard
29	532137180	Kit Spark Arrestor (Flat Scrn)
31	532161911	Tank Fuel Front 2 00
32	532140527	Cap Asm Fuel W/sym Vented
33	532123487	Clamp Hose Black
37	532137040	Line Fuel 20"
38	-----	Plug Oil Drain (Order From Engine Manufacturer)
40	532124028	Bushing Snap Nyl Blk Fuel Line
44	817490412	Screw Hexwsh Thdrol 1/4-20x3/4
45	817060612	Screw 3/8-16 x 3/4 Smgml Tap/R
46	819091416	Washer 9/32 X 7/8 X 16 Ga
62	810040500	Washer Lock Hvy Hlcl Spr 5/16
66	532127951	Stop Throttle 3000 RPM
72	871070510	Screw Hexhd Cap 5/16-18x 5/8
78	817060620	Screw 3/8-16x1-1/4
81	532128861	Nut Flange 1/4-20 Starter Nut

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

SEAT ASSEMBLY



KEY PART NO. NO.

DESCRIPTION

1	532140839	Seat
2	532140551	Bracket Pivot Seat 8 720
3	874760616	Bolt Fin Hex 3/8-16unc X 1
4	819131610	Washer 13/32 X 1 X 10 Ga
5	532145006	Clip Push-In
6	873800600	Nut Hex w/Ins. 3/8-16 Unc
7	532124181	Spring Seat Cprsn 2 250 Blk Zi
8	817060616	Screw 3/8-16 X 1-1/2
9	819131614	Washer 13/32 X 1 X 14 Ga.
10	532155925	Pan Seat
11	532166369	Knob Seat
12	532121246	Bracket Mounting Switch

KEY PART NO. NO.

DESCRIPTION


13	532121248	Bushing Snap Blk Nyl 50 Id
14	872050412	Bolt Rdhd Sqnk 1/4-20x1-1/2
15	532134300	Spacer Split 28x 96 Yel Zinc
16	532121250	Spring Cprsn 1 27 Blk Pnt
17	532123976	Nut Lock 1/4 Lge Flg Gr 5 Zinc
21	532153236	Bolt Shoulder 5/16-18 Unc
22	873800500	Nut Hex Lock W/Ins 5/16-18
24	819171612	Washer 17/32 X 1 X 12 Ga.
25	532127018	Bolt Shoulder 5/16-18 X 62

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 954 17 00-27

DECALS




KEY NO.	PART NO.	DESCRIPTION
1	532126187	Decal 100 DBA
2	532140837	Decal Saddle Brake Parking
3	532151320	Decal Hood RH
4	532151321	Decal Hood LH
5	532170848	Decal HP Engine
6	532145437	Decal Europe Stand CE
7	532159713	Decal Pnl Side
8	532145494	Decal Mower Cutfinger
9	532150617	Decal Fender Husq
10	532145498	Decal Read Owner's Manual Syms.
11	532159736	Decal Chassis Hot Muffler
12	532159737	Decal Brake/ Clutch Symbol Lt

KEY NO.	PART NO.	DESCRIPTION
13	532170564	Decal Steering Wheel
14	532160396	Decal V-Belt Schematic
20	532145005	Decal Bat Dan/Psn
--	532171284	Pad Footrest LH STLT
--	532162598	Decal Drawbar
--	532171285	Pad Footrest RH STLT
--	532138311	Decal Handle Lift Height Adjust
--	532171784	Manual Operator's (Euro.)
--	532171785	Manual Operator's (Scan.)

Available accessories not included with tractor:

--	CE42	Grass Catcher
--	Mk420	Mulch Kit w/Blades

WHEELS & TIRES




KEY NO.	PART NO.	DESCRIPTION
1	532059192	Cap Valve Tire
2	532065139	Stem Valve
3	532106222	Tire F Ts 15 X 6 0 - 6 Service
4	532059904	Tube Front (Service Item Only)
5	532138336	Rim Asm 6"front Silver Service
6	532124957	Fitting Grease (Front Wheel Only)
7	532124959	Bearing Flange (Front Wheel Only)
8	532138337	Rim Asm 8"rear Silver Service
9	532106268	Tire R Ts 18x9 5-8 C Service
10	532124926	Tube Rear (Service Item Only)
11	532104757	Cap Axle Blk 1 50 X 1 00
--	532144334	Sealant, Tire (10 oz. Tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

MOWER DECK



REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

MOWER DECK


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532165892	Deck Asm MWR 42"weldment	59	532141043	Guard TUV Idler
2	872140506	Bolt Rdhd Sqnk 5/16-18unc X3/4	67	532106932	Knob Rd 3/8-16 Plstc Thds Blk
3	532138017	Bracket Asm Fr Sway Bar 38/42	68	531007562	V-Belt Mower 42"
4	532165460	Bracket Asm Deck 42"sway Bar	90	874760616	Bolt Fin Hex 3/8-16 UNC x 1
5	532124670	Retainer Spring	91	532132274	Bracket Asm Noseroller LH
6	532130832	Arm Suspension Rear	92	873800600	Nut Lock Hex W/Ins 3/8-16 Unc
8	532850857	Bolt 3/8 - 24 X 1.25 Gr 8	93	819171416	Washer 17/32 x 7/8 x 16 Ga.
9	810030600	Washer Lock Hvy 3/8	94	532132264	Roller Nose 38 & 42
10	532140296	Washer Hard Blade Mower Vented	95	532132273	Bracket Asm Noseroller RH
11	531005085	Blade Mower High Perf 42"	111	532155197	Bracket Wheel Gauge LH 42" Deck
12	532129895	Bearing Ball #6024 (Mandrel)	112	532155198	Bracket Gauge Wheel RH 42" Deck
13	532137645	Shaft Asm W/lower Bearing	113	817060512	Screw 5/16-18 X 3/4
14	532128774	Housing Mandrel Vented	114	873510500	Nut Keps 5/16-18 UNC
15	532110485	Bearing Ball Mandrel	115	872110504	Bolt Carriage 5/16-UNC x 1/2
16	532140329	Stripper Mower Vented	116	532124842	Bolt Shoulder
18	872140505	Bolt Rdhd Sqnk 5/16-18 X 5/8	117	532165746	Wheel Gauge
19	532132827	Bolt Shoulder	118	873930600	Nut Centerlock 3/8-16 UNC
20	532159770	Baffle Vortex 42	119	819121414	Washer 3/8 x 7/8 x 14 Ga.
21	873680500	Nut Crownlock 5/16-18 UNC	121	532143723	Bracket Extruded Gauge Wheel
22	532134753	Stiffener Bracket 42"deck	128	532153390	Washer Felt
23	532131267	Bracket Deflector Mower 42"	129	819131312	Washer 13/32 x 13/16 x 12 Ga.
24	532105304	Cap Sleeve 80x 112 Blk Mower	130	874780616	Bolt Fin Hex 3/8-16 UNC x 1 Gr. 5
25	532123713	Spring Torsion Deflector 2 52	131	872140608	Bolt Rdhd Sqnk 3/8-16 x 1
26	532110452	Nut Push Phos & Oil	142	532165890	Arm Spring Brake Mower
27	532171859	Shield Deflector Mower 42" Blk	143	532157109	Bracket Arm Idler 42"
28	819111016	Washer 11/32 X 5/8 X 16 Ga	144	532158634	Keeper Belt 42" Clutch Cable
29	532131491	Rod Hinge 42"6 75 Wlg	145	532165888	Pulley Idler Flat
30	532157722	Screw Thd Rolling Washer Head	146	532165891	Bolt Carriage Idler
31	532129963	Washer Spacer Mower Vented	147	532131335	Spring Extension
32	532153535	Pulley Mandrel 42"	148	532169022	Spring Return Idler
33	532137266	Nut 9/16 Toplock Flng Oil Dip	149	532169898	Retainer Spring Yellow
34	872110614	Bolt Rdhd 3/8-16uncx1-3/4 Gr5	150	819091216	Washer 9/32 x 3/4 x 16 Ga.
35	532133835	Fastner Christmas Tree	151	532169670	Bracket Clutch Cable
36	532131494	Pulley Idler Flat 3 060	152	532169676	Clutch Cable 42"
37	819131316	Washer 13/32 X 13/16 X 16	153	532169674	Washer Flat 3/8" Type B
40	873680600	Nut Crownlock 3/8-16 UNC	154	532169675	Spring Retainer
44	532140088	Guard Mandrel LH Black	155	532169671	Spring Retention Lvr Cltch Cab
45	532124788	Spring Retainer 1" Zinc/cad	156	532169672	Spacer Clutch Cable
46	532137729	Screw Hex Thd Cut 1/4-20x5/8 T	157	532169669	Rod Clutch Cable 3/8"
48	532133944	Washer Hardened Smaller	158	817720410	Screw Hex Thd Cut 1/4-20 x 5/8
49	532155066	Roller Asm Cam Follower 42"dec	159	872140614	Bolt Rdhd Sqn 3/8-16 Unc x 1-3/4
50	532131340	Bolt Shldr 10-24 Zinc Gr 5 42"	--	532130794	Mandrel Asm Service (Includes Key
51	532069180	Nut Lock #10-24 Unc			Nos. 8-10, 12-15, 31 and 33)
52	532139888	Bolt Shoulder 5/16-18 Unc Blkz	--	532171491	Deck Serv 42" (Standard Deck -
53	532131845	Arm Asm Pad Brake			Order noseroller, mulch cover and
54	532133943	Washer Hardened			gauge wheel components separately
55	532155046	Arm Idler 42"mower LT/YT			Key Nos. 90-95, and 111-120)
56	532165723	Spacer Retainer Mower			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

MOWER LIFT



REPAIR PARTS

TRACTOR - MODEL NO. YT130 (HEYT130J), PRODUCT NO. 95417 00-27

MOWER LIFT

KEY NO.	PART NO.	DESCRIPTION
1	532159460	Wire Asm Inner/Spring W/plunger
2	532159471	Shaft Asm Lift
3	532105767	Pin Groove
4	812000002	E Ring #5133-62
5	819211621	Washer PLTD 21/32 X 1 X 21ga
6	532120183	Bearing Nylon Blk 629 Id
7	532125631	Grip Handle Fluted
8	532124526	Button Plunger Black
11	532139865	Link Lift LH
12	532139866	Link Lift RH
13	532124670	Retainer Spring
15	532167253	Link Front
16	873350800	Nut Jam Hex 1/2-13 Unc
17	532130171	Trunnion Blk Zinc
18	873800800	Nut Lock W/wsh 1/2-13unc
19	532139868	Arm Suspension Rear
20	532163552	Spring, Retainer
31	532140302	Bearing Pvt. Lift Spherical
32	873540600	Nut Crownlock 3/8-24

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm