

# YTH210 XP

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**


**GPL**®

# ILLUSTRATED PARTS LIST

**MFG. ID NO. 96011012100**


**CUSTOMER CATALOG NO. YTH210 XP**

**PRODUCT NO. 960 11 01-21**



# REPAIR PARTS


TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
DECAL



| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 1       | 532 18 89-21 | Decal, Pnl Side               |
| 2       | 532 14 08-37 | Decal, Brake Parking Sandle   |
| 3       | 532 18 89-22 | Decal, Hood                   |
| 4       | 532 18 91-44 | Decal, Rpl. Int.              |
| 5       | 532 16 03-96 | Decal, V-Belt Sch.            |
| 6       | 532 15 97-36 | Decal, Chassis Hot Muffler    |
| 7       | 532 18 21-66 | Decal, Mower Cutfinger Symbol |
| 8       | 532 18 89-36 | Decal, Logo, Fender           |
| 9       | 532 18 04-32 | Decal, Fender 100 DB/CE       |
| 10      | 532 40 03-89 | Decal, Warning Symbols CE     |
| 11      | 532 14 50-05 | Decal, Bat Dan/Poi P/L Sym    |
| 12      | 532 17 83-02 | Decal, Oper. Cruise Symbols   |
| 13      | 532 19 11-54 | Decal, Sidepnl                |

| KEY NO. | PART NO.     | DESCRIPTION                                     |
|---------|--------------|-------------------------------------------------|
| 14      | 532 18 89-25 | Decal, Wheel Steering                           |
| 15      | 532 15 97-37 | Decal, Brake/Clutch Symbol                      |
| 16      | 532 17 91-28 | Decal, Deck "B"                                 |
| 17      | 532 19 63-57 | Decal, Cutfinger Warning                        |
| 18      | 532 40 11-46 | Decal, Warning Service/Fire                     |
| --      | 532 16 25-98 | Decal Drawbar Load Limit                        |
| --      | 532 16 69-60 | Decal By Pass Lt Hydro                          |
| --      | 532 13 83-11 | Decal, Handle Lift Height Adjust. (Lift Handle) |
| --      | 532 18 14-95 | Pad, Footrest LH                                |
| --      | 532 18 14-96 | Pad, Footrest RH                                |
| --      | 532 40 08-35 | Manual, Operator's (Euro)                       |

## WHEELS & TIRES




| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                    |
| 2       | 532 06 51-39 | Stem Valve                        |
| 3       | 532 10 62-22 | Tire F Ts 15 x 6 0 - 6 Service    |
| 4       | 532 05 99-04 | Tube Front (Service Item Only)    |
| 5       | 532 13 83-36 | Rim Asm 6" front Silver Service   |
| 6       | 532 12 49-57 | Fitting Grease (Front Wheel Only) |
| 7       | 532 12 49-59 | Bearing Flange (Front Wheel Only) |
| 8       | 532 13 83-37 | Rim Asm 8" Rear Silver Service    |
| 9       | 532 12 20-82 | Tire R Ts 20 x 10-8 C Service     |
| 10      | 532 12 49-26 | Tube Rear (Service Item Only)     |
| 11      | 532 17 50-39 | Cap Axle Blk 1 50 x 1 00          |
| --      | 532 14 43-34 | Sealant, Tire (10 oz. tube)       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
SCHEMATIC


03110\_197429



03110

# REPAIR PARTS

TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO.960 11 01-21  
ELECTRICAL



# REPAIR PARTS


TRACTOR-MODEL NO. YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
ELECTRICAL

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                           |
|------------|--------------|---------------------------------------|
| 1          | 532 14 49-27 | Battery                               |
| 2          | 874 76 04-12 | Bolt Hex Hd 1/4-20 unc x 3/4          |
| 8          | 532 18 64-91 | Box Battery                           |
| 16         | 532 17 61-38 | Switch Interlock                      |
| 21         | 532 17 56-88 | Harness Asm Light W/4152J             |
| 22         | 532 00 41-52 | Bulb Light #1156                      |
| 24         | 532 12 47-80 | Cable Battery 6 Ga. 11" red           |
| 25         | 532 14 61-48 | Cable Battery 6 Ga. W/16 Ga. Wire 22" |
| 26         | 532 17 51-58 | Fuse 20 AMP                           |
| 27         | 873 51 04-00 | Nut Keps hex 1/4-20 Unc               |
| 28         | 532 14 54-91 | Cable Ground 6 Ga. 21" Black          |
| 29         | 532 19 27-49 | Switch Seat                           |
| 30         | 532 19 33-50 | Switch Ignition                       |
| 33         | 532 14 04-01 | Key Ign Molded Generic                |
| 34         | 532 11 07-12 | Switch Light                          |
| 40         | 532 19 74-29 | Harness Ign.                          |
| 41         | 871 11 04-08 | Bolt Hex Hd. Fin 1/4-20 x 1/2 Gr. 5   |
| 42         | 532 13 15-63 | Cover Terminal Red                    |
| 43         | 532 19 25-07 | Solenoid                              |
| 46         | 532 19 81-38 | Hourmeter                             |
| 48         | 532 14 08-44 | Adapter Ammeter Rectangular           |
| 50         | 532 17 46-51 | Switch PTO                            |
| 51         | 532 14 04-05 | Ring Retainer PTO                     |
| 90         | 532 18 04-49 | Cover Terminal Battery                |
| 91         | 532 19 02-70 | Strap Battery Mount Front             |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
ENCLOSURES



# REPAIR PARTS


TRACTOR-MODEL NO. YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
ENCLOSURES

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                                             |
|------------|--------------|---------------------------------------------------------|
| 1          | 532 17 46-19 | Chassis Stl Stamping                                    |
| 2          | 532 17 65-54 | Drawbar                                                 |
| 5          | 532 15 52-72 | Bumper Hood/Dash                                        |
| 9          | 532 40 28-22 | Dash                                                    |
| 10         | 872 14 06-08 | Bolt Carriage 3/8-16 x 1                                |
| 11         | 532 17 49-96 | Panel Dash Lh                                           |
| 14         | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2                               |
| 13         | 532 17 21-06 | Panel Dash Rh                                           |
| 17         | 532 18 88-93 | Hood LT/PL Husqvarna                                    |
| 18         | 532 18 49-21 | Bumper Hood                                             |
| 26         | 873 80 06-00 | Nut Lock Hex W/Ins 3/8-16 unc                           |
| 28         | 532 18 35-38 | Grille LT/PL Husqvarna (Includes Key Nos. 212, 258-261) |
| 30         | 532 19 48-06 | Fender Footrest STLT Pnt                                |
| 31         | 532 13 99-76 | Bracket Support Fender                                  |
| 37         | 817 49 05-08 | Screw Thdrol 6/16-18 x 1/2 TYT                          |
| 38         | 532 17 57-10 | Bracket Asm. Pivot Mower Rear                           |
| 39         | 532 17 47-14 | Bracket Pivot Laser                                     |
| 58         | 532 18 45-38 | Duct Intake Air                                         |
| 60         | 872 14 06-06 | Bolt Rdhd Sqnk 3/8-16 unc x 3/4                         |
| 64         | 532 15 47-98 | Dash Lower STLT                                         |
| 74         | 873 68 06-00 | Nut Crownlock 3/8-16 unc                                |
| 90         | 532 12 43-46 | Nut Self-Thd Wsh-Hd 1/4                                 |
| 142        | 532 17 57-02 | Plate Reinforcement STLT                                |
| 143        | 532 18 66-89 | Bracket Swaybar Chassis                                 |
| 144        | 532 17 55-82 | Bracket Footrest STLT                                   |
| 145        | 532 15 65-24 | Rod Pivot Chassis/Hood                                  |
| 159        | 532 19 24-04 | Cupholder                                               |
| 206        | 532 17 01-65 | Bolt Shoulder 5/16-18 TT                                |
| 207        | 817 67 05-08 | Screw Thdrol 5/16-18 x 1/2 TYTT                         |
| 208        | 817 67 06-08 | Screw Thdrol 3/8-16 x 1/2 TYT BL                        |
| 209        | 817 00 06-12 | Screw Hexwsh Thdr 3/8-16 x 3/4                          |
| 212        | 532 18 35-48 | Insert Lens Reflective                                  |
| 217        | 532 18 54-36 | Console Fuel Window                                     |
| 258        | 532 18 52-13 | Lens Husq. Laser LT Clear RH                            |
| 259        | 532 18 52-14 | Lens Husq. Laser LT Clear LH                            |
| 260        | 532 18 52-16 | Cover Lens Husq. Laser LT                               |
| 261        | 532 18 52-12 | Insert Grille                                           |
| 272        | 532 18 88-96 | Vent Hood RH                                            |
| 273        | 532 18 88-95 | Vent Hood LH                                            |
| 278        | 532 19 16-11 | Screw 10 x 3/4 Single Lead-Hex                          |

**NOTE:** All component dimensions given in U. S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO.960 11 01-21  
DRIVE



# REPAIR PARTS

**TRACTOR-MODEL NO. YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
DRIVE**


| KEY NO. | PART NO.     | DESCRIPTION                                                                           |
|---------|--------------|---------------------------------------------------------------------------------------|
| 1       | -----        | Transaxle (Order parts from trans-<br>axle manufacturer)<br>Hydro gear Model 347-0510 |
| 6       | 817 06 05-12 | Screw 5/16-18                                                                         |
| 9       | 532 18 02-20 | Clutch                                                                                |
| 15      | 874 49 05-44 | Bolt Hex Flghd 5/16-18 Gr. 5                                                          |
| 16      | 873 80 05-00 | Nut Lock Hex W/Ins. 5/16-18 unc                                                       |
| 17      | 532 12 61-97 | Washer 1-1/2 OD x 15/32 ID x<br>.250                                                  |
| 19      | 873 80 06-00 | Nut Lock Hex W/Wsh 3/8-16 unc                                                         |
| 20      | 532 17 39-37 | Bolt Hex 7/16-20 x 4 x Gr. 5-1.5                                                      |
| 21      | 532 18 14-54 | Knob Custom Control Cruise                                                            |
| 22      | 532 17 58-96 | Rod, Brake                                                                            |
| 24      | 873 35 06-00 | Nut, Hex Jam 3/8-16 unc                                                               |
| 25      | 532 19 20-36 | Spring, Brake Rod                                                                     |
| 26      | 819 13 13-16 | Washer                                                                                |
| 27      | 876 02 04-12 | Pin Cotter 1/8 x 3/4 CAD.                                                             |
| 28      | 532 17 57-65 | Rod, Parking Brake                                                                    |
| 29      | 532 07 16-73 | Cap, Brake, Park                                                                      |
| 30      | 532 16 95-92 | Bracket, Transaxle                                                                    |
| 32      | 874 76 05-12 | Bolt Hex Hd 5/16-18 unc x 3/4                                                         |
| 33      | 872 14 05-06 | Bolt Rdhd Sqnk 5/16-18 unc x 3/4                                                      |
| 34      | 532 17 55-78 | Shaft, Foot Pedal                                                                     |
| 35      | 532 12 01-83 | Bearing, Nylon                                                                        |
| 36      | 819 21 16-16 | Washer                                                                                |
| 37      | 532 12 49-63 | Pin, Roll                                                                             |
| 38      | 532 17 91-14 | Pulley, Composite                                                                     |
| 39      | 872 11 06-22 | Bolt Rdhd 3/8-16 unc x 2-3/4 Gr. 5                                                    |
| 41      | 532 17 55-56 | Keeper, Belt Idler Flat                                                               |
| 47      | 532 12 77-83 | Pulley, Idler, V-Groove                                                               |
| 48      | 532 15 44-07 | Bellcrank Clutch Grnd Drw Stl                                                         |
| 49      | 532 12 32-05 | Retainer, Belt                                                                        |
| 50      | 872 11 06-12 | Bolt Carr. SH 3/8-16 x 1-1/2 Gr. 5                                                    |
| 51      | 873 68 06-00 | Nut Crownlock 3/8-16 unc                                                              |
| 52      | 873 68 05-00 | Nut, Crownlock 5/16-18 unc                                                            |
| 53      | 532 19 96-52 | Link, Clutch                                                                          |
| 55      | 532 10 57-09 | Spring, Return, Clutch                                                                |
| 56      | 817 06 06-20 | Screw 3/8-16 x 1-1/4                                                                  |
| 57      | 532 14 02-94 | V-Belt, Ground Drive                                                                  |
| 59      | 532 16 96-91 | Keeper, Center Span                                                                   |
| 61      | 817 12 06-14 | Screw 3/8-16 x .875                                                                   |
| 62      | 532 12 35-33 | Cover, Pedal                                                                          |
| 63      | 532 17 46-07 | Pulley, Engine                                                                        |
| 65      | 810 04 07-00 | Washer                                                                                |
| 66      | 532 15 47-78 | Keeper Belt Engine                                                                    |
| 69      | 532 14 24-32 | Screw Hex Wsh Hi-Lo 1/4 x 1/2 unc                                                     |
| 74      | 532 13 70-57 | Spacer, Axle                                                                          |
| 75      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.                                                         |
| 76      | 812 00 00-01 | E-Ring                                                                                |

| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 77      | 532 12 35-83 | Key, Square                       |
| 78      | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.     |
| 89      | 532 19 19-15 | Console, Shift                    |
| 95      | 532 19 56-31 | Rod Bypass                        |
| 96      | 532 12 47-88 | Retainer Spring                   |
| 120     | 873 90 06-00 | Nut Lock Flg 3/8-16 unc           |
| 150     | 532 17 54-56 | Spacer Retainer                   |
| 151     | 819 13 32-10 | Washer 13/32 x 2 x 10 Ga.         |
| 202     | 872 11 06-14 | Bolt Carr Sh 3/8-16 x 1-3/4 Gr. 5 |
| 214     | 532 17 47-35 | Link Transaxle                    |
| 217     | 532 17 94-33 | Pedal Reverse                     |
| 218     | 532 17 47-13 | Arm Control Pedal Reverse         |
| 219     | 532 17 48-39 | Bracket Frest Pdl Ctrl. Hyd       |
| 220     | 532 17 47-11 | Bracket Mtg. Pedal Control        |
| 221     | 872 14 06-06 | Bolt Rdhd Sqnk 3/8-16 unc x 3/4   |
| 222     | 873 68 07-00 | Nut Crownlock 7/16-14 unc         |
| 223     | 532 17 48-40 | Washer Nylon 11/16 ID x .060      |
| 224     | 532 17 47-36 | Pedal Forward                     |
| 225     | 532 17 47-12 | Arm Control Pedal Forward         |
| 226     | 532 17 49-02 | Bolt Pivot Spacer                 |
| 227     | 532 17 47-10 | Cam Reverse Pedal LT              |
| 228     | 532 17 90-32 | Bolt Shoulder 5/16-18             |
| 229     | 532 17 64-51 | Washer Serrated 5/16 x .75        |
| 231     | 532 17 45-73 | Strap Torque                      |
| 232     | 532 17 55-70 | Actuator Cruise Disengage         |
| 233     | 532 17 48-56 | Pawl Control Cruise               |
| 234     | 532 17 48-58 | Lever Control Cruise              |
| 235     | 532 17 48-57 | Sector Control Cruise             |
| 236     | 532 12 89-03 | Bolt Shoulder 3/8-16 unc 1/44     |
| 237     | 532 17 01-65 | Bolt Shoulder 5/16-18             |
| 238     | 532 17 58-07 | Arm Mtg. Cruise Sector            |
| 239     | 817 49 05-08 | Screw Thdrol 5/16 x 1/2           |
| 240     | 532 17 56-10 | Spring Return Cruise Control      |
| 241     | 873 93 04-00 | Nut Centerlock 1/4-20 unc         |
| 242     | 874 78 04-12 | Bolt Fin Hex 1/4-20 unc x .75     |
| 243     | 532 19 07-36 | Bracket Anti-Rotation             |
| 244     | 817 49 05-10 | Screw 5/16-18 x 5/8               |
| 251     | 817 06 05-16 | Screw 5/16-18 x 1                 |
| 252     | 819 13 16-16 | Washer 13/32 x 1 x 16 Ga.         |
| 253     | 532 17 94-22 | Washer .312 x .615 x 16 Ga.       |
| 254     | 817 00 06-16 | Screw 3/8-16 x 1                  |
| 263     | 817 00 06-12 | Screw Hexwsh Thdr 3/8-16 x 3/4    |
| 272     | 817 67 05-08 | Screw Thdrol 5/16-18 x 1/2        |
| 273     | 532 17 96-10 | Pad Pedal Reverse                 |
| 274     | 532 17 56-46 | Cover Pedal Forward               |
| 276     | 532 17 80 62 | Clip Retainer                     |

**NOTE:**All component dimensions give in U.S. inches.  
1 inch = 25.4 mm.

## REPAIR PARTS

**TRACTOR-MODEL NO. YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21**  
**STEERING ASSEMBLY**



# REPAIR PARTS

TRACTOR-MODEL NO. YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
STEERING ASSEMBLY

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                         |
|------------|--------------|-------------------------------------|
| 1          | 532 19 36-51 | Wheel Steering                      |
| 2          | 532 18 47-06 | Axle                                |
| 3          | 532 16 98-40 | Spindle Asm LH                      |
| 4          | 532 16 98-39 | Spindle Asm RH                      |
| 5          | 532 12 49-31 | Bearing Race Thrust Harden          |
| 6          | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.       |
| 8          | 812 00 00-29 | Ring Klip #t5304-75                 |
| 10         | 532 17 51-21 | Link Drag                           |
| 11         | 810 04 06-00 | Washer Lock Hvy Hlcl Spr 3/8        |
| 13         | 532 13 65-18 | Spacer Brg Axle Front               |
| 15         | 532 14 52-12 | Nut Hex Flange Lock                 |
| 17         | 532 19 07-53 | Shaft Asm Strg                      |
| 29         | 817 00 06-12 | Screw 3/8-16 x 3/4                  |
| 32         | 532 17 18-88 | Rod Tie                             |
| 33         | 819 11 12-16 | Washer 11/32 x 3/4 x 16 Ga.         |
| 34         | 810 04 05-00 | Washer Lock Hry Hlcl Spr 5/16       |
| 35         | 873 54 05-00 | Crownlock Nut 5/16 - 24 unf         |
| 36         | 532 15 50-99 | Bushing Strg                        |
| 37         | 532 15 29-27 | Screw TT #32.5 x 5 x 3/8 Flange     |
| 38         | 532 19 36-52 | Cap Wheel Steer                     |
| 39         | 819 11 38-12 | Washer 11/32 ID x 2 3/8 OD x 12 Ga. |
| 40         | 873 54 06-00 | Nut Crownlock 3/8-24 unf            |
| 41         | 532 18 67-37 | Adaptor Wheel Strg                  |
| 42         | 532 16 96-34 | Boot Dash Steering                  |
| 43         | 532 12 17-49 | Washer 25/32 x 1 1/4 x 16 Ga.       |
| 44         | 532 19 07-52 | Extension Steering Shaft            |
| 46         | 532 12 12-32 | Cap Spindle Fr Top Blk              |
| 65         | 532 16 03-67 | Spacer Brace Axle                   |
| 67         | 872 11 06-18 | Bolt Rdhd Sq 3/8-16 x 2-1/4         |
| 68         | 532 16 98-27 | Brace, Axle                         |
| 71         | 532 17 51-46 | Steering Asm                        |
| 82         | 532 19 99-78 | Bracket Susp Chassis Front          |
| 87         | 532 17 39-66 | Washer Flat .781 x 1-1/2 x .14      |
| 88         | 532 17 51-18 | Bolt Shoulder 7/16-20               |
| 91         | 532 17 55-53 | Clip Steering                       |
| 95         | 532 18 89-67 | Washer Harden .793 x 1.637 x .060   |
| 97         | 874 78 05-64 | Bolt 5/16-18 unc x 4" L Gr. 5       |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm.

**TRACTOR-MODEL NO. YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
SEAT ASSEMBLY**




| KEY NO. | PART NO.     | DESCRIPTION                      |
|---------|--------------|----------------------------------|
| 15      | 532 12 12-49 | Spacer Split 28 x 88 Zinc        |
| 16      | 532 12 37-40 | Spring Cprsn 1 310 Blk Pnt       |
| 17      | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr. 5 Zinc  |
| 21      | 532 17 18-52 | Bolt Shoulder 5/16-18 unc-2A     |
| 22      | 873 80 05-00 | Nut Lock Hx w/Ins 5/16-18 unc PL |
| 24      | 819 17 19-12 | Washer 17/32 x 1-3/16 x 12 Ga    |
| 25      | 532 12 70-18 | Bolt Shoulder 5/16-18 x 62       |
| 41      | 532 14 06-75 | Strap Asm. Fender                |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
ENGINE



# REPAIR PARTS


TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
ENGINE

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                                                                    |
|------------|--------------|--------------------------------------------------------------------------------|
| 1          | 532 18 69-68 | Control, Throttle                                                              |
| 2          | 817 72 04-08 | Screw, Hex Head, Thread Cutting 1/4-20 x 1/2                                   |
| 3          | -----        | Engine, KAWASAKI Model Number FH641V<br>(Order Parts From Engine Manufacturer) |
| 4          | 532 14 97-23 | Muffler                                                                        |
| 5          | 532 18 45-79 | Tube, Manifold, LH                                                             |
| 6          | 532 18 45-80 | Tube, Manifold, RH                                                             |
| 8          | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems                                                  |
| 10         | 532 14 66-29 | Shield, Heat Muffler CV-Intek                                                  |
| 13         | -----        | Muffler Gasket (Order Parts From Engine Manufacturer)                          |
| 14         | 532 14 84-56 | Tube Drain Oil Easy                                                            |
| 23         | 532 16 98-37 | Shield, Browning / Debris Guard                                                |
| 25         | 532 19 17-17 | Choke Control                                                                  |
| 29         | 532 13 71-80 | Kit, Spark Arrestor                                                            |
| 31         | 532 17 90-22 | Tank Fuel 3 50 Rear                                                            |
| 32         | 532 18 18-03 | Cap Fuel Asm                                                                   |
| 33         | 532 12 34-87 | Clamp, Hose                                                                    |
| 37         | 532 14 21-58 | Line, Fuel                                                                     |
| 38         | -----        | Plug Drain Oil Easy<br>(Order Parts From Engine Manufacturer)                  |
| 41         | 532 13 92-77 | Stem Fuel Tank                                                                 |
| 45         | 817 00 06-12 | Screw Hexwash Thdr                                                             |
| 81         | 873 51 04-00 | Nut, Keps Hex 1/4-20 unc                                                       |
| 105        | 817 12 06-16 | Screw 3/8-16 x 1 SMGML TAP/R                                                   |
| 112        | 532 12 49-52 | Bushing                                                                        |
| 116        | 532 18 43-62 | Nut Flange M8-1.25 NON-LK ZINK                                                 |
| 119        | 532 40 05-95 | Guard Asm LH                                                                   |
| 120        | 532 40 05-94 | Guard Asm RH                                                                   |
| 121        | 532 19 66-88 | Clip Threaded                                                                  |
| 122        | 532 13 77-29 | Screw Thd /rikk 1/4-20 x 5/8                                                   |
| 123        | 817 67 05-08 | Screw Thdrol 5/16-18 x 1/2                                                     |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
MOWER DECK



# REPAIR PARTS

**TRACTOR-MODEL NO. YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21**  
**MOWER DECK**


| KEY NO. | PART NO.     | DESCRIPTION                      |
|---------|--------------|----------------------------------|
| 1       | 532 16 58-92 | Housing Asm Mower 42"94 T-Path   |
| 2       | 872 14 05-06 | Bolt Rdhd Sqnk 5/16-18 unc x 3/4 |
| 3       | 532 13 80-17 | Bracket Asm Fr Sway Bar 38/42    |
| 4       | 532 16 54-60 | Bracket Asm Deck 42"sway Bar     |
| 5       | 532 12 46-70 | Retainer Spring                  |
| 6       | 532 17 80-24 | Bar Sway Deck                    |
| 8       | 532 19 30-03 | Bolt Washer Asm. 7/16-20 unf     |
| 9       | 810 03 06-00 | Washer Lock Hvy 3/8 Unplated     |
| 10      | 532 14 02-96 | Washer Hard Blade Mower Vented   |
| 11      | 532 13 89-71 | Blade Mower High Lift"           |
| 13      | 532 19 28-72 | Shaft Asm W/lower Bearing        |
| 14      | 532 18 72-81 | Housing Mandrel Vented(machd)    |
| 15      | 532 11 04-85 | Bearing Ball Mandrel             |
| 16      | 532 17 44-93 | Stripper Round Mower             |
| 18      | 872 14 05-05 | Bolt Carr 5/16-18 x 5/8          |
| 19      | 532 13 28-27 | Bolt Shoulder                    |
| 20      | 532 15 97-70 | Baffle Vortex 42                 |
| 21      | 873 68 05-00 | Nut Crown Lock 5/16-18           |
| 23      | 532 17 75-63 | Bracket Deflector Mower 42"      |
| 24      | 532 10 53-04 | Cap Sleeve 80 x 112 Blk Mower    |
| 25      | 532 12 37-13 | Spring Torsion Deflector 2 52    |
| 26      | 532 11 04-52 | Nut Push Phos & Oil              |
| 27      | 532 40 14-31 | Shield Deflector                 |
| 28      | 819 11 10-16 | Washer 11/32 x 5/8 x 16 Ga.      |
| 29      | 532 13 14-91 | Rod Hinge 42" 6 75 Wlg           |
| 30      | 532 17 39-84 | Screw Thd Rolling                |
| 31      | 532 18 76-90 | Washer Spacer                    |
| 32      | 532 15 35-35 | Pulley Mandrel                   |
| 33      | 532 40 02-34 | Nut Flange Toplock               |
| 34      | 872 11 06-12 | Bolt RDHD 3/8-16 x 1-1/2         |
| 36      | 532 13 14-94 | Pulley Idler Flat 3 060          |
| 40      | 873 90 06-00 | Nut Lock 3/8-16 unc              |
| 44      | 532 14 00-88 | Guard Mandrel LH Black           |
| 45      | 532 12 47-88 | Retainer Spring                  |
| 46      | 532 13 77-29 | Screw Thdrol 1/4-20 x 5/8        |
| 54      | 532 17 85-15 | Washer Hardened                  |
| 55      | 532 15 50-46 | Arm Idler 42" mower LT/YT        |
| 56      | 532 16 57-23 | Spacer Retainer Mower            |
| 59      | 532 14 10-43 | Guard, Belt                      |
| 61      | 532 17 48-82 | Spring Ext. Elect                |
| 68      | 532 18 02-60 | V-Belt Mower                     |
| 91      | 532 18 05-32 | Bracket Asm Noseroller LH        |

| KEY NO. | PART NO.     | DESCRIPTION                                                                                                                                      |
|---------|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| 92      | 873 80 06-00 | Nut Lock Hex w/Ins. 3/8-16 unc                                                                                                                   |
| 94      | 532 13 22-64 | Roller Nose 38 & 42                                                                                                                              |
| 95      | 532 18 05-33 | Bracket Asm Noseroller RH                                                                                                                        |
| 111     | 532 17 92-92 | Bracket Gauge Wheel Lh                                                                                                                           |
| 112     | 532 17 92-93 | Bracket Gauge Wheel Rh                                                                                                                           |
| 113     | 817 00 05-10 | Screw 3/8-16 x .625                                                                                                                              |
| 116     | 532 12 48-42 | Bolt Shoulder                                                                                                                                    |
| 117     | 532 18 86-06 | Wheel Gauge                                                                                                                                      |
| 118     | 873 93 06-00 | Nut Centerlock 3/8-16 unc                                                                                                                        |
| 119     | 819 12 14-14 | Washer 3/8 x 7/8 x 14 Ga.                                                                                                                        |
| 129     | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga.                                                                                                                    |
| 130     | 874 78 06-16 | Bolt Fin Hex 3/8-16 unc x 1 Gr. 5                                                                                                                |
| 131     | 872 14 06-08 | Bolt Rdhd Sqnk 3/8-16 unc x1                                                                                                                     |
| 132     | 817 00-06-12 | Screw 3/8-16 x .75                                                                                                                               |
| 143     | 532 15 71-09 | Bracket Arm Idler                                                                                                                                |
| 144     | 532 15 86-34 | Keeper Belt                                                                                                                                      |
| 145     | 532 16 58-88 | Pulley Idler Flat                                                                                                                                |
| 146     | 532 17 19-77 | Bolt Carriage Idler                                                                                                                              |
| 148     | 532 16 90-22 | Spring Return Idler                                                                                                                              |
| 149     | 532 16 58-98 | Retainer Spring Yellow                                                                                                                           |
| 150     | 819 09 12-10 | Washer 9/32 x 3/4 x 10 Ga.                                                                                                                       |
| 159     | 872 14 06-14 | Bolt RDHD Sqn 3/8-16 x 1-3/4                                                                                                                     |
| 182     | 532 17 91-26 | Rod Roller Nose                                                                                                                                  |
| 183     | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock                                                                                                                     |
| 184     | 819 13 14-10 | Washer 13/32 x 7/8 x 10 Ga.                                                                                                                      |
| 196     | 532 40 11-19 | Guard Mandrel RH                                                                                                                                 |
| 199     | 532 40 02-78 | Guard Asm. Fabric LH                                                                                                                             |
| 200     | 532 40 02-79 | Guard Asm. Fabric RH                                                                                                                             |
| 201     | 532 40 12-20 | Push Nut                                                                                                                                         |
| 202     | 872 11 06-08 | Bolt Rdhd Sqnk 3/8-16 x 1 Gr. 5                                                                                                                  |
| 203     | 532 19 72-62 | Bolt Shoulder Bolt                                                                                                                               |
| --      | 532 19 28-70 | Mandrel Assembly (Includes Housing, Shaft and Shaft Hardware Only-Pulley Not Included)                                                           |
| --      | 532 40 08-34 | Replacement Mower, Complete (Std. Deck - Order separately nose roller and gauge wheel components key nos. 91, 94, 95, 132, 182, 183 and 116-119) |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO. 960 11 01-21  
MOWER LIFT



lift-rh.1pc.stlt\_10

# REPAIR PARTS

TRACTOR-MODEL NO.YTH210 XP (96011012100), PRODUCT NO.960 11 01-21  
MOWER LIFT

| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                    |
|------------|--------------|--------------------------------|
| 1          | 532 15 94-60 | Wire Asm Inner/Sprg w/plngr LT |
| 2          | 532 15 94-71 | Shaft Asm Lift                 |
| 3          | 532 10 57-67 | Pin Groove                     |
| 4          | 812 00 00-02 | E Ring #5133-62                |
| 5          | 819 21 16-21 | Washer 21/32 x 1 x 21 Ga.      |
| 6          | 532 12 01-83 | Bearing Nylon Blk 629 Id       |
| 7          | 532 12 56-31 | Grip Handle                    |
| 8          | 532 12 45-26 | Button Plunger Black           |
| 11         | 532 13 98-65 | Link Lift LH Mower             |
| 12         | 532 13 98-66 | Link Lift RH Mower             |
| 13         | 532 12 46-70 | Retainer Spring                |
| 15         | 532 17 32-88 | Link Front                     |
| 16         | 873 35 08-00 | Nut Jam Hex 1/2-13 unc         |
| 17         | 532 17 56-89 | Trunnion                       |
| 18         | 873 80 08-00 | Nut Lock w/wsh 1/2-13 unc      |
| 19         | 532 13 98-68 | Arm Suspension Rear            |
| 20         | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock   |
| 23         | 532 11 08-07 | Nut Special                    |
| 24         | 819 13 10-16 | Washer 13/32 x 5/8 x 16 Ga.    |
| 25         | 532 12 48-74 | Spring 2-1/8"                  |
| 26         | 532 16 94-84 | Retainer Clip                  |
| 27         | 532 12 69-71 | Rod Adj Lift                   |
| 28         | 873 35 06-00 | Nut Hex Jam 3/8-16 unc         |
| 29         | 532 13 80-57 | Knob Inf 3/8-16 unc            |
| 30         | 532 15 02-33 | Trunnion Inf. Height           |
| 31         | 532 16 98-65 | Bearing PT Lift                |
| 32         | 873 54 06-00 | Nut Crownlock 3/8-24           |
| 36         | 532 15 50-97 | Pointer Height Ind             |
| 37         | 532 12 39-35 | Plug Hole                      |
| 38         | 817 06 05-16 | Screw 5/16-18 x 1              |
| 40         | 819 11 24-10 | Washer 11/32 x 1-1/2 x 10 Ga.  |
| 41         | 532 15 50-98 | Ind Height STLT                |
| 49         | 532 14 52-12 | Nut, Hex Flange Lock           |
| 50         | 532 11 04-52 | Nut, Push                      |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm