

600 S

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen


Repuestos

Reservdelar

Product No: 954 05 66-21

GPL®

A



A

KEY NO.	PART NO.	PART NAME
---------	----------	-----------

1	532 85 07-35	Control Bar
2	532 15 38-17	Upper Handle
3	532 15 30-28	Lower Handle
4	532 13 19-59	Handle Bolt 5/16-18 x 3/4
5	532 14 49-29	Pan Head Machine Screw 1/4-20 x 2.12
6	532 85 14-62	Throttle Control
8	532 13 08-61	Engine Zone Control Cable
9	532 06 36-01	Locknut 1/4-20
10	532 75 00-97	Hex Washer Head Screw #10-24x1/2
11	532 12 51-62	Up-Stop Bracket
12	532 15 15-17	Cable Clip
13	532 05 17-93	Hairpin Cotter
14	532 13 20-01	Rope Guide
15	532 13 63-76	Handle Knob
18	532 08 79-30	Cable Clip
19	532 08 38-16	Thread Rolling Screw #10-32x5/8
21	532 14 08-36	Wheel Adjuster Bracket (LF/RR)
24	532 15 30-27	Handle Bracket Assembly (Left)
25	532 15 30-26	Handle Bracket Assembly(Right)
26	532 14 09-96	Wheel Adjuster Bracket (RF/LR)
27	532 14 66-30	Spacer
29	532 14 17-30	Selector Spring
30	532 08 78-77	Selector Knob
31	532 08 75-89	Torsion Spring
33	532 14 72-86	Hinge Rod
34	532 08 75-93	Housing Bracket
35	532 75 01-49	Discharge Guard Assembly
36	532 14 98-57	Axle Arm Assembly
37	532 06 23-35	Belleville Washer 1/2
38	532 14 27-48	Shoulder Bolt 3/8-16
39	532 75 00-01	Wheel & Tire Assembly

KEY NO.	PART NO.	PART NAME
---------	----------	-----------

42	532 07 74-00	Hubcap
43	532 15 00-78	Screw 5/16-18x3/4
44	532 12 51-99X	Handle Support Bracket (Right)
45	532 12 52-01X	Handle Support Bracket (Left)
47	532 15 24-55	Lawn Mower Housing
48	532 14 60-26	Front Baffle
- -	532 12 50-46	Rear Baffle (Not Shown)
50	532 75 15-92	Locknut 3/8-16
51	532 85 09-99	HexHeadTreadRollingScrew3/8-16x1
52	532 85 09-77	Blade Adapter
53	532 14 51-06	20" Blade
54	532 85 10-74	Hardened Washer
55	532 85 02-63	Helical Lockwasher 3/8
56	532 85 10-84	Hex Head Screw 3/8-24 x1Grade8
58	532 14 54-94	Warning Decal
59	-----	* Engine
60	532 08 58-25	Hex Washer Head Screw 10-24 x 1
61	532 06 91-80	NutHexLk.Washer#10-24
62	532 15 41-47	Footguard

*These Parts must be purchased through an authorised Briggs and Stratton Dealer.