


# J50

**Spare parts**  
**Ersatzteile**  
**Pièces détachées**  
**Reserve onderdelen**  
**Repuestos**  
**Reservdelar**

**GPL®**

# ROTARY LAWN MOWER - - MODEL NUMBER J50 (96111001302) PRODUCT NUMBER 961 11 00-13



# ROTARY LAWN MOWER - - MODEL NUMBER J50 (96111001302) PRODUCT NUMBER 961 11 00-13

| KEY NO. | PART NO.            | DESCRIPTION                 |
|---------|---------------------|-----------------------------|
| 1       | 532 19 60-25        | Control Bar                 |
| 2       | 532 19 47-88        | Rope Guide                  |
| 3       | 532 12 50-78        | Engine Washer               |
| 4       | 532 19 60-26        | Upper Handle                |
| 5       | 532 15 50-44        | Lower Handle                |
| 6       | 532 13 20-04        | Nut, Hex                    |
| 7       | 532 19 15-74        | Handle Bolt 5/16-18 x 1-3/4 |
| 8       | 532 12 51-62        | Up-Stop Bracket             |
| 9       | 532 08 58-25        | Screw                       |
| 10      | 532 70 08-92        | Engine Zone Control Cable   |
| 11      | 532 75 06-34        | Nut, Hex                    |
| 12      | 532 06 64-26        | Wire Tie                    |
| 13      | 532 05 17-93        | Hairpin Cotter              |
| 14      | 532 19 19-38        | Wing Nut, Steel             |
| 15      | 532 75 20-52        | Discharge Guard             |
| 16      | 532 85 02-63        | Helical Lockwasher 3/8      |
| 17      | 532 06 91-80        | Nut, Hex                    |
| 18      | 532 85 10-74        | Hardened Washer             |
| 19      | 532 85 18-55        | Torsion Spring              |
| 20      | 532 14 51-06        | Blade, 20"                  |
| 21      | 532 08 86-02        | Bracket, Mounting           |
| 22      | 532 15 02-15        | Hinge Rod                   |
| 23      | 532 15 41-47        | Footguard                   |
| 24      | 532 13 99-01        | Wheel Adjusting Bracket     |
| 25      | 532 85 09-77        | Blade Adapter               |
| 26      | 532 17 09-75        | Handle Bracket Assembly, RH |
| 27      | 532 17 09-77        | Handle Bracket Assembly, LH |
| 29      | <b>532 40 16-29</b> | Spacer                      |

| KEY NO. | PART NO.            | DESCRIPTION                                                                             |
|---------|---------------------|-----------------------------------------------------------------------------------------|
| 30      | - - -               | Engine, Briggs & Stratton, Model Number 9D902<br>(order parts from engine manufacturer) |
| 31      | <b>532 40 64-28</b> | Selector Spring                                                                         |
| 32      | 532 08 78-77        | Selector Knob                                                                           |
| 33      | <b>532 40 78-71</b> | Axle Arm Assembly                                                                       |
| 34      | <b>532 40 16-30</b> | Belleville Washer                                                                       |
| 35      | 532 14 27-48        | Shoulder Bolt                                                                           |
| 36      | 532 40 52-68        | Wheel & Tire Assembly                                                                   |
| 37      | 532 08 39-23        | Nut, Hex                                                                                |
| 38      | 532 15 04-06        | Hex Head Thread Rolling Screw 3/8-16 x 1-1/8                                            |
| 39      | 532 40 00-60        | Lawn Mower Housing                                                                      |
| 40      | 532 85 10-84        | Hex Head Screw 3/8-24 x 1-3/8 Grade 8                                                   |
| 41      | 532 14 97-41        | Thread Cutting Screw 5/16-18 x 3/4                                                      |
| 42      | 532 18 21-66        | Danger Decal                                                                            |
| 43      | 532 75 15-92        | Locknut, Hex 3/8-16                                                                     |
| 44      | 532 19 79-91        | Clip, Cable                                                                             |
| 45      | 532 08 38-16        | Screw #10                                                                               |
| 46      | 532 11 11-90        | Clamp, Cable                                                                            |
| 47      | 532 70 04-17        | Control Throttle                                                                        |
| 48      | 532 18 33-65        | Screw 1/4-20 x 2.12                                                                     |
| 55      | 532 14 15-19        | Front Baffle                                                                            |
| 56      | 873 80 04-00        | Nut, Hex                                                                                |
| 57      | <b>532 19 33-60</b> | Mulcher Plug                                                                            |
| --      | 532 14 15-20        | Rear Baffle (not shown)                                                                 |
| --      | 532 40 00-56        | Operator's Manual, European                                                             |
| --      | 532 40 00-55        | Operator's Manual, Scandinavian                                                         |
| --      | <b>532 40 00-57</b> | Operator's Manual, East Bloc                                                            |
| --      | <b>532 40 00-58</b> | Operator's Manual, Baltic                                                               |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.