




# SPARE PARTS LIST


LAWN MOWERS: CONSUMER  
WALK-BEHINDS

LB 348SI, 967656501, 2018-10

**B** LB 348SI  
HANDLE

| Ref | Part No      | Description         | Remark | QTY KIT |
|-----|--------------|---------------------|--------|---------|
| 1   | 582 81 81-02 | HANDLE              |        | 1       |
| 2   | 501 11 01-01 | TUBE                |        | 1       |
| 3   | 582 09 02-02 | BAIL                |        | 1       |
| 4   | 587 10 18-02 | BAIL                |        | 1       |
| 5   | 587 10 25-03 | GRIP                |        | 1       |
| 6   | 503 32 09-02 | BUSHING             |        | 4       |
| 7   | 531 20 80-43 | BRACKET             |        | 1       |
| 8   | 535 47 52-45 | SCREW EHHFM         |        | 1       |
| 9   | 732 25 16-01 | HEXAGON LOCKING NUT |        | 1       |
| 10  | 582 66 25-03 | LEVER ASSY          |        | 1       |
| 11  | 502 43 52-01 | SCREW ITXPANTT      |        | 2       |
| 12  | 579 13 46-01 | CABLE HOLDER        |        | 2       |
| 13  | 589 33 42-03 | WIRE                |        | 1       |
| 14  | 582 10 52-02 | WIRE                |        | 1       |
| 15  | 587 78 04-01 | WASHER              |        | 2       |
| 16  | 588 15 73-02 | BOLT                |        | 2       |
| 17  | 588 15 74-01 | WASHER              |        | 2       |
| 18  | 731 43 18-01 | HEXAGON THIN NUT    |        | 2       |
| 19  | 587 23 72-01 | KNOB                |        | 2       |
| 20  | 506 57 01-04 | SCREW EHHFM         |        | 2       |
| 21  | 732 21 18-01 | LOCK NUT            |        | 2       |
| 22  | 734 18 20-51 | WASHER              |        | 2       |






## MOWER DECK / CUTTING DECK

LB 348SI, 967656501, 2018-10

| Ref | Part No      | Description      | Remark | QTY KIT  |
|-----|--------------|------------------|--------|----------|
| 1   | 502 43 52-01 | SCREW ITXPANTT   |        | 17       |
| 2   | 504 05 56-01 | NUT FLANGE       |        | 1        |
| 3   | 504 05 33-01 | PULLEY           |        | 1        |
| 4   | 501 98 66-01 | BELT             |        | 1        |
| 5   | 522 02 46-01 | SPRING           |        | 2        |
| 6   | 504 83 82-01 | LEVER            |        | 1        |
| 7   | 504 04 80-01 | GEARBOX          |        | 1        |
| 8   | 502 43 53-01 | SCREW ITXPANT    |        | 2        |
| 9   | 522 02 40-01 | NUT              |        | 2        |
| 10  | 504 04 87-01 | SPRING           |        | 1        |
| 11  | 504 04 86-01 | BRACKET          |        | 1        |
| 12  | 504 45 60-01 | WASHER, 5X13X1   |        | 2        |
| 13  | 582 66 42-02 | HANDLE SUPPORT   |        | 1        |
| 15  | 522 61 23-01 | BELT GUIDE       |        | 1        |
| 16  | 504 64 15-01 | SKID PLATE       |        | 1        |
| 17  | 582 66 45-02 | HANDLE SUPPORT   |        | 1        |
| 18  | 506 55 83-02 | SCREW EHHFT      |        | 6        |
| 19  | 735 31 09-21 | E-CLIP           |        | 2        |
| 21  | 504 62 50-01 | SHAFT            |        | 2        |
| 22  | 504 70 28-01 | LOCK RING        |        | 2        |
| 23  | 505 22 14-01 | WASHER           |        | 4        |
| 24  | 738 21 01-04 | BALL BEARING     |        | 8 25, 30 |
| 25  | 584 14 22-01 | WHEEL ASSY       |        | 2        |
| 27  | 574 25 94-01 | SCREW            |        | 4        |
| 28  | 584 15 93-01 | HUB CAP          |        | 4        |
| 29  | 584 15 94-01 | NUT CAP          |        | 4        |
| 30  | 584 61 16-01 | WHEEL ASSY       |        | 2        |
| 31  | 504 62 41-01 | DUST COVER       |        | 4        |
| 32  | 544 34 23-01 | PINION           |        | 2        |
| 33  | 504 70 98-04 | LINK ARM ASSY    |        | 2        |
| 35  | 504 70 98-02 | LINK ARM ASSY    |        | 2        |
| 36  | 504 62 49-01 | BRACKET          |        | 2        |
| 39  | 505 52 10-01 | NUT              |        | 2        |
| 40  | 583 90 18-01 | FRONT COVER ASSY |        | 1        |
| 41  | 502 62 54-02 | SKID PLATE       |        | 1        |
| 42  | 504 61 55-02 | ROD              |        | 1        |
| 44  | 574 40 60-01 | TRANSVERSAL ROD  |        | 2        |
| 46  | 501375506    | TBD              |        | 1        |
| 47  | 735 31 36-21 | LOCKWASHER       |        | 1        |
| 48  | 504 83 82-01 | LEVER            |        | 1        |
| 49  | 522 59 85-01 | KNOB             |        | 1        |
| 50  | 501 35 50-02 | REAR COVER       |        | 1        |
| 61  | 594 96 56-01 | COVER ASSY       |        | 1        |
| 62  | 594 96 54-01 | DEFLECTOR ASSY   |        | 1        |

**C** LB 348SI  
ENGINE

## ENGINE

LB 348SI, 967656501, 2018-10

| Ref | Part No      | Description    | Remark       | QTY KIT |
|-----|--------------|----------------|--------------|---------|
| 1   | .            | TBD            | 104M0B0069H1 | 1       |
| 3   | .            | TBD            |              | 1       |
| 4   | 532 15 04-06 | BOLT           |              | 3       |
| 5   | 588 64 57-02 | BLADE SUPPORT  |              | 1       |
| 6   | 501 96 81-01 | BELT COVER     |              | 1       |
| 7   | 502 43 52-01 | SCREW ITXPANTT |              | 2       |
| 8   | 503 25 94-01 | WASHER         |              | 1       |
| 9   | 502 88 13-10 | BLADE          |              | 1       |
| 10  | 503 33 25-01 | SPRING         |              | 1       |
| 11  | 504 45 64-03 | SCREW EHHI     |              | 1       |
| 12  | 587 35 68-01 | CHARGER        |              | 1       |
| 13  | 587 35 67-01 | BATTERY        |              | 1       |

