

SPARE PARTS CATALOGUE

LAWN MOWERS: CONSUMER WALK-BEHINDS: HUSQVARNA LC 140P




Spare Parts List

SPARE PARTS LIST

LAWN MOWERS: CONSUMER WALK-
BEHINDS

HUSQVARNA LC 140P


A LC 140P CHASSIS



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599349369	CHASSIS	CHASSIS	1
2	599349371	COVER KIT	FRONT COVER	1
3	599349373	FLAP	REAR DOOR	1
4	599349422	WHEEL	REAR WHEEL	1
5	599349385	AXLE	WHEEL AXLE	1
6	599349417	SLEEVE	REAR AXLE SLEEVE	1
7	599349387	AXLE	WHEEL AXLE	1
8	599349382	AXLE	FRONT AXLE FIXING	1
9	599349367	WHEEL	FRONT WHEEL	1
10	599349398	HANDLE KIT	HEIGHT ADJUSTMENT HANDLE	1
11	599349363	PLATE KIT	HEIGHT ADJUSTMENT PLATE	1
12	599349364	ROD	HEIGHT ADJUSTMENT ROD	1
13	599349366	SPRING	HEIGHT ADJUSTMENT SPRING	1




D LC 140P
GRASS HANDLING



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599349378	GRASS BAG ASSY	GRASS BAG KIT	1




C LC 140P
ENGINE



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	TBD	TBD		1
2	599349407	INSTALLATION KIT	BOLTS AND NUTS	1
3	599349376	COVER	BELT COVER	1
4	529737101	BLADE SUPPORT	BLADE ADAPTER	1
5	599349374	BLADE		1



B LC 140P
HANDLE



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
1	599349362	BAIL ARM ASSY	BAIL ARM	1
2	599349402	HANDLE KIT	HANDLE AND SHEATH	1
3	599349397	HANDLE	LOWER HANDLE	1
4	599349361	BAIL ARM ASSY	BAIL ARM	1
5	529853401	HANDLE KIT	HANDLE	1
6	599349360	KNOB ASSY	KNOB	1
7	599349391	CABLE	FLAMEOUT CABLE	1
8	599349379	CLIP	CABLE CLIP	1
9	529596001	KNOB ASSY	KNOB	1
10	599349380	SUPPORT KIT	HANDLE BRACKET	1
11	599349418	SLEEVE	ANTI FRICTION SLEEVE	1

