

LC53 e

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar


GPL®

A LC53e Deck




Page A LC53e DECK				
Position	Article	Quantity	Notes	Kit
1	502 43 52-01	2		
2	504 05 56-01	1		
3	504 05 33-01	1		
4	501 98 66-02	1		
5	574 86 72-01	1		
6	504 04 83-01	1		
7	504 04 80-01	1		
8	502 43 53-01	2		
9	522 02 40-01	2		
10	504 04 87-01	1		
11	504 04 86-01	1		
12	505 14 40-01	1		
13	505 89 59-01	1		
14	531 20 58-48	1		
15	522 61 23-01	1		
16	504 64 15-01	1		
17	505 13 04-01	1		
18	506 55 83-02	6		
19	735 31 09-21	2		
21	504 62 50-01	2		
22	504 70 28-01	2		
23	505 22 14-01	4		
24	738 21 01-04	8		
26	502 49 68-01	2		
27	544 44 39-01	4		
28	574 25 94-01	4		
29	544 43 31-01	4		
30	544 91 69-02	2		
31	504 62 41-01	4		
32	544 34 23-01	2		
33	504 70 98-01	2		
34	506 60 63-01	1		
35	504 70 98-02	2		
36	504 62 49-01	2		
39	505 52 10-01	2		
40	505 03 19-01	1		
41	502 62 54-01	1		
42	510 02 94-01	1		
43	505 10 93-01	1		
44	574 40 60-01	2		
45	504 62 76-02	1		
46	505 39 70-01	1		
47	502 43 52-01	2		
48	502 43 52-01	4		
49	502 43 52-01	4		
50	505 20 19-01	1		
52	505 20 21-01	1		
53	502 43 52-01	2		
54	505 13 05-01	1		
55	505 13 09-01	1		
56	505 12 43-01	1		
57	505 14 05-01	1		
58	505 14 39-01	1		
59	502 43 53-01	4		
60	502 43 52-01	1		

B LC53e
Handle Std



Page B LC53e HANDLE				
Position	Article	Quantity	Notes	Kit
1	505 27 60-01	1		
2	505 27 58-01	1		
3	505 27 61-01	1		
4	574 39 14-01	1		
5	734 11 46-01	1		
6	522 98 54-01	1		
7	523 04 52-01	1		
8	505 27 62-01	1		
9	574 25 83-01	1		
10	505 27 52-01	1		
12	505 27 53-01	1		
13	505 27 55-01	1		
15	505 60 64-01	1		
16	506 60 61-01	1		
17	522 98 53-01	1		
18	505 06 80-01	1		
19	574 88 64-01	1		
20	574 56 67-01	1		
21	505 07 06-01	1		
23	734 11 65-41	1		
24	574 85 27-01	1		
25	503 22 10-11	1		
26	521 89 34-01	1		
27	521 89 33-01	1		
28	505 19 84-01	2		
29	525 44 88-01	2		
30	505 89 60-01	1		
31	725 53 70-01	1		
32	510 28 23-01	1		
34	522 66 93-02	1		
36	574 23 07-01	2		
37	725 53 72-01	8		
42	510 40 88-01	1		
43	510 40 89-01	1		
44	505 52 46-03	4		
45	525 51 48-01	4		


C LC53e
Engine



Page C LC53e ENGINE				
Position	Article	Quantity	Notes	Kit
1	516 04 36-01	1		
2	100602-0164-B8	1	Briggs & Stratton	
3	531 21 28-51	3		
4	504 46 05-01	1		
5	504 59 13-01	1		
7	501 96 81-01	1		
8	502 43 52-01	2		
9	510 43 64-01	1		
10	531 20 72-43	1		
11	531 20 72-37	1		
12	531 20 66-49	1		
13	575 74 97-01	1		

GPL®

D LC53e
Collect parts



Page D LC53e COLLECT PARTS				
Position	Article	Quantity	Notes	Kit
1	502 24 59-01	1		
2	502 24 47-01	1		
3	504 59 81-01	1		
4	502 43 53-01	1		
5	734 11 47-41	1		
6	501 96 77-01	1		
7	501 98 77-01	1		
8	505 39 67-01	1		
9	505 15 14-01	1		
10	502 30 50-01	2		
11	505 19 84-01	2		
12	505 15 61-01	2		
13	522 66 93-02	2		
14	505 19 84-01	2		
15	505 55 77-01	2		
16	502 43 53-01	6		
17	501 98 76-01	1		
18	502 44 71-01	1		
19	505 39 69-01	1		

