

ILLUSTRATED PARTS LIST


MODEL NUMBER LC56 B

PRODUCT NUMBER 961 41 02-73

MFG. ID. NUMBER 96141027300



HUSQVARNA ROTARY LAWN MOWER - MODEL NUMBER LC56 B (96141027300) PRODUCT NO. 961 41 02-73




HUSQVARNA ROTARY LAWN MOWER - MODEL NUMBER LC56 B (96141027300) PRODUCT NO. 961 41 02-73

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	580 63 87-06	Upper Handle	49	532 85 02-63	Washer, Lock
2	579 48 42-02	Cable, Blade Brake / Clutch Control	50	532 18 04-60	Bolt, Hex Head, Grade 8
6	532 18 23-98	Handle Knob, Star	51	581 23 89-01	Front Baffle
8	580 74 97-06	Control Bar Assembly (Includes Blade Control Lever, Roll Pin and Spring)	52	532 18 21-66	Decal, Danger
9	532 43 13-90	Rear Door Assembly	53	817 00 05-10	Screw
11	532 42 55-75	Hairpin, Door/Handle Pivot	56	817 41 13-12	Screw, Hex Washer Head #13 x 3/4
12	532 19 19-38	Handle Knob, Standard	57	532 15 53-77	Nut, Hex
13	532 43 75-16	Pug, Handle Bar	58	532 44 11-97	Bar, Lower Handle
17	581 78 21-01	Rear Baffle	59	532 19 15-74	Handle Bolt
18	532 13 20-04	Keps Locknut 1/4-20	60	579 48 28-01	E-Ring
19	532 19 47-88	Rope Guide	61	581 42 45-01	Bolt, Pivot, Tension Arm
21	532 41 99-49	Spring, Rear Door, LH, Black	64	- - -	Engine, Honda, Model Number GCV160-AOSBHE (order parts from Honda Engines)
22	532 14 18-41	Screw, Panhead, Torx #20	84	532 42 81-24	Fastener, Push
24	532 41 99-48	Spring, Rear Door, RH, Grey	96	532 19 79-91	Clip, Cable
26	532 41 99-45	Screw, Rear Door/Handle Pivot	97	581 11 53-02	Belt Keeper
28	872 25 05-05	Bolt, Carriage 5/16-18 x 5/8	99	532 43 73-89	Cover, Drive
30	580 94 73-07	Grassbag	100	532 43 94-68	Control, Throttle/Engine
31	532 41 99-51	Frame, Grass Catcher	101	532 18 33-65	Screw
32	532 44 11-92	Latch, Mulcher Door	103	581 53 07-01	Spring, Brake Reset
33	532 41 99-27	Mulcher Door	104	580 29 00-01	Shroud, Engine
34	532 43 81-34	Bracket, Grassbag	105	580 76 87-01	Mounting Screw, Engine Shroud
36	532 17 57-35	Hinge Bracket Assembly	106	579 14 69-01	Bolt, Brake Reset Spring
37	532 43 73-45	Screw, Hex Washer Head	107	579 27 32-01	Belt, Blade Brake/Clutch
38	532 42 61-29	Discharge Deflector	108	532 85 10-84	Bolt, Blade Brake/Clutch
39	581 35 37-02	Handle Bracket, LH	109	581 30 81-01	Free Hub/Blade Adapter
40	581 35 36-02	Handle Bracket, RH	110	581 35 45-01	Tension Arm Assembly, Blade Brake/Clutch
41	532 15 04-06	Screw, Dogpoint 3/8-16 x 1-1/8	111	872 14 04-05	Bolt, Carriage 1/4-20
42	532 19 30-00	Spring, Torsion	112	579 47 18-02	Bracket, Mounting, Blade Brake/Clutch Cable
43	532 19 17-30	Nut, Hex, Nylock	113	532 43 81-30	Nut, Hex, Flanged 1/4-20
44	581 70 83-17	Kit, Lawn Mower Housing	- -	115 58 34-20	Operator's Manual, European
45	532 17 56-50	Rod, Hinge	- -	115 58 34-10	Operator's Manual, Scandinavian
46	581 27 74-01	Blade Brake/Clutch Assembly	- -	115 58 34-50	Operator's Manual, East Bloc
47	581 04 52-03	Blade, 22"	- -	115 58 34-40	Operator's Manual, Baltic
48	579 27 38-01	Washer, Flat			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

HUSQVARNA ROTARY LAWN MOWER - MODEL NUMBER LC56 B (96141027300) PRODUCT NO. 961 41 02-73



HUSQVARNA ROTARY LAWN MOWER - MODEL NUMBER LC56 B (96141027300) PRODUCT NO. 961 41 02-73

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	581 95 05-01	Drive Control Assembly (Includes Cable)	30	532 19 17-30	Bolt, Hex Head 5/16-18
4	532 19 74-80	O-Ring	31	532 40 48-45	Pawl, Drive
5	532 08 83-48	Washer, Flat	32	581 68 51-01	Wheel & Tire Assembly, Rear
9	532 43 16-50	Cable, Drive	33	532 40 91-48	Nut, Flangelock 3/8-16
10	532 43 27-90	Mounting Bracket, Drive Control	34	532 40 48-35	Pinion
12	532 40 65-57	Belt, Drive	35	532 43 78-72	Kit, Wheel Adjuster, Front, RH
13	581 68 08-01	Gear Case Assembly, Complete	36	532 43 78-71	Kit, Wheel Adjuster, Front, LH
14	532 19 41-28	Pulley, Drive	37	532 16 34-09	Screw, Hi-Lo Thread
15	581 49 79-01	Wheel Adjuster, Rear, RH	40	532 41 08-31	Wheel & Tire Assembly, Front
16	581 49 79-02	Wheel Adjuster, Rear, LH	41	532 43 84-89	Kit, Water Washout Assembly
18	532 70 10-37	Selector Knob	42	532 43 49-94	Fitting, Water Washout
20	580 80 69-01	Debris Shield	43	532 41 55-85	Washer, Lock, Internal Tooth
22	817 00 05-10	Bolt, Hex Head	44	532 41 55-86	Locknut, Hex, with O-Ring
25	581 31 38-02	Mounting Bracket, Debris Shield	55	581 35 13-01	Spring, Return
26	532 42 60-66	Belt Keeper	59	532 44 21-13	Support Bracket, Front Axle
27	532 06 77-25	Washer	61	532 18 16-98	Screw
28	812 00 00-58	E-Ring 7/16	84	532 41 64-05	Adapter, Quick-Connect
29	581 84 04-01	Cover, Dust, Wheel	86	580 36 43-01	Pulley, Idler
			87	581 12 76-01	Screw

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.