

R53SV

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar



ROTARY LAWN MOWER - - MODEL NUMBER R53SV (96141013501) - PRODUCT NUMBER 961 41 01-35

3


KEY NO.	PART NO.	DESCRIPTION
1	532 19 64-03	Upper Handle, with Foam Grip
2	532 15 34-18	Lower Handle
3	532 19 70-19	Control Bar
4	532 18 35-67	Engine Zone Control Cable
5	532 19 15-74	Handle Bolt
6	532 19 19-38	Handle Knob
7	532 05 17-93	Hairpin Cotter
8	532 06 64-26	Wire Tie
9	532 40 69-85	Rear Door Assembly
10	532 12 84-15	Pop Rivet
11	532 41 05-40	Support Bracket, LH
12	532 41 05-42	Support Bracket, RH
13	817 06 04-10	Screw 1/4-20 x 5/8
14	532 19 60-37	Handle Bracket Assembly, LH
15	532 19 60-36	Handle Bracket Assembly, RH
16	532 40 54-17	Spring, Rear Door, LH
17	532 40 54-18	Spring, Rear Door, RH
18	532 13 20-04	Keps Locknut 1/4-20
19	532 19 47-88	Rope Guide
20	532 41 05-36	Foot Guard
21	532 05 45-83	Screw, Hx Top 1/4-20 x 1/2
24	- - -	Engine, Honda, Model Number GCV-160
25	532 15 04-06	Hex Head Thread Rolling Screw 3/8-16 x 1-1/8
26	532 40 91-49	Hex Flange Nut
27	532 40 25-95	Wheel & Tire Assembly, Rear, 12"
28	532 16 08-28	Shoulder Bolt 5/16-18 x .33
29	532 12 50-78	Engine Washer
30	532 40 25-71	Axle Arm Assembly, Rear, RH
31	532 70 10-37	Selector Knob
32	532 19 01-57	Selector Spring
33	873 80 05-00	Nut, Hex 5/16-18

KEY NO.	PART NO.	DESCRIPTION
34	532 40 25-72	Axle Arm Assembly, Rear, LH
36	532 18 41-93	Bolt
37	874 78 05-12	Thread Cutting Screw w/Sems 5/16-18 x 3/4
38	819 11 22-06	Washer
39	532 19 85-41	Nut, Hex
40	532 19 09-39	Mounting Bracket, Debris Shield
41	532 19 23-25	Screw
43	532 40 58-44	Debris Shield
44	532 40 80-16	Kit, Lawn Mower Housing (Includes Key Numbers 10, 11, 12 and 45)
45	532 18 21-66	Danger Decal
46	532 19 77-52	Blade Adapter / Pulley
47	532 19 93-77	Blade, 21"
48	532 85 10-74	Hardened Washer
49	532 85 02-63	Helical Washer 3/8-24 x 1-3/8 Grade 8
50	532 85 10-84	Hex Head Machine Screw 3/8-24 x 1-3/8 Grade 8
57	532 12 51-62	Upstop Bracket
58	532 75 06-34	Screw
59	532 18 55-82	Discharge Deflector
60	532 17 57-35	Hinge Bracket
61	532 19 30-00	Spring
62	532 17 56-50	Hinge Rod
63	873 80 04-00	Nut, Hex
64	532 18 55-76	Mulcher Door
65	532 19 74-80	O-Ring
66	532 08 83-48	Washer, Flat 1/2
69	532 18 27-48	Grip, Foam
96	532 19 79-91	Clip, Cable
--	532 18 21-91	Decal, Warning (not shown)
--	532 41 13-72	Replacement Parts Manual
--	532 41 13-45	Operator's Manual Euro
--	532 41 13-46	Operator's Manual Scan
--	532 41 13-42	Operator's Manual Baltic


NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

ROTARY LAWN MOWER - - MODEL NUMBER R53SV (96141013501) - PRODUCT NUMBER 961 41 01-35



ROTARY LAWN MOWER - - MODEL NUMBER R53SV (96141013501) - PRODUCT NUMBER 961 41 01-35



ROTARY LAWN MOWER - - MODEL NUMBER R53SV (96141013501) - PRODUCT NUMBER 961 41 01-35

KEY NO.	PART NO.	DESCRIPTION
1	532 40 73-16	Drive Control Assembly
2	532 41 16-73	Cover, Drive Control, Upper
3	532 40 62-62	Pulley
4	532 19 00-39	Lever, Drive Control
5	532 41 16-64	Cover, Drive Control, Lower
6	532 18 16-98	Screw
7	532 40 07-23	Mounting Bracket, Drive Control
9	532 40 62-59	Cable, Drive
10	532 18 93-78	Decal, Drive Control
11	532 40 25-67	Wheel & Tire Assembly
12	812 00 00-58	E-Ring
13	532 40 38-49	Pinion
14	532 18 94-03	Dust Cover
15	532 19 10-17	Pawl, Drive
16	532 06 77-25	Washer 1/2 x 1-1/2 x .134
17	532 40 48-31	Bearing, Wheel Adjuster
18	532 70 10-37	Selector Knob
25	532 41 16-63	Belt Keeper
26	532 16 34-09	Screw
27	532 17 52-62	Screw, Pan Head, Self-Tapping #10-24 x 2-3/4
28	532 18 55-79	Drive Cover
29	532 19 41-49	V-Belt
32	532 19 40-18	Drive Pulley
33	532 40 91-48	Locknut, Hex

KEY NO.	PART NO.	DESCRIPTION
35	532 40 91-08	Kit, Wheel Adjuster, LH (Includes Knob and Bearing)
36	532 40 48-33	Gearcase Assembly, Complete
38	873 80 04-00	Locknut, Hex 1/4-20
40	532 40 65-58	Spring
41	532 40 91-09	Kit, Wheel Adjuster, RH (Includes Knob and Bearing)
54	532 40 19-03	Grassbag Assembly
57	532 40 18-02	Frame, Grassbag
60	532 19 35-57	Decal, Drive Cover
61	532 41 07-26	Case, Upper
62	532 41 09-49	Shaft, Output
63	532 18 35-08	Seal, Output Shaft
64	532 18 35-11	Bushing
65	532 18 35-09	Washer
66	532 18 35-14	Seal, Worm Shaft
67	532 18 35-06	Bearing, Ball
68	532 41 07-29	Gear, 28 Teeth
69	532 41 07-32	Fixed Dog Clutch
70	532 41 07-33	Pin
71	532 41 07-30	Movable Dog Clutch
73	532 18 35-13	Screw, Case
74	532 41 07-34	Case, Lower
78	532 41 07-31	Spring, Leaf
79	532 41 07-27	Shaft, Worm

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.