


H Husqvarna



Royal 36EL



1.1995

Spare parts





Ersatzteile




Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

A**B****C****D**

E**F****G****H**

MODEL NUMBER R36E

PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE
510 64 49-64	B		514 92 01-00	A				
510 64 81-01	G		514 92 33-00	F				
510 65 38-01	G		514 93 70-00	G	N			
510 65 40-01	G		515 00 19-00	B				
510 65 95-00	A		519 52 04-00	B				
510 65 97-00	F							
510 65 98-00	B							
510 65 99-00	F							
510 66 15-02	A							
510 67 28-01	G	N						
511 68 74-01	E							
511 74 53-01	B							
511 75 58-00	G	N						
511 76 67-01	E							
511 77 85-00	D							
511 78 55-00	D							
511 80 91-01	E	N						
512 62 40-01	E							
512 68 64-00	B							
512 70 08-00	G							
512 70 60-00	B							
512 70 61-00	B							
512 70 99-00	D							
512 72 50-03	H							
512 72 55-00	G							
512 73 77-00	F							
512 73 81-00	C	N						
512 73 97-00	F							
512 73 99-00	A							
512 74 14-01	C							
512 74 14-02	C							
512 75 15-00	C	N						
512 75 29-61	C	N						
513 01 27-00	D							
513 66 92-01	B							
513 76 08-01	D							
513 76 79-00	E							
513 77 50-00	E							
513 77 86-00	G							
513 78 99-00	B							
513 79 33-00	E							
513 80 24-00	E							
513 81 30-00	B							
513 83 11-00	F							
513 83 13-00	A							
513 83 46-01	B	N						
513 83 84-00	G	N						
514 02 66-00	E							
514 09 80-00	C							
514 15 85-00	C							
514 63 09-00	B							
514 66 72-00	E,G							
514 67 36-00	A							
514 68 24-00	A,B							
514 77 77-00	C							
514 82 59-00	D							
514 82 82-29	G	N						
514 86 57-00	G							
514 86 58-00	G							
514 87 73-00	G							
514 87 84-00	G							
514 87 96-00	B							
514 88 14-27	G							
514 88 14-28	G							
514 88 86-00	E							
514 90 24-00	G							
514 90 31-00	C							
514 90 46-00	B							
514 91 81-00	F							
514 91 97-01	B							
514 91 98-00	E	N						