


# Royal 46/46S



**1.1998**

**Spare parts**

**Ersatzteile**


**Pièces détachées**

**Reserve onderdelen**


**Repuestos**

**Reservdelar**

A




B




C

## Royal 46



D

## Royal 46S



516 88 70-00

531 00 50-35

515 79 60-01

515 12 39-30

Exploded view diagram of a mechanical assembly. The diagram shows the following parts and their corresponding part numbers:

- 516 93 03-01
- 729 53 67-71
- 516 63 18-01
- 516 93 37-04
- 531 00 50-36
- 516 86 80-00
- 516 86 95-11
- 515 11 30-32
- 515 13 97-54
- 516 86 69-11
- 516 93 04-01
- 516 61 91-01
- 516 93 33-00
- 516 88 29-00
- 516 87 72-00
- 516 93 39-01
- 728 63 66-00
- 516 67 14-00
- 516 61 74-00

Correction:  
516 61 74-00  
516 67 14-00