

Royal 48



1. 1988

Spare parts




Ersatzteile

Pièces détachées

Reserve onderdelen


Repuestos

Reservdelar

A**B****C**


D

516 92 12-00 (Quantum)
516 11 70-01 (Max)




E

Motor Briggs & Stratton
Quantum Model 100708 Type 0110 Trim 01
Max Model 111708 Type 0180 Trim02 (S.N.)



F



Ref. No. Teil-Nr. N° de réf. Ref. No. N° ref. Ref. nr.	Square Viereck Carreau Vak Cuadro Ruta	Ref. No. Teil-Nr. N° de réf. Ref. No. N° ref. Ref. nr.	Square Viereck Carreau Vak Cuadro Ruta
071 18 35-07	B	516 84 22-00	A
515 10 43-79	B	516 84 24-11	F
515 11 70-01	D	516 84 25-07	E
515 12 39-30	D	516 84 30-07	E
515 70 08-35	A	516 84 36-11	F
515 70 08-60	A	516 84 63-07	E
515 70 18-30	A	516 84 64-11	C
515 72 46-35	B	516 84 65-07	E
515 74 50-29	E	516 90 48-00	B
515 74 50-51	E	516 90 51-00	F
515 74 50-53	F	516 90 91-00	F
515 74 51-26	A	516 90 92-00	E
515 74 51-49	E, F	516 91 32-00	E
515 76 20-06	B	516 91 91-00	F
515 76 20-08	A, B	516 91 92-00	E
515 76 80-09	A	516 91 93-00	E
515 76 80-10	A, B	516 91 99-00	A
515 76 80-12	B	516 92 01-00	E
515 79 60-01	D	516 92 12-00	D
516 42 52-00	E		
516 42 53-00	E		
516 42 57-00	E		
516 42 58-00	E		
516 42 66-00	E		
516 42 75-11	F		
516 42 77-00	D		
516 42 90-00	E		
516 43 01-07	B		
516 43 19-00	E		
516 43 68-00	F		
516 43 88-00	F		
516 44 07-00	F		
516 44 50-00	E		
516 44 54-11	B		
516 44 89-00	E		
516 44 91-00	B		
516 44 99-11	B		
516 47 87-00	E		
516 49 00-00	E		
516 69 29-00	E		
516 69 31-00	F		
516 69 38-00	C		
516 69 82-00	E		
516 69 84-00	A		
516 69 96-11	C		
516 69 97-00	E		
516 69 98-00	E		
516 69 99-00	E		
516 81 80-00	F		
516 82 13-00	B		
516 82 27-00	B		
516 83 25-00	B		
516 83 58-07	E		
516 83 61-07	E		
516 83 63-07	B		
516 83 67-11	B		
516 83 68-11	B		
516 83 69-00	C		
516 83 74-08	F		
516 83 75-07	B		
516 83 81-07	E		
516 83 86-00	E		
516 83 89-07	E		
516 83 89-11	F		
516 83 96-11	B		
516 83 99-07	E		
516 84 20-00	D		