




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

LB448 S, 967622101, 2016-01


D LB 448S
ENGINE

ENGINE

LB448 S, 967622101, 2016-01

Ref	Part No	Description	Remark	QTY KIT	
1	725 24 61-51	SCREW EHHM		2	
2	722 78 39-02	BLIND RIVET		2	1
3	502 88 05-01	DEFLECTOR		1	1
4	.	TBD	GCV160 A0 S4-HB-SD	1	1
6	734 11 64-01	WASHER		2	
7	732 21 18-01	LOCK NUT		2	
8	502 88 29-01	SCREW		1	
9	502 94 53-01	BELT	Kit: 5254800-01 (Belt with shell)	1	
10	588 82 40-01	BLADE SUPPORT		1	
11	586 94 41-01	BELT COVER		1	
12	502 43 52-01	SCREW ITXPANTT		4	11
13	503 25 94-01	WASHER		1	
14	502 88 13-10	MOWER BLADE		1	
16	503 33 25-01	SPRING		1	
17	504 45 64-02	SCREW EHHI		1	
18	585 83 52-06	DECAL		1	




B GEAR
Mulch

GEAR BOX


LB448 S, 967622101, 2016-01

Ref	Part No	Description	Remark	QTY KIT	
1	585 19 26-01	TRANSMISSION KIT			
2	578 97 60-01	SCREW ITXPANTT		5	1
3	578 26 55-02	COVER		1	1
4	504 45 67-01	SCREW IHSCM		1	1
5	734 18 13-51	WASHER		2	1
6	587 23 54-01	PULLEY		1	1
7	502 88 03-01	SPRING		1	1
8	503 32 30-02	PULLEY ASSY		1	1
9	503 32 66-01	SPRING		1	1
10	578 34 28-02	HOUSING ASSY		1	1
11	504 45 73-01	WASHER		1	1
12	503 27 71-01	BUSHING		2	1
13	504 46 08-01	WASHER		1	1
14	578 89 91-01	LEVER		1	1
16	732 25 16-01	HEXAGON LOCKING NUT		2	1
17	578 26 56-01	SEALING RING		1	1
18	578 26 54-02	COVER		1	1
19	580 79 40-01	V-BELT	Kit: 5254799-01 (Belt with shell)	1	1
20	503 31 76-01	BARREL NUT		1	1
21	738 22 01-19	BALL BEARING	6201-2RS1	1	1
22	504 46 06-01	WASHER		1	1
23	725 63 69-51	SCREW IHCSFM		1	1
24	503 32 40-01	SPRING		1	1
25	727 64 51-51	SCREW		1	1
26	732 25 14-01	HEXAGON LOCKING NUT		1	1
27	578 26 52-02	HOUSING		1	1
28	504 45 60-01	WASHER, 5X13X1		1	1
29	504 46 19-01	SCREW IHSCM		1	1
30	503 32 44-01	BUSHING		1	1
31	503 32 81-05	WORM GEAR ASSY		1	
32	585 51 44-02	PULLEY KIT	For wormgear 5033281-03/-04/-05	1	31
33	522 54 63-01	BELT GUARD		1	31
34	504 46 70-01	SCREW ITXPANM		1	31
35	522 63 56-01	SCREW ITXPANM		1	31

C LB 448S
HANDLE

Ref	Part No	Description	Remark	QTY	KIT
1	579 15 91-02	BAIL ARM ASSY		1	
2	531 20 49-61	WASHER		1	
3	503 32 09-01	BUSHING		1	
4	576 64 19-01	HANDLE GRIP		1	
5	502 90 74-04	HANDLE ASSY		1	
6	725 23 81-51	SCREW EHHM		1	
7	732 25 16-01	HEXAGON LOCKING NUT		2	
8	504 45 99-01	WASHER		1	
9	585 40 20-04	CABLE		1	
10	579 14 37-02	CONTROL		1	
11	725 23 78-71	SCREW EHHM		1	
12	727 65 43-51	SCREW RSQM		1	15
13	503 29 83-01	LEVER ASSY		1	
14	504 45 73-01	WASHER		1	
15	503 28 43-02	HANDLE ASSY		1	
16	504 46 45-02	ADJUSTMENT WHEEL		2	
17	735 31 12-00	CIRCLIP		2	



A LB 448S
DECK

47

Ref	Part No	Description	Remark	QTY KIT	
1	503 27 51-01	HUB CAP		3	
2	504 45 83-01	CIRCLIP		2	
3	502 88 27-01	BALL BEARING	6201-2RS/B9	2	5
4	510 10 96-01	TYRE		4	5, 33, 43
5	503 27 54-02	WHEEL ASSY		2	
6	504 46 18-01	SPACER RING		2	5
7	503 24 29-01	BALL BEARING	6201-2RS	2	5
8	504 45 76-01	WASHER		2	
9	504 45 73-01	WASHER		4	
10	503 33 30-01	SPRING		2	
11	731 23 18-01	HEXAGON NUT		4	
12	735 21 64-01	LOCKWASHER		4	
13	503 26 58-02	HANDLE SUPPORT ASSY		1	
14	504 45 70-01	SCREW SLCSFM		4	
15	503 25 80-01	REAR AXLE ASSY		1	
16	735 31 10-00	CIRCLIP		2	
17	504 46 47-01	KNOB		1	
18	503 24 90-02	INDEX PLATE ASSY		1	
19	503 25 76-01	SPRING		1	
20	505 43 87-05	CHASSIS		1	
21	585 19 26-02	TRANSMISSION KIT		1	
22	725 23 29-61	SCREW EHHFT		4	
23	522 54 63-01	BELT GUARD		1	
24	522 63 56-01	SCREW ITXPANM		1	
25	504 46 70-01	SCREW ITXPANM		1	
26	503 24 95-02	ROD ASSY		1	
27	504 46 51-01	HUB CAP		1	
28	504 45 67-01	SCREW IHSCM		2	
29	504 45 99-01	WASHER		2	
30	503 33 23-01	SPRING		1	
31	504 46 09-01	WASHER		1	
32	504 46 13-01	DRIVER		1	
33	503 31 74-02	WHEEL ASSY		1	
34	503 27 71-01	BUSHING		1	33
35	504 46 36-01	BUSHING		2	
36	504 46 38-02	BRACKET		2	
37	502 89 81-02	CASING		2	
38	504 45 71-01	SCREW ITXPANM		4	
39	503 26 92-01	FRONT AXLE		1	
40	502 87 38-01	DRIVE SHAFT		1	
41	504 45 98-01	WASHER		1	
42	503 27 64-01	BUSHING		1	43
43	503 27 55-04	WHEEL ASSY		1	
45	504 45 65-01	SCREW ITXPANT		2	
46	503 24 30-01	MULCH WALL		1	
47	579 73 39-01	DECAL		1	